

**SERVICE MANUAL**  
**HIGH RESOLUTION DISPLAY MONITOR**  
**NSB1107STTUW/NUB1107STTUW**

**MITSUBISHI ELECTRIC CORPORATION**  
**NOVEMBER 1999**

**CBB-S5674A**

# Contents

## Contents

1. Specification .....	1
2. Circuit description .....	2-1
2.1 Outline .....	2-1
2.2 Power circuit .....	2-2
2.2.1 Outline .....	2-2
2.2.2 Rectifying smoothing circuit and rush current control .....	2-7
2.2.3 Higher harmonic circuit .....	2-10
2.2.4 Sub-power circuit .....	2-13
2.2.5 Main power circuit .....	2-13
2.2.6 Degaussing circuit .....	2-15
2.2.7 Power management circuit .....	2-15
2.2.8 Protection circuit .....	2-15
2.3 Deflection circuit block .....	2-18
2.3.1 Outline .....	2-18
2.3.2 Horizontal oscillation circuit, vertical oscillation circuit and blanking circuit .....	2-18
2.3.3 Horizontal output circuit .....	2-19
2.3.4 +B control circuit .....	2-19
2.3.5 CS/LIN circuit .....	2-20
2.3.6 H-POSI circuit .....	2-20
2.3.7 Vertical output circuit .....	2-20
2.4 High voltage circuit .....	2-22
2.4.1 DBF circuit .....	2-22
2.5 Video block .....	2-22
2.5.1 Image signal amplifying circuit .....	2-22
2.5.2 Synchronization separator circuit .....	2-23
2.5.3 On Screen Display circuit .....	2-23
2.6 Control circuit .....	2-23
2.6.1 Outline .....	2-23
2.6.2 Rotation circuit .....	2-23
2.6.3 Corner purity circuit .....	2-23
2.6.4 Geomagnetism canceler circuit .....	2-24
2.6.4.1 Meridional horizontal magnetic field cancel function .....	2-24
2.6.4.1.1 Horizontal magnetic field landing cancel .....	2-24
2.6.4.1.2 Horizontal magnetic field convergence cancel .....	2-24
2.6.4.2 Vertical magnetic field cancel function .....	2-25
2.6.4.2.1 Vertical magnetic field landing cancel .....	2-25

# Contents

2.6.4.2.2 Vertical magnetic field convergence cancel .....	2-25
2.6.4.2.3 Vertical magnetic field horizontal picture position cancel .....	2-25
2.6.5 DDCC circuit .....	2-30
2.6.6 Deflection compensation .....	2-34
2.6.6.1 PCC .....	2-34
2.6.6.2 PIN-KEY .....	2-34
2.7 Control software .....	2-37
2.7.1 Outline .....	2-37
2.7.2 Input SYNC judgment.....	2-37
2.7.3 Picture adjustment function.....	2-38
2.7.4 POWER SAVE function.....	2-38
2.7.5 Input connector select.....	2-39
2.8 USB circuit .....	2-41
2.8.1 Outline .....	2-41
2.8.2 USB 2 upstream .....	2-41
2.8.3 USB downstream power supply .....	2-42
2.8.4 USB monitor control .....	2-43
Descriptor of USB Monitor function .....	2-44
3. Adjustment procedure .....	3-1
3.1 Scope .....	3-1
3.2 Application .....	3-1
3.3 Measuring instruments .....	3-1
3.4 Standard setting state .....	3-2
3.4.1 Power voltage .....	3-2
3.4.2 Adjustment magnetic field .....	3-2
3.4.3 Signal cable .....	3-2
3.5 Preparatory inspections .....	3-2
3.6 Initializing the adjustment data in the EEPROM .....	3-3
3.7 Names of each monitor part .....	3-4
3.7.1 Configuration of front control panel .....	3-4
3.7.2 Configuration of rear input connector .....	3-5
3.7.3 OSD display matrix .....	3-6
3.7.3.1 User mode .....	3-6
3.7.3.2 Factory mode .....	3-8
3.8 Adjustment .....	3-12
3.8.1 How to select the factory adjustment (FACTORY) mode .....	3-12
3.8.1.1 Selecting with automatic adjustment device .....	3-12

# Contents

3.8.1.2	Selecting with front panel switches .....	3-12
3.8.2	Adjustments before aging .....	3-12
3.8.2.1	Adjusting the high voltage .....	3-12
3.8.2.2	SCREEN voltage adjustment .....	3-12
3.8.2.3	.....	3-13
3.8.2.4	Setting the high voltage protector working voltage .....	3-13
3.8.2.5	Shock test .....	3-13
3.8.2.6	Preadjustment before aging .....	3-13
3.8.2.7	Adjusting the landing (ITC/4 corner purity adjustment) .....	3-13
3.8.3	Adjustments after aging .....	3-14
3.8.4	Adjusting the picture size, position and distortion .....	3-14
3.8.4.1	Adjusting the picture rotation .....	3-14
3.8.4.2	Adjusting the back raster position .....	3-14
3.8.4.3	Adjusting the left/right distortion, picture width, picture position (H-PHASE) and vertical linearity (all modes) .....	3-15
3.8.4.4	Horizontal linearity adjustment .....	3-15
3.8.4.5	Adjusting the DBF amplitude and phase .....	3-15
3.8.5	Adjusting the cut off (using the automatic adjustment device) .....	3-17
3.8.6	Adjusting the RGB drive signal .....	3-20
3.8.6.1	Adjusting the R, G, B drive signal (Adjustment of COLOR 1) .....	3-20
3.8.6.2	Adjusting ABL .....	3-20
3.8.7	Adjusting the Purity .....	3-21
3.8.8	Adjusting the focus .....	3-22
3.8.9	Adjusting the convergence .....	3-23
3.8.9.1	Adjusting with ITC .....	3-23
3.8.9.2	Adjusting DDCP (using automatic adjustment device) .....	3-25
3.8.10	Default settings (With factory mode) .....	3-28
3.9	Inspections (In normal mode) .....	3-29
3.9.1	Electrical performance .....	3-29
3.9.1.1	Withstand voltage .....	3-29
3.9.1.2	Grounding conductivity check .....	3-29
3.9.1.3	Degaussing coil operation .....	3-29
3.9.1.4	POWER SAVE function operation .....	3-29
3.9.1.5	Confirming the MOIRE-CLEAR function .....	3-30
3.9.1.6	Confirming the CORNER-PURITY function .....	3-30
3.9.1.7	Focus, picture performance .....	3-30
3.9.1.8	Fixing the parts .....	3-30

# Contents

3.9.1.9 Mis-convergence .....	3-31
3.9.1.10 Picture distortion .....	3-32
3.9.1.11 Linearity .....	3-34
3.9.1.12 Adjustment value list .....	3-35
3.9.1.13 Confirming GTF .....	3-36
3.9.1.14 Checking the functions during Sync on Green and Composite Sync input ....	3-36
3.9.1.15 Confirming the D-SUB/BNC input .....	3-36
3.9.1.16 Confirming the ROTATION function and reset operation.....	3-36
3.9.1.17 Confirming the full white luminance .....	3-37
3.9.1.18 Confirming the back raster luminance .....	3-37
3.9.1.19 Luminance/color coordination uniformity .....	3-37
3.9.1.20 Confirming the full white color coordination.....	3-38
3.9.1.21 Confirming the color tracking .....	3-38
3.9.1.22 Confirming the TEXT MODE operation .....	3-38
3.9.1.23 Confirming the BLACK LEVEL .....	3-38
3.9.1.24 CRT installation position .....	3-38
3.9.1.25 Confirming the geomagnetism tolerance .....	3-38
3.9.1.26 Confirming the cancel function operation).....	3-39
3.9.1.27 Confirming the grill vibration .....	3-39
3.9.1.28 Confirming the USB hub .....	3-40
3.9.1.29 Others.....	3-40
3.10 Checking the DDC function (using automatic adjustment device) .....	3-40
3.10.1 Writing/checking the DDC and EDID data .....	3-40
3.10.2 Setting the serial No. ....	3-41
3.10.3 DDC write data contents .....	3-43
3.11 Default inspection .....	3-45
3.11.1 Default setting of switches .....	3-45
3.11.2 Default setting of OSD .....	3-45
3.11.3 Checking the labels .....	3-45
3.11.4 Packaging.....	3-45
3.12 Degaussing with handy-demagnetizer.....	3-46
3.12.1 General precautions .....	3-46
3.12.2 How to hold and use the handy-demagnetizer.....	3-46
3.13 Caution .....	3-46
3.14 Timing chart .....	3-47
3.15 Adjustment timing .....	3-48
3.16 USB monitor control data .....	3-50

# Contents

4.1 Circuit block diagram

5.1 PWB tangential diagram

5.2 B Chassis connector connection

5.3 Schematic diagram

6.1 Exploded view

6.2 Packing

<Appendix>

User's guide

**1. Specification**

# Specification

## Contents

1.	Regulations .....	1-3
1.1	Geographical Region and Regulation .....	1-3
2.	CRT specifications .....	1-5
3.	Electric specifications .....	1-6
3.1	Deflection performance .....	1-6
3.2	Signal input .....	1-6
3.3	Video characteristics .....	1-7
3.4	Power supply .....	1-7
3.5	Power management function (When USB is not connected) .....	1-7
3.6	Degaussing .....	1-7
4.	Functions .....	1-8
4.1	Front panel adjustment functions .....	1-8
4.2	OSD (On Screen Display) functions .....	1-9
4.3	Rear panel .....	1-10
4.4	Connector pin layout .....	1-11
4.5	DDC (Display Data Channel) function .....	1-11
4.6	Preset timing .....	1-11
4.7	USB (Universal Serial Bus) function .....	1-11
5.	Display performance .....	1-12
5.1	Testing condition .....	1-12
5.2	Display dimensions .....	1-12
5.3	Luminance (brightness) .....	1-12
5.4	Color coordination .....	1-12
5.5	Rotation .....	1-13
5.6	Other distortion .....	1-13
5.7	Linearity .....	1-14
5.8	Misconvergence .....	1-14
5.9	Focus .....	1-15
5.10	Raster size regulation .....	1-15
6.	Design and mechanism specifications .....	1-16
6.1	Cabinet and tilt stand .....	1-16
6.2	Rating label .....	1-16
6.3	Packing .....	1-16
6.4	Weight .....	1-16
6.5	Accessories .....	1-16



7. Environment conditions .....	1-17
7.1 Temperature, humidity and altitude .....	1-17
7.2 Vibration test (in packaged state) .....	1-17
7.3 Dropping test (with carton box) .....	1-18
Appendix 1 Preset timing chart .....	1-19
Appendix 2 EDID data for VESA DDC .....	1-20

# Specification

## 1. Regulations

### 1.1 Geographical Region and Regulation

Geographical region	REGULATIONS						
	SAFETY	EMC	X-RAY	ELF-VLF	Power Management	Ergonomics	Miscellaneous
NSB1107STTUW	UL C-UL TUV-GS	FCC-B DOC-B EN55022-B EN50082-1 EN61000-3-2 EN61000-3-3 VCCI-B JPHG	DHHS HWC RöV	MPR-II TCO'91	Energy Star Energy2000	TÜV-GS	TCO'99 CE Marking

UL : UL1950 3rd Edition

C-UL : CAN/CSA-22.2 No. 950:1995

TÜV-GS : EN60950:1992&AD1/AD2/AD3/AD4/AD11  
ISO9241-3, ISO9241-7, ISO9241-8

FCC : 47 CFR Part 15 Subpart B, Class B

DOC : Interference-Causing Equipment Standard ICES-003 Issue-003, Class B

DHHS : 21CFR Chapter I Subchapter J

HWC : Radiation Emitting Devices Regulations Chapter 1370

RöV : RöV Vom 8.1. 1987

MPR-II : MPR 1990:8

TÜV-ERGO : ISO9241-3, ISO9241-7, ISO9241-8 & MPPR-II

TCO'99 : Requirements for environmental labeling of personal computers (First Edition)

CE-Marking : EN60950:1992&AD1/AD2/AD3/AD4/AD11

EN55022-B :1994 Clas B

EN50082-1 :1992

EN61000-3-2 :1995

EN61000-3-3 :1995

Energy Star : International Energy Star office equipment Program

Energy Star2000 : Energy2000 energy-efficiency Label

VCCI : Guide to member ship of Voluntary Control Council for Interference by data Processing  
Equipment and Electronic Office Machines, Class B.

JPHG : Guidelines for the suppression of Harmonics in Appliances and General-Use Equipment  
(Japan

Power Harmonics  
Guidelines)

# Specification

Geographical region	REGULATIONS						
	SAFETY	EMC	X-RAY	ELF-VLF	Power Management	Ergonomics	Miscellaneous
NUB1107STTUW	UL	FCC-B	DHHS	MPR-II	Energy Star	TÜV-ERGO	TCO'99
	C-UL TUV-GS	DOC-B EN55022-B EN50082-1 EN61000-3-2 EN61000-3-3 VCCI-B JPHG	HWC RöV	TCO'91	Energy2000		CE Marking

- UL : UL1950 3rd Edition
- C-UL : CAN/CSA-22.2 No. 950:1995
- TÜV-GS : EN60950:1992&AD1/AD2/AD3/AD4 & ZH1/618
- FCC : 47 CFR Part 15 Subpart B, Class B
- DOC : Interference-Causing Equipment Standard ICES-003 Issue-003, Class B
- DHHS : 21CFR Chapter I Subchapter J
- HWC : Radiation Emitting Devices Regulations Chapter 1370
- RöV : RöV Vom 8.1. 1987
- MPR-II : MPR 1990:8
- TÜV-ERGO : ISO9241-3, ISD9241-7, ISO9241-8 & MPPR-II
- TCO'99 : Requirements for environmental labeling of personal computers (First Edition)
- CE-Marking : EN60950:1992&AD1/AD2/AD3/AD4/AD11  
 EN55022-B :1994 Clas B  
 EN50082-1 :1992  
 EN61000-3-2 :1995  
 EN61000-3-3 :1995
- Energy Star : International Energy Star office equipment Program
- Energy Star2000 : Energy2000 energy-efficiency Label
- VCCI : Guide to member ship of Voluntary Control Council for Interference by data Processing Equipment and Electronic Office Machines, Class B.
- JPHG (Japan Power Harmonics Guidelines) : Guidelines for the suppression of Harmonics in Appliances and General-Use Equipment

## Specification

### 2. CRT specifications

#### NSB1107STTUW

Model	M51LRY22X61
Type	Diamond Tron NF (aperture grill)
CRT size	55cm/51cm Diagonal Viewable Image (22"/20" Diagonal Viewable Image)
Grill pitch	0.24mm
Phosphors	0.25mm
Deflection angle	90 degrees
Phosphor type	B22 (Medium short persistence)
Electron gun type	S-NX-DBF
Transmittance	Approx. 39.8% (including coating)
Surface treatment	Coating (Anti-reflection, Anti-glare and Anti-static)
Max. phosphors surface size	406.1mm x 304.6mm
Surface curvature	Horizontal: 50000mm, Vertical: 80000mm
Phosphors color coordination	Red: X=0.625, Y=0.340 Green: X=0.285, Y=0.600 (Typical) Blue: X=0.150, Y=0.075

#### NUB1107STTUW

Model	M51LPE21X51
Type	Diamond Tron NF (aperture grill)
CRT size	22type (51cm)
Grill pitch	0.25mm (center) -0.27mm (periphery)
Deflection angle	90 degrees
Phosphors	B22 short afterglow
Electron gun	Inline P-NX-DBF gun
Transmittance	Approx. 40.5% (including coating)
Surface treatment	Low reflection antistatic coating
Max. phosphors surface size	406.1mm x 304.6mm
Surface curvature rate radius (reference)	Horizontal: 50000mm, Vertical: 80000mm
Phosphors color coordination	Red: X=0.625, Y=0.340 Green: X=0.290, Y=0.605 (Typical) Blue: X=0.150, Y=0.070

# ----- Specification -----

## 3. Electric specifications

### 3.1 Deflection performance

Horizontal deflection	Scanning frequency	30~121kHz
	Back porch	1.1 $\mu$ sec or more
	Blanking	2.3 $\mu$ sec or more
	Horizontal sync. signal width	0.7 $\mu$ sec or more
Vertical deflection	Scanning frequency	50~160Hz
	V-sync+V-back Porch	450 $\mu$ sec or more
	Vertical sync. signal width	When $2H \leq V_s \leq 10H$ $F_h \leq 50Hz$ When $3H \leq V_s \leq 10H$ $F_h > 50Hz$
	Total No. of scanings	(Vertical sync. signal width + 256H) or more

(\*) The display may not extend to the picture edges at a timing where the display time ratio is as follows:

72% or less (When horizontal frequency is 100kHz or more)

74% or less (When horizontal frequency is 100kHz or less)

Display time ratio = Horizontal display time/horizontal scanning time (%)

### 3.2 Signal input

<NSB1107STTUW>

Video signal	R. G. B video signal
Sync. signal	Sync on Green (Superimposed on green image signal) Composite sync. signal (Negative polarity TTL) Separate sync. signal (Positive/negative polarity TTL)
Video input impedance	75 $\Omega$
Sync. signal input impedance	2.2k $\Omega$
Signal input level	Video signal: 0.7V/1.0Vp-p $\pm$ 10% Sync on Green: 0.3Vp-p $\pm$ 10% Separate sync. signal: TTL level (>2.5V)

<NUB1107STTUW>

Video signal	R. G. B video signal
Sync. signal	Sync on Green (Superimposed on green image signal) Composite sync. signal (Negative polarity TTL) Separate sync. signal (Positive/negative polarity TTL)
Video input impedance	75 $\Omega$
Sync. signal input impedance	1k $\Omega$
Signal input level	Video signal: 0.7V/1.0Vp-p $\pm$ 10% Sync on Green: 0.3Vp-p $\pm$ 10% Separate sync. signal: TTL level (>2.5V)

# Specification

### 3.3 Video characteristics

Video clock frequency	240MHz
Rise/fall time	3.7nsec (standard) 10 to 90% (video amplitude: 35Vp-p)

- The input video signal rise/fall time is 2nsec or less.
- The video circuit rise/fall time is calculated with the following expression.

$$T_a = \sqrt{T_m^2 - (T_s^2 + T_p^2 + T_{sc}^2)}$$

- Where :
- T<sub>a</sub> = Amplifier rise / fall time
  - T<sub>m</sub> = Measured rise / fall time
  - T<sub>s</sub> = Input signal rise / fall time
  - T<sub>p</sub> = Probe effect on rise / fall time = 2.2 x R1 x Cp
  - R1 = Amplifier output resistance (ohm)
  - Cp = Total probe capacitance (F)
  - T<sub>sc</sub> = Scope rise / fall time = 0.35 / Scope bandwidth (MHz)

### 3.4 Power supply

Power voltage	100~120/220~240VAC±10%
Power frequency	50/60Hz±3Hz
Power consumption (standard)	155W 1.55A@100-120VAC 0.75A@220-240VAC (When USB device is not connected) 170W 1.70A@100-120VAC 0.80A@220-240VAC (When USB device is connected)
Leakage current	3.5mA or less
Rush current (at cold start)	70A 0-p or less

### 3.5 Power management function (When USB is not connected)

Mode	Sync. signal		Video	Power consumption	Recovery time	Power lamp
	Horizontal	Vertical				
Normal	On	On	Active	155W	—	Green
Standby	Off	On	Blank	15W or less	Approx. 3 sec.	Amber
Temporary stop	On	Off	Blank	15W or less	Approx. 3 sec.	Amber
Complete stop	Off	Off	Blank	3W or less	Approx. 12 sec.	Amber

- When a computer with the VESA DPMS (Display Power Management Signaling Standard) compatible power management function is connected and used, complies with the "International Energy Star Program".

### 3.6 Degaussing

- An interval of 15 minutes or more is required before carrying out degaussing again.


Automatic demagnetizing	Automatically demagnetizes when power is turned ON.
Manual demagnetizing	Demagnetizes when operations are carried out with demagnetizing menu in OSD.

4. Functions

4.1 Front panel adjustment functions


<NSB1107STTUW>

- a: POWER SWITCH
- b: POWER LAMP
- c: BNC/D-SUB: CONNECTOR SELECT/OSD
- d: ADJUST ITEM SELECT BUTTON
- e: ADJUST BUTTON



<NUB1107STTUW>

- a: POWER SWITCH
- b: POWER LAMP
- c: CONNECTOR SELECT BUTTON
- d: MAIN MANU SELECT BUTTON
- e: ENTER BUTTON
- f: SUB-MENU SELECT/ADJUST BUTTON
- g: USB DOWNSTREAM



# Specification

## 4.2 OSD (On Screen Display) functions

<NSB1107STTUW>

OSD1 group		Default setting	OSD3 group		Default setting
Contrast	0 - 100%	100%	TEXT mode	Sharp / Smooth	Sharp
Brightness	0 - 100%	Adjustment value	Black level	Low / High	High
Color number	1 (9300K)	1 (9300K)	Horizontal convergence	0 - 100%	Adjustment value
	2 (6500K)		Vertical convergence	0 - 100%	Adjustment value
	3 (5000K)		Vertical conv-top	0 - 100%	Adjustment value
R amplitude1,2,3	0 - 100%	Adjustment value	Vertical conv-bottom	0 - 100%	Adjustment value
G amplitude1,2,3	0 - 100%	Adjustment value	Horizontal conv-right	0 - 100%	Adjustment value
B amplitude1,2,3	0 - 100%	Adjustment value	Horizontal conv-left	0 - 100%	Adjustment value
Color temperature1,2,3	5000-9300K	9300K	Corner purity (TL)	0 - 100%	Adjustment value
Color reset1,2,3	PROCEED	-	Corner purity (TR)	0 - 100%	Adjustment value
OSD2 group		Default setting	Corner purity (BL)	0 - 100%	Adjustment value
Horizontal width	0 - 100%	Adjustment value	Corner purity (BR)	0 - 100%	Adjustment value
Horizontal phase	0 - 100%	Adjustment value	Moire cancel	Off / On	Off
Horizontal raster position	0 - 100%	Adjustment value	Moire cancel level	0 - 100%	0%
Vertical width	0 - 100%	Adjustment value	Clamp pulse position	Front / Back	Back
Vertical position	0 - 100%	Adjustment value	OSD4 group		Default setting
PPincushion	0 - 100%	Adjustment value	Degaussing	PROCEED	-
Kestone	0 - 100%	Adjustment value	Power save	Off / On	On
Top-Pin	0 - 100%	Adjustment value	Control lock	Off / On	Off
Bottom-Pin	0 - 100%	Adjustment value	OSD position	<- ->	Center
Rotation	0 - 100%	Adjustment value	All reset	PROCEED	-
Zoom	0 - 100%	Adjustment value	GTF auto adjust	PROCEED	-
Geometry reset	PROCEED	-	Diagnosis	Horizontal Frequency	
				Vertical Frequency	
				Preset Information	
				Connector Information	
			Language	ENG / GER	ENG
				ESP / FRA ITA / JAP	
			OSD5 group		
			PORT-A / PORT-B		
			USB upstream select A D-SUB / BNC		
			USB port combination B BNC / D-SUB		

NUB1107STTUW

OSD1 group		Default setting	OSD3 group		Default setting
Contrast	0 - 100%	100%	TEXT mode	Sharp / Smooth	Sharp
Brightness	0 - 100%	Adjustment value	Horizontal convergence	0 - 100%	Adjustment value
Color number	1 (9300K)	1 (9300K)	Vertical convergence	0 - 100%	Adjustment value
	2 (6500K)		Upper vertical convergence	0 - 100%	Adjustment value
	3 (5000K)		Lower vertical convergence	0 - 100%	Adjustment value
R amplitude1,2,3	0 - 100%	Adjustment value	Right vertical convergence	0 - 100%	Adjustment value
G amplitude1,2,3	0 - 100%	Adjustment value	Left vertical convergence	0 - 100%	Adjustment value
B amplitude1,2,3	0 - 100%	Adjustment value	MOIRE clear	Off / On	Off
Color temperature1,2,3	5000-9300K	9300K	MOIRE clear level	0 - 100%	0%
Color reset1,2,3	PROCEED	-	Upper left purity	0 - 100%	Adjustment value
OSD2 group		Default setting	Upper right purity	0 - 100%	Adjustment value
Horizontal width	0 - 100%	Adjustment value	Lower left purity	0 - 100%	Adjustment value
Horizontal phase	0 - 100%	Adjustment value	Lower right purity	0 - 100%	Adjustment value
Horizontal raster position	0 - 100%	Adjustment value	Clamp position	Front / Back	Back
Vertical width	0 - 100%	Adjustment value	Video amplitude	1.0V / 0.7V	0.7V
Vertical position	0 - 100%	Adjustment value	OSD4 group		Default setting
Pin-cushion distortion	0 - 100%	Adjustment value	Degaussing	PROCEED	-
Trapezoid distortion	0 - 100%	Adjustment value	Power save	Off / On	On
Center pincushion distortion	0 - 100%	Adjustment value	Control lock	Off / On	Off
Upper pincushion distortion	0 - 100%	Adjustment value	Menu position	<- ->	Center
Lower pincushion distortion	0 - 100%	Adjustment value	All reset	PROCEED	-
Pincushion balance	0 - 100%	Adjustment value	GTF automatic size	PROCEED	-
Parallelogram distortion	0 - 100%	Adjustment value	Information	Horizontal Frequency	
Peripheral pincushion distortion balance	0 - 100%	Adjustment value		Vertical Frequency	
Center pincushion distortion balance	0 - 100%	Adjustment value		Preset Information	
Vertical linearity balance	0 - 100%	Adjustment value		Connector Information	
Vertical linearity	0 - 100%	Adjustment value	Language select	ENG / GER	JAP
Rotation	0 - 100%	Adjustment value		ESP / FRA ITA / JAP	
Zoom	0 - 100%	Adjustment value	OSD5 group		
Screen reset	PROCEED	-	PORT-A / PORT-B		
			USB upstream select A D-SUB / BNC		
			USB port combination B BNC / D-SUB		



**4.3 Rear panel**

a: Power input connector (3P IEC plug)

b: Signal input connector (mini D-Sub 15P)

c: Signal input connector (BNC)

Red Video signal

Green Video signal or, green Video signal + composite sync. signal  
(Sync on Green)


Blue Video signal

Horizontal sync. signal/Composite sync. signal

Vertical sync. signal

d: USB upstream (x2)


e: USB downstream (x2)



#### 4.4 Connector pin layout

(1) Mini D-Sub 15-pin

Pin	Signal
1	Red video signal
2	Green video signal, or Green video signal+Composite sync. signal
3	Blue video signal
4	Ground
5	Ground
6	Ground (red)
7	Ground (green)
8	Ground (blue)
9	Not used
10	Ground
11	Ground
12	Serial data
13	Horizontal sync. signal / Composite sync. signal
14	Vertical sync. signal
15	Serial clock



Rear panel

#### 4.5 DDC (Display Data Channel) function

Compatible with VESA DDC1 and DDC2B (Only EDID data)

The EDID data is listed in Appendix 2.

#### 4.6 Preset timing

- Factory preset: 11 (Refer to Appendix 1 for the factory-set timing)
- User preset: 15 (Max. No. of set timings)

Preset timing discrimination

Horizontal scanning frequency	Must be separated by 1kHz or more
Vertical scanning frequency	Must be separated by 1Hz or more
Sync. signal polarity	The horizontal or vertical synchronization signal polarity must be different.

- If even one of the above conditions is satisfied for the preregistered factory and user preset timing, the judgement can be made.

#### 4.7 USB (Universal Serial Bus) function

Universal Serial Bus Specification Revision 1.0 compatible

Operates under Windows 98 environment.

SELF POWERED HUB (Up to one downstream port 500mA can be supplied)

3 x downstream port

2 x upstream port

Monitor Control function

Compatible with Windows98 only

# Specification

## 5. Display performance

### 5.1 Testing conditions

Power supply	100VAC 60Hz or 230VAC 50Hz
Video input signal	1600×1200 (106kHz, 85Hz), 0.7Vp-p
Warm up	30 min. or more with fully white picture
Ambient temperature	20~25°C
Relative humidity	40~80%
Environment magnetic field	BH=0, BV=0.040mT
Contrast, brightness setting	Contrast: max., brightness: factory-set state
Display dimensions	393mm×295mm : 4 : 3 Aspect ratio
Ambient lighting	200±50lx
Luminance meter	Minolta CA-100 or equivalent

• Items with no particular designated are tested at the factory-set state.

### 5.2 Display dimensions

<NSB1107STTUW>

For aspect ratio 4:3	Width: 393mm, height: 295mm
For aspect ratio 5:4	Width: 369mm, height: 295mm

<NUB1107STTUW>

For aspect ratio 4:3	Width: 393mm±5mm, height: 295mm±5mm
For aspect ratio 5:4	Width: 369mm±5mm, height: 295mm±5mm

### 5.3 Luminance (brightness)

CRT center luminance (brightness)	Full white: 100cd/m <sup>2</sup> or more (At color No. 1) 85cd/m <sup>2</sup> or more (At color No. 2) 70cd/m <sup>2</sup> or more (At color No. 3)
Luminance (brightness) evenness	Δ Luminance/center luminance: 25% or less
Back raster luminance (brightness)	Approx. 0.3cd/m <sup>2</sup> : Factory-set state No back raster must be visible at minimum brightness.

### 5.4 Color coordination


Color temperature setting value	Color-1: 9300K±8 M.P.C.D. X=0.283±0.020 Y=0.297±0.020
	Color-2: 6500K X=0.313±0.020 Y=0.329±0.020
	Color-3: 5000K±8 M.P.C.D. X=0.345±0.020 Y=0.359±0.020
White color evenness	0.020 or less: Difference of picture center and X or Y of periphery
Color tracking	±0.020 or less: Video input level: 10cd/m <sup>2</sup> to MAX
	±0.020 or less: Contrast adjustment: 25cd/m <sup>2</sup> to MAX (Brightness is adjusted at factory-set state)

# Specification

## 5.5 Rotation

Rotation	$ H1 - H2  \leq 3.5\text{mm}$
----------	-------------------------------


- Green monochrome crosshatch applied.
- The active display rotation is such that a horizontal line located at the center of the display is 3.5mm or less.



## 5.6 Other distortion

All other distortion excluding picture inclination and picture position	H: $\leq 2.5\text{mm}$ , V: $\leq 3.0\text{mm}$
---	---

- Green monochrome crosshatch display
- The screen inclination and screen position must be in the hatched section after being adjusted to the optimum level.




**5.7 Linearity**

Linearity	Horizontal: 10% or less, adjacent: 7% or less
	Vertical: 10% or less, adjacent: 7% or less

- Specified at the preset timing.
- Display a green monochrome crosshatch (16 x 12 pitch) with 17 vertical and 13 horizontal lines.
- Calculate the max. pitch as Xmax, and the min. pitch as Xmin using the following expression.

$$\frac{X_{max} - X_{min}}{X_{max}} \times 100\%$$





X1 = X2 = X3 = ... = X16  
 Y1 = Y2 = Y3 = ... = Y12

**5.8 Misconvergence**

Misconvergence	Area A : ≤ 0.3mm within the 295mm diameter circle
	Area B : ≤ 0.35mm within the 393mm x 295mm

- With white crosshatch applied.
- Area A is a circular area with 295mm diameter at the center.
- Area B is a rectangular area (393mm x 295mm) outside of the area A.
- Use worst case horizontal/vertical misconvergence between any two primary colors.



# ----- Specification -----

## 5.9 Focus

Focus	Display a 7×9 pixel "e" with white single pixel strokes, the entire picture shall be readable with clearly discernible characters at normal viewing distance.
-------	---

## 5.10 Raster size regulation

Raster size regulation	≤0.5% of the horizontal or vertical picture size
------------------------	--

- The picture size change is adjusted value or less in either the horizontal or vertical direction over 30% to 100% luminance range and 90-132VAC or 198-264VAC input respectively.

# Specification

## 6. Design and mechanism specifications

### 6.1 Cabinet and tilt stand

Plastic material	Cabinet: PC+HIPS (Flame Class 2.5mm 5VA) Tilting table: ABS (Flame Class HB)
Outer color	Grayish White (Mitsubishi color No.: B-N-C039)
Logo display	Refer to Fig. 2.
Tilt table adjustment angle	Left/right: $-90^{\circ} \sim +90^{\circ}$ , Up/down: $10^{\circ} \sim -5^{\circ}$
Outline dimensions	500mm (W)×500mm (H)×482mm (D) Refer to Fig. 1

### 6.2 Rating label

Refer to fig. 3.

### 6.3 Packing

Packaging box specifications	Material: Class 2 double-sided cardboard Stacking height: Max. five levels
Packaging box printing specifications	Refer to Fig. 5.
Packaging box outline dimensions	Refer to Fig. 4.
Packaging box drawing	Refer to Fig. 6.

### 6.4 Weight

<NSB1107STTUW>

Net	Approx. 31kg (68.3 lbs)
Gross	Approx. 36.5kg (80.5 lbs)

<NUB1107STTUW>

Net	Approx. 33kg
Gross	Approx. 39.5kg

### 6.5 Accessories

<NSB1107STTUW>

Power cord	North America	see Fig. 7-1	
	Europe	Except UK	see Fig. 7-2
		U.K.	see Fig. 7-3
	Australia	see Fig. 7-4	
Signal cable	SC-B104: see Fig. 8		
User's guide	North America	English	
	Europe	5 Languages (English, German, French, Italian, Spanish)	
	Australia		

<NUB1107STTUW>

Power cord	2-pole power core with grounding lead wire: Refer to Fig. 7.
Signal cable	SC-B102 : Refer to Fig. 8.
USB cable	RC-X301 : Refer to Fig. 9.
User's guide	English
Warranty card	

# ----- Specification -----

## 7. Environment conditions

### 7.1 Temperature, humidity and altitude

	Operating	Storage and shipment
Temperature	5~35°C	-20~60°C
Relative humidity	10~90% (Without condensation)	10~95% (Without condensation)
Altitude	3000m (10000ft)	15000m (50000ft)

### 7.2 Vibration test (in packaged state)

#### (1) Sine wave vibration (resonance point search)

Test axis	3 axes
Search frequency	5~200Hz
Sweep time	2 minutes
Acceleration	4.9m/s <sup>2</sup> (0-P)
Dwelling time	5 minutes for each resonant point of each 3 axis
Mounting	Fixed firmly on the vibration table


#### (2) Random vibration

Test axis	3 axes
Search frequency	5~200Hz
Acceleration	0-14.42m/s <sup>2</sup> rms
Dwelling time	30 minutes x 3 axis
Mounting	Fixed firmly on the vibration table



# Specification


## 7.3 Dropping test (with carton box)



The inside unit shall be withstand without any damage by following procedure. Drop to the hard wooden board from the position of the following height.

	Position	Height
Corner	1	46cm (18 inch)
Edge	2, 3, 4, 5	46cm (18 inch)
Surface	A, B, C, D, E	46cm (18 inch)

Appendix 1 Preset timing chart



NO.	Clock (MHz)	Th (μsec) (dot)	Tsh (μsec) (dot)	Tfh (μsec) (dot)	Tbh (μsec) (dot)	Tdh (μsec) (dot)	Tv (msec) (line)	Tsv (msec) (line)	Tfv (msec) (line)	Tbv (msec) (line)	Tdv (msec) (line)	Hs	Vs	Fh (kHz)	Fv (Hz)	Remarks
0	25.175	31.778 (800)	3.813 (96)	0.636 (16)	1.907 (48)	25.422 (640)	16.683 (525)	0.064 (2)	0.318 (10)	1.048 (33)	15.253 (480)	-	-	31.470	59.940	VESA 640x480 / 60Hz
1	56.250	18.631 (1048)	1.138 (64)	0.569 (32)	2.702 (152)	14.222 (800)	11.756 (631)	0.056 (3)	0.019 (1)	0.503 (27)	11.179 (600)	+	+	53.674	85.061	VESA 800x600 / 85Hz
2	78.750	16.661 (1312)	1.219 (96)	0.203 (16)	2.235 (176)	13.004 (1024)	13.328 (800)	0.050 (3)	0.017 (1)	0.466 (28)	12.795 (768)	+	+	60.020	75.029	VESA 1024x768 / 75Hz
3	94.500	14.561 (1376)	1.016 (96)	0.508 (48)	2.201 (208)	10.836 (1024)	11.765 (808)	0.044 (3)	0.015 (1)	0.524 (36)	11.183 (768)	+	+	68.677	84.997	VESA 1024x768 / 85Hz
4	100.000	14.560 (1456)	1.280 (128)	0.320 (32)	1.440 (144)	11.520 (1152)	13.322 (915)	0.044 (3)	0.043 (3)	0.568 (39)	12.667 (870)	-	-	68.680	75.060	APPLE 21 1152x870 / 75Hz
5	135.000	12.504 (1688)	1.067 (144)	0.119 (16)	1.837 (248)	9.481 (1280)	13.329 (1066)	0.038 (3)	0.013 (1)	0.475 (38)	12.804 (1024)	+	+	79.976	75.025	VESA 1280x1024 / 75Hz
6	157.500	10.971 (1728)	1.016 (160)	0.406 (64)	1.422 (224)	8.127 (1280)	11.761 (1072)	0.033 (3)	0.011 (1)	0.483 (44)	11.234 (1024)	+	+	91.146	85.027	VESA 1280x1024 / 85Hz
7	202.500	10.667 (2160)	0.948 (192)	0.316 (64)	1.501 (304)	7.901 (1600)	13.333 (1250)	0.032 (3)	0.011 (1)	0.491 (46)	12.800 (1200)	+	+	93.750	75.000	VESA 1600x1200 / 75Hz
8	229.500	9.412 (2160)	0.837 (192)	0.279 (64)	1.325 (304)	6.972 (1600)	11.765 (1250)	0.028 (3)	0.009 (1)	0.433 (46)	11.294 (1200)	+	+	106.250	85.000	VESA 1600x1200 / 85Hz
9	297.000	8.889 (2640)	0.754 (224)	0.485 (144)	1.185 (352)	6.465 (1920)	13.333 (1500)	0.027 (3)	0.009 (1)	0.498 (56)	12.800 (1440)	-	+	112.500	75.000	VESA 1920x1440 / 75Hz
10	299.667	8.303 (2488)	0.667 (200)	0.481 (144)	1.148 (344)	6.007 (1800)	11.765 (1417)	0.025 (3)	0.008 (1)	0.523 (63)	11.208 (1350)	-	-	120.445	85.000	GTF 1800x1350 / 85Hz

# Specification

## Appendix 2 EDID data for VESA DDC

<NSB1107STTUW>

ROM-address

0C32~	00 ff ff ff ff ff ff 00 34 ac 11 43 ** ** ** **
0C42~	WW YY 01 01 0e 28 1e 78 e9 04 88 a0 57 4a 9b 26
0C52~	12 48 4c ff ff 80 31 59 d1 4f a9 59 a9 4f 81 99
0C62~	e1 4f 61 59 45 59 0f 75 08 b0 72 46 43 50 90 c8
0C72~	13 00 89 27 11 00 00 18 00 00 00 fd 00 32 a0 1e
0C82~	79 24 00 0a 20 20 20 20 20 20 00 00 fc 00 0e
0C92~	53 42 31 31 30 37 55 0a 20 20 20 20 20 00 00 ff
OCA2~0CB1	00 NN NN NN NN NN NN NN NN NN NN 20 20 00 00 SS

-- EDID DATA DUMP TEXT --

Vendor Name: MEL  
 Product Code LSB (HEX): 11  
 Product Code MSB (HEX): 43  
 Product Code (DEC): 17169  
 (Microsoft INF ID: MEL4311)  
 Serial Number (DEC): 0  
 Serial Number (HEX): 00000000  
 Week of Manuf: WW  
 Year of Manuf: YY

EDID Version: 1  
 EDID Revision: 1  
 Extension Flag: 0

Input Singal: ANALOG  
 Setup: NO  
 Sync on Green: YES  
 Composite Sync: YES  
 Separate Sync: YES  
 V Sync Serration: NO  
 V Signal Level: 0.700V/0.300V (1V p-p)

Max Image Size H (cm): 40  
 Max Image Size V (cm): 30  
 DPMS Stand By: YES  
 DPMS Suspend: YES  
 DPMS Active Off: YES  
 GTF Support: YES  
 Standard default Color Space: NO  
 Preferred Timing Mode: NO  
 Display Type: RGB Color

Gamma: 2.2  
 Red x: 0.625  
 Red y: 0.340  
 Green x: 0.290  
 Green y: 0.605  
 Blue x: 0.150  
 Blue y: 0.070  
 White x: 0.283  
 White y: 0.297

Established Timings:

720x400@70  
 720x400@88  
 640x480@60  
 640x480@67  
 640x480@72  
 640x480@75  
 800x600@56  
 800x600@60  
 800x600@72  
 800x600@75  
 832x624@75  
 1024x768@87  
 1024x768@60  
 1024x768@70  
 1024x768@75  
 1152x870@75  
 1280x1024@75

Standard Timing #1:  
 Horizontal Active Pixels: 640  
 Aspect Ratio: 4:3  
 (480 active lines)  
 Refresh Rate: 85Hz

Standard Timing #2:  
 Horizontal Active Pixels: 1920  
 Aspect Ratio: 4:3  
 (1440 active lines)  
 Refresh Rate: 75Hz

Standard Timing #3:  
 Horizontal Active Pixels: 1600  
 Aspect Ratio: 4:3  
 (1200 active lines)  
 Refresh Rate: 85Hz

Standard Timing #4:  
 Horizontal Active Pixels: 1600  
 Aspect Ratio: 4:3  
 (1200 active lines)  
 Refresh Rate: 75Hz

Standard Timing #5:  
 Horizontal Active Pixels: 1280  
 Aspect Ratio: 5:4  
 (1024 active lines)  
 Refresh Rate: 85Hz

Standard Timing #6:  
 Horizontal Active Pixels: 2048  
 Aspect Ratio: 4:3  
 (1536 active lines)  
 Refresh Rate: 75Hz

Standard Timing #7:  
 Horizontal Active Pixels: 1024  
 Aspect Ratio: 4:3  
 (768 active lines)  
 Refresh Rate: 85Hz

Standard Timing #8:  
 Horizontal Active Pixels: 800  
 Aspect Ratio: 4:3  
 (600 active lines)  
 Refresh Rate: 85Hz

Detailed Timing (block #1):  
 Pixel Clock: 299.67  
 Horizontal Active: 1800  
 Horizontal Blanking: 688  
 Vertical Active: 1350 lines  
 Vertical Blanking: 67 lines  
 (Horizontal Frequency: 120.45 kHz)  
 (Vertical Frequency: 85.0 Hz)  
 Horizontal Sync Offset: 144 pixels  
 Horizontal Sync Width: 200 pixels  
 Vertical Sync Offset: 1 lines  
 Vertical Sync Width: 3 lines  
 Horizontal Border: 0 pixels  
 Vertical Border: 0 lines  
 Horizontal Image Size: 363 mm  
 Vertical Image Size: 295 mm  
 Interlaced: NO  
 Image: Normal Display  
 Sync: Digital Separate  
 Bit 1: OFF  
 Bit 2: OFF

Monitor Range Limits (block #2):  
 Minimum Vertical Rate: 50 Hz  
 Maximum Vertical Rate: 160 Hz  
 Minimum Horizontal Rate: 30 kHz  
 Maximum Horizontal Rate: 121 kHz  
 Maximum Pixel Clock: 330 MHz  
 GTF Data: 00 0a 20 20 20 20 20

Monitor Name (block #3): NSB1107U

Monitor Serial Number (block #4):  
 NNNNNNNNNN

EDID EDITOR V1.34 (990407) (C)  
 Mitsubishi Electric 1995-1999

EDID DATA DUMP HEX

```
00 ff ff ff ff ff ff 00
34 ac 11 43 ** ** ** **
WW YY 01 01 0e 28 1e 78
e9 04 88 a0 57 4a 9b 26
12 48 4c ff ff 80 31 59
d1 4f a9 59 a9 4f 81 99
e1 4f 61 59 45 59 0f 75
08 b0 72 46 43 50 90 c8
13 00 89 27 11 00 00 18
00 00 00 fd 00 32 a0 1e
79 24 00 0a 20 20 20 20
20 20 00 00 00 fc 00 52
53 46 32 32 48 0a 20 20
20 20 20 20 00 00 00 ff
00 NN NN NN NN NN NN NN
NN NN 0a 20 20 20 00 SS
** : Serial number 1(HEX)
WW : Week of manufacture
YY : Year of manufacture
NN : Serial number 2 (ASCII)
SS : Checksum
```

# Specification

<NUB1107STTUW>

-- EDID DATA DUMP TEXT --

Vendor Name: MEL  
Product Code LSB (HEX): 0  
Product Code MSB (HEX): 43  
Product Code (DEC): 17152  
(Microsoft INF ID: MEL4300)  
Serial Number: 0 HEX: 0  
Week of Manuf: 1  
Year of Manuf: 98

EDID Version: 1  
EDID Revision: 1  
Extension Flag: 0

Input Singal: ANALOG  
Setup: NO  
Sync on Green: YES  
Composite Sync: YES  
Separate Sync: YES  
V Sync Serration: NO  
V Signal Level: 0.700V/0.300V (1V p-p)

Max Image Size H (cm): 40  
Max Image Size V (cm): 30  
DPMS Stand By: YES  
DPMS Suspend: YES  
DPMS Active Off: YES  
GTF Support: YES  
Display Type: RGB Color

Gamma: 2.2  
Red x: 0.625  
Red y: 0.340  
Green x: 0.290  
Green y: 0.605  
Blue x: 0.150  
Blue y: 0.070  
White x: 0.283  
White y: 0.297

Established Timings:

720x400@70  
720x400@88  
640x480@60  
640x480@67  
640x480@72  
640x480@75  
800x600@56  
800x600@60  
800x600@72  
800x600@75  
832x624@75  
1024x768@87  
1024x768@60  
1024x768@70  
1024x768@75  
1152x870@75  
1280x1024@75

Standard Timing #1:  
Horizontal Active Pixels: 1800  
Aspect Ratio: 5:4  
Refresh Rate: 80

Standard Timing #2:  
Horizontal Active Pixels: 1800  
Aspect Ratio: 4:3  
Refresh Rate: 85

Standard Timing #3:  
Horizontal Active Pixels: 1600  
Aspect Ratio: 4:3  
Refresh Rate: 85

Standard Timing #4:  
Horizontal Active Pixels: 1600  
Aspect Ratio: 4:3  
Refresh Rate: 75

Standard Timing #5:  
Horizontal Active Pixels: 1280  
Aspect Ratio: 5:4  
Refresh Rate: 85

Standard Timing #6:  
Horizontal Active Pixels: 1280  
Aspect Ratio: 5:4  
Refresh Rate: 75

Standard Timing #7:  
Horizontal Active Pixels: 1024  
Aspect Ratio: 4:3  
Refresh Rate: 85

Standard Timing #8:  
Horizontal Active Pixels: 800  
Aspect Ratio: 4:3  
Refresh Rate: 85

Detailed Timing (block #1):  
Pixel Clock: 299.95  
Horizontal Active: 1800  
Horizontal Blanking: 688  
Vertical Active: 1440  
Vertical Blanking: 67  
(Horizontal Frequency: 120.56 kHz)  
(Vertical Frequency: 79.9 Hz)  
Horizontal Sync Offset: 144  
Horizontal Sync Width: 200  
Vertical Sync Offset: 1  
Vertical Sync Width: 3  
Horizontal Border: 0  
Vertical Border: 0  
Horizontal Image Size: 369  
Vertical Image Size: 295  
Interlaced: NO  
Image: Normal Display  
Sync: Digital Separate  
Bit 1: OFF  
Bit 2: OFF

Monitor Range Limits (block #2):  
Minimum Vertical Rate: 50 Hz  
Maximum Vertical Rate: 160 Hz  
Minimum Horizontal Rate: 30 kHz  
Maximum Horizontal Rate: 121 kHz  
Maximum Pixel Clock: 330 MHz  
GTF Data: 00 0a 20 20 20 20 20

Monitor Name (block #3): NUB1107STTUW

Monitor Serial Number (block #4):  
NNNNNNNNN

EDID EDITOR V1.17 (970612) (C)  
Mitsubishi Electric

EDID DATA DUMP HEX  
00 ff ff ff ff ff ff 00  
34 ac 00 43 \*\* \*\* \*\* \*\*  
WW YY 01 01 0e 28 1e 78  
e9 04 88 a0 57 4a 9b 26  
12 48 4c ff ff 80 c2 94  
c2 59 a9 59 a9 4f 81 99  
81 8f 61 59 45 59 2b 75  
08 b0 72 a0 43 50 90 c8  
13 00 71 27 11 00 00 18  
00 00 00 fd 00 32 a0 1e  
79 21 00 0a 20 20 20 20  
20 20 00 00 00 fc 00 52  
44 46 32 32 48 0a 20 20  
20 20 20 20 00 00 00 ff  
00 NN NN NN NN NN NN NN  
NN NN 0a 20 20 20 00 SS

\*\* : Serial number (HEX)  
WW : Week of manufacture  
YY : Year of manufacture  
NN : Serial number (ASCII)  
SS : Checksum

## **2. Circuit description**

### **2.1 Outline**

This display monitor is configured of the following eight blocks.

- (a) Power block
- (b) Deflection circuit block
- (c) High-voltage circuit
- (d) Video circuit block
- (e) Control circuit
- (f) Control software
- (g) USB circuit
- (h) CRT drive circuit

Details of each circuit are given in this section.

## Circuit description

### 2.2 Power circuit

#### 2.2.1 Outline

- (1) The power block is compatible with 100 to 120VAC/220 to 240VAC (50/60Hz).
- (2) An active filter circuit is incorporated to suppress the higher harmonic current and improve the power factor.
- (3) The circuit that supplies to the secondary side is divided into two, with one called the main power and the other called the sub-power.

During normal use, both the main power and sub-power supply power to the secondary side, but during power save, only the sub-power functions.

The main power is configured with a pseudo-resonance operation fly-back converter type switching control IC. The sub-power is configured with a PWM (Pulse Width Modulation) control IC.

Each power circuit suppresses the voltage fluctuation caused by the secondary load fluctuation by feeding back the voltage fluctuation from the secondary side of the transformer via a photo coupler.

- (4) The secondary side output is as shown in Table 1.

This power block only generates power to the reference voltage. Thus, the voltage required for each circuit block (i.e., +12V or +5V) is generated in the respective circuit block or by the three-terminal regulator, etc., in the PWB mounted on the circuit block.


(Refer to power system diagram)

Power block	Circuit name	Output voltage (actual measurement value)	Application
Main power section	+180V	+188V	Horizontal deflection circuit, VIDEO cutoff circuit
	+80V	+75V	
	+15V	+15.3V	DBF circuit, high-voltage circuit
	-15V	-15.4V	+12V Reg, etc.
	H-CENT (+)	4.56V (across +B)	-12V Reg, etc.
	+B	+B	Horizontal position control circuit
	H-CENT (-)	-4.61V (across +B)	
	+6.5V	+6.6V	
Sub-power supply section			Heater, +5V Reg, USB circuit

Table 1


# Circuit description

~Power system diagram 1~



# Circuit description



~Power system diagram 2~






# Circuit description

~Power system diagram 3~



# Circuit description

~Power system diagram 4~



## Circuit description

### 2.2.2 Rectifying smoothing circuit and rush current control

- (1) The AC input voltage is rectified by the diode bridge in the IC901.
- (2) The R902 is inserted as a series in the rectifying line to suppress the rush current when the power switch is turned ON.  
The same effect can be achieved with the R973, but it is added as a measure against EMI.
- (3) The AC input when the power is turned ON charges C908 from D5, D6 via R904/R905. During this time, R902 acts as the current limiting element.
- (4) When C908 is charged, the internal thyristor turns ON. R902 is short-circuited to prevent power loss from R902.
- (5) When the power is turned OFF, the C908 charge is discharged via R903.  
The rectified voltage is supplied to the active filter circuit.




Figure 1. Rectifying smoothing circuit

----- Circuit description -----




Figure 2

Circuit description




Figure 3

### 2.2.3 Higher harmonic circuit

- (1) This circuit detects the current that continuously flows through L903, and tracks this current voltage to the full-wave rectified voltage.  
(Smoothing current mode control).
- (2) A Motorola MC33262 is used for control. (Refer to Fig. 4.)
- (3) The IC902 pin No. 1 is the voltage feedback input terminal.  
When the C917 + side reaches approx. 380V, the voltage is fed back via R931, R929, R955, R930 and R928.
- (4) The IC902 pin No. 3 is the multiplier input terminal.  
The full-wave rectified voltage waveform is input via R917, R918, R919, R920 and R921.  
Both voltages are multiplied in the IC902 to achieve the threshold voltage.
- (5) The IC902 pin No. 4 is the current sense input terminal. The current that flows through L903 is converted into a voltage at the R923 between the Q905 source FG, and is input into the IC902 pin No. 4.  
This voltage and the threshold voltage are compared internally to turn the Q905 gate ON and OFF.  
The threshold voltage is created with the full-wave rectified voltage, so the current that flows to L903 is as shown in Fig. 4.
- (6) The IC902 pin No. 5 detects the L903 zero current.  
Turning ON of the Q905 is started when the IC902 detects this zero current, and ends when the threshold voltage is reached.
- (7) The IC902 pin No. 8 is the Vcc terminal with low-voltage detection circuit. The voltage is supplied from the sub-power via Q910 (SW).  
As the output voltage rises when pin No. 1 is open, an overvoltage protector is provided on the external circuit.

The energy accumulated in the L903 during the Q905 ON interval is discharged to C917 via D904 by the pulses generated during the OFF interval.

This is smoothed at C917 and changed into a DC voltage.

By repeating the above operation, a DC power is obtained for the output, and even if the input side is a current pulse, there is maximum current of each cycle is above the sine, so by smoothing, a sine wave equivalent to the input voltage waveform is achieved finally.

# Circuit description





Figure 4. High harmonic wave circuit



----- Circuit description -----




Figure 5. High harmonic wave OVP circuit



### 2.2.4 Sub-power circuit

- (1) An automatic regulator MIP02223SY is used for the sub-power.
- (2) When the power switch is turned ON, the rectified and smooth DC voltage (AC voltage  $\times \sqrt{2}$ ) is supplied to pin No. 3 of IC904. This passes through pin No. 1 and charges C926. When pin No. 1 reaches 5.7V, the current supply from pin No. 3 is cut off, and the oscillation in the IC904 starts. The output FET operation starts. (As the Q910 is OFF, IC902 and IC903 do not operate.)
- (3) With this, the voltage is induced to T902 pin No. 2 and the secondary side. These outputs are each rectified, and are used as the primary side control power and as the power for the MPU, USB and heater.
- (4) The voltage induced to the secondary side is fed back from the constant voltage circuit using an IC922 (shunt regulator) to the primary side via IC914 (photo coupler). This circuit supplies and controls the primary control power to the IC904 pin No. 1 via R952, and suppresses the voltage fluctuation on the secondary side.
- (5) When the secondary voltage starts, the MPU operation starts, and the P-SUS signal line is set to HIGH.
- (6) This information is conveyed to the primary side via IC911 to turn Q910 ON. When Q910 turns ON, the primary side control power is supplied to IC902 and IC903, and the higher harmonic circuit operates. The main power circuit operation then starts. This is approx. 200ms after the sub-power starts.

### 2.2.5 Main power circuit

- (1) The main power uses a pseudo-resonance operation fly-back converter type switching control ICMA5941.
- (2) In Fig. 6, when the sub-power starts and Q910 turns ON, Q908 turns OFF and IC903 starts operation. In other words, when potential is generated across the No. 5 and No. 3 pins and  $V_{TH} = 3V$  (TPY) is achieved, the drain current flows to the main switching terminal Q1, and the input voltage VDC is applied on the Np coil. With this, the voltage calculated with the following expression is generated at the NC1 coil, and the voltage is supplied to the gate terminal (pin No. 5) via R943 and C922.
- (3) Immediately after the power is turned ON, the constant voltage and dropping control are not sufficiently activated, so an excessive current could flow to the Q1 drain. As the Q1 drain current overcurrent protection, the R939 is connected across the source terminal (pin No. 3) and ground terminal (pin No. 4). When the voltage drops, Q4 turns On, the gate voltage VGS drops below  $V_{TH}$ , and Q1 turns OFF.
- (4) From the NC1 coil, voltage is supplied to the gate terminal and C2 is charged via D5. When the C2 potential reaches approx. 1V, Q2 turns ON and the gate voltage VGS drops below  $V_{TH}$ . Thus, Q1 turns OFF. In other words, the Q1 max. ON time is the value determined by the NC1 coil voltage  $V_{CNC1}$ , R900, R944, D5 and C2.
- (5) When Q1 turns OFF, the energy accumulated in the transformer T901 is output from the NS coil to the secondary side via D961. At the same time, the voltage generated in the reverse direction passes through D5, R900 and R944 to discharge C2, and charges the NC1 coil with a minus potential. When the discharge of the transformer energy ends, D961 turns OFF, but a voltage is generated in the NC1 due to the fly-back of the slight residual energy. This turns Q1 ON again, and continues the switching operation.
- (6) Constant voltage control  
IC921 is connected to the 180V power line, and is fed back to the IC903 F/B terminal (pin No. 6) via IC912 (photo coupler).

----- Circuit description -----




Figure 6. Main power circuit

## Circuit description

### 2.2.6 Degaussing circuit

- (1) An automatic and manual degaussing circuit are provided.

These circuits are used to prevent the picture performance from dropping when the CRT is magnetized, and operate as follow.

- (2) Q964 is conducted and RY901 operates with the DG signal output from the MPU when the power is turned ON.

With this, a current flows to the degaussing coil, and degaussing is carried out. This degaussing takes approx. 5 sec. Manual degaussing is possible by selecting the degaussing menu from the OSD picture.

### 2.2.7 Power management circuit

When power management is turned ON on the OSD menu picture, the energy conservation mode will be enabled as shown in Table 2 according to the presence of a horizontal/vertical synchronization signal.

Mode	H-SYNC	V-SYNC	VIDEO
Normal	Present	Present	Active
Standby	Not present	Present	Blank
Temporary stop	Present	Not present	Blank
Complete stop	Not present	Not present	Blank

Table 2

The energy consumption at this time is as shown in Table 3.

Mode	Power consumption	Recovery time	Power LED
Normal	155W	—	Green
Standby	15W or less	Approx. 3 sec.	Amber
Temporary stop	15W or less	Approx. 3 sec.	Amber
Complete stop	3W or less	Approx. 12 sec.	Amber

Table 3

### 2.2.8 Protection circuit

- (1) Overcurrent protection circuit

The IC903 has an overcurrent protection circuit determined by VNC1, R900, R944, D5 and C2. This activates when the +180V or +80V line is short-circuited.

- (2) Overvoltage protection circuit (secondary side)

The +80V line voltage is monitored so that the CRT is not fatally damaged. If the +80V line voltage rises for any cause, TH901 (thyristor) turns ON via D970, and the P-SUS line is set to LOW.

This information passes through the IC911 (photo coupler) and is conveyed to the primary side. Q910 is turned OFF, and the main power operation is stopped.

As this is a thyristor operation, the state is held until the power is turned OFF and ON again.




Figure 7. Secondary-side overvoltage protection circuit

# Circuit description




Figure 8. IC904 (MIP0223Y) circuit

## **2.3 Deflection circuit block**

### **2.3.1 Outline**

The deflection block is configured of the horizontal oscillation circuit, vertical oscillation circuit, and blanking circuit, and of the horizontal output circuit, +B control circuit, CS/LIN circuit, H-POS1 circuit and vertical output circuit.

### **2.3.2 Horizontal oscillation circuit, vertical oscillation circuit and blanking circuit**

#### **(1) Horizontal oscillation circuit**

The horizontal oscillation circuit is configured centering on the IC7A1 on the PWB-DEFL-SUB.

The H-SYNC/G-SYNC signal input from the synchronization separation circuit to the IC100 (MPU) is output from the IC100 as the H\_S-OUT signal. It is then, reversed and rectified at the IC110 (inverter), and input as the H\_S signal into the IC7A1 pin No. 1.

IC7A1 oscillates in synchronization with this H-S signal. With the phase control and duty control from the 12C BUS with the MPU, a stabilized horizontal drive output HD2 signal is output from pin No. 26 with the AFC signal fed back from the horizontal output circuit to pin No. 12.

#### **(2) Vertical oscillation circuit**

The vertical oscillation circuit is also configured centering on the IC7A1.

IC7A1 oscillates in synchronization with the V-S signal input into pin No. 2, and outputs the VST1 signal and Imid signal from pin Nos. 23 and 21.

#### **(3) Blanking circuit**

The blanking circuit is configured of the IC702 (inverter) peripheral circuit on the PWB-DY-SUB.

The AFC signal from the horizontal output circuit is rectified by Q707, Q708 and IC702, and is added at Q705 and Q706 with the V-BLK signal rectified at IC702. Then it is output as the HV-BLK signal rectified again at the IC702 to the image signal amplifying circuit.

### 2.3.3 Horizontal output circuit

The horizontal output circuit is configured mainly of Q501, T501, Q502 and T503, etc., in the PWB-MAIN as shown in Fig. 9.

The HD signal (= HD2 signal) output from the horizontal oscillation circuit described above, passes through Q501 and T501, and drives and switches the horizontal output transistor Q502 base.

When Q502 turns ON, the deflection current  $I_{dy}$  that flows to the horizontal deflection yoke increases from 0 to max.  $I_{dy}$  following the next expression:

$$I_{dy} = (V_{cc}/L_{dy}) \times T_{on}$$

( $V_{cc}$ : Power voltage,  $L_{dy}$ : parallel inductance of horizontal output transformer T503 and horizontal deflection yoke,  $T_{on}$ : Q502 ON interval).

When Q502 turns OFF, the deflection current  $I_{dy}$  flows to charge C506 and C526 with the energy accumulated in the horizontal deflection yoke. However, when the C506 and C526 voltage (hereinafter  $V_{cp}$ ) reaches  $\{1 + (\pi/2) \times (T_s/T_r)\} \times V_{cc}$ , the deflection current  $I_{dy}$  becomes 0. The charge accumulated in C506 and C526 is discharged, and flows to the horizontal deflection yoke as the negative deflection current.

This charge/discharge time is called the retrace interval or retrace time, and is expressed with the following expression.

$$T_r = \pi \sqrt{L_{dy} \times C_r} \quad (C_r : \text{Parallel capacity of C506, C526})$$

When  $V_{cp}$  reaches approx. 0, the negative deflection current reaches the peak.

This charging/discharge interval is the resonance interval by  $L_{dy}$  and  $C_r$ . When  $V_{cp}$  oscillates into the negative direction due to the resonance phenomenon, a forward bias is applied on the damper diodes D506, D503 and D505. The deflection current  $I_{dy}$  flows between the horizontal deflection yoke and damper diode loop, and nears 0.

By repeating the above steps, a sawtooth current is passed to the horizontal deflection yoke, and horizontal scanning is carried out.

### 2.3.4 +B control circuit

The horizontal picture width is controlled by varying the +B power voltage applied on the horizontal output circuit.

The +B control circuit is a DC-DC converter configured of the IC5J1, IC5J2, Q541 and T502, etc. By comparing the voltage data converted from the horizontal deflection current fed back from the T502 and the H-SIZE-CON signal from the MPU, the IC5J2 carries out PWM control of the Q541, and a stable +B power is supplied.

By superimposing the PCC signal on the H-SIZE-CON signal at IC5J2 and modulating the +B power, the distortion at the left and right sides of the picture is compensated.

## Circuit description

### 2.3.5 CS/LIN circuit

The horizontal linearity is compensated by selecting the S-character compensation capacitor (C552, C531, C518, C513, C514, C515, C516, C517, C550) with the FET switch (Q504, Q505, Q516, Q515, Q514, Q513, Q512), and by selecting the horizontal linearity coil L502 with relay RY501.

Refer to the following table for the selection of the S-character compensation capacitor and horizontal linearity coil.

Horizontal frequency (kHz)	C517 C550	C516	C515	C514	C513	C518	C531 C552	RY501
	Q512	Q513	Q514	Q515	Q516	Q504	Q505	
30.0~33.0	ON	ON	ON	ON	ON	ON	ON	
33.0~36.5	ON		ON		ON			
36.5~40.0	ON				ON	ON	ON	
40.0~45.0		ON	ON	ON				ON
45.0~47.5		ON		ON	ON	ON	ON	ON
47.5~52.0		ON			ON	ON		ON
52.0~55.0			ON	ON	ON	ON		ON
55.0~59.0			ON	ON		ON	ON	ON
59.0~62.0			ON	ON				ON
62.0~66.0			ON		ON		ON	ON
66.0~70.0				ON	ON	ON	ON	ON
70.0~73.5				ON	ON	ON		ON
73.5~77.0				ON	ON		ON	ON
77.0~81.0				ON	ON			ON
81.0~84.0				ON		ON		ON
84.0~88.0				ON				ON
88.0~92.5					ON	ON	ON	ON
92.5~97.0					ON	ON		ON
97.0~103.0					ON			ON
103.0~110.0						ON	ON	ON
110.0~118.0							ON	ON
118.0~121.0								ON

\* With the preset 8 AP21 (68.68kHz/75Hz), only C515, C518 and RY501 turn ON.

### 2.3.6 H-POSI circuit

The H-POSI circuit is configured of Q5A1, IC5A1 and L5A1, etc. The horizontal luster position is controlled by supplying the DC current from the IC5A1 pin No. 4 via the L5A1 to the horizontal deflection yoke.

### 2.3.7 Vertical output circuit

The vertical deflection circuit controls the vertical width and vertical position with IC7A1 on the DEFL-SUB PWB. The linearity is controlled with IC701 on the DY-SUB PWB. Each control signal is added and input into the vertical deflection output IC401 via connector J5P1.



Circuit description




Figure 9

### 2.4 High voltage circuit

(1) The horizontal deflection collector pulse is divided into approx. 1/20, and the pulse is input into the IC601 pin No. 4. When Q601 turns ON, energy is supplied to the high-voltage coil to generate a high voltage. To maintain the high voltage at a constant level regardless of the horizontal frequency or beam current amount, the high voltage is divided into approx. 1/5400 by the bleeder resistor in the T601. This is applied in the IC601 pin No. 6 and compared with the IC internal reference voltage.

The Q601 gate pulse width is varied by the IC601 pin No. 1 output so that these two voltages have the same potential.

In this manner, feedback control is carried out to keep the high voltage at a constant level.

The high voltage is set with VR601 (HV-ADJ). (27.0kV standard)

(2) The pulses detected from the T601 tertiary coil is rectified by D605 and C604. When the high voltage reaches 31.5kV or more, that voltage is changed to 14V and is applied in the IC602 pin No. 5. When the voltage exceeds the IC internal reference voltage, the HIGH voltage is output from the IC pin No. 9, and the high voltage control pulse output from the IC601 pin No. 1 is stopped to shut down the high voltage circuit. This state is not cancelled until the power switch is turned OFF.

(3) The beam current that flows to T601 is detected by R613 and input in the IC602 pin No. 6. It is then compared with the IC internal reference voltage. When the beam current exceeds approx. 1200 $\mu$ A, the HIGH voltage is output from the IC pin No. 7, and the high-voltage control pulses output from the IC601 pin No. 1 are stopped to shut down the high-voltage circuit. This state is not cancelled until the power switch is turned OFF.

#### 2.4.1 DBF circuit

The DBF circuit optimizes the focus at the center of the picture and at the periphery. There are two electrodes for the focus electrodes. A voltage having divided anode voltage is applied on both electrodes. The horizontal (approx. 360V) and vertical (approx. 140V) parabola waves are superimposed on the dynamic (F1) via the capacitor. The horizontal and vertical parabola waves are created at IC701, and then amplified at Q6E3, Q6E4, Q6E2, Q6E1 and T6E1. Then, these are added to the fly-back transformer T601.

### 2.5 Video block

#### 2.5.1 Image signal amplifying circuit

The video circuit has the same configuration for R, G and B. The G (Green) video circuit will be explained in this section.

The video signal is input in the input signal select IC200 pins No. 5 (BNC input) and No. 12 (D-SUB input). When the pin No. 15 is LOW, the pin No. 5 is selected, and when the HIGH, the No. 12 pin is selected. The signal is then output from pin No. 23. The output from the IC200 pin No. 23 is input into the IC301 pin No. 2.

With the IC301, the video signal and adjustment picture (OSD) video signal, clamp signal and blanking signal are combined and output from pin No. 35.

The output from the IC301 pin No. 35 is input in the main up IC302 pin No. 1 and amplified. The output from the IC302 pin No. 3 is AC-coupled at C315, and is then combined with the cutoff voltage (video output bias). After combining, it is supplied to the CRT cathode via the lead wire.

### 2.5.2 Synchronization separator circuit

The synchronization signal input from the D-SUB connector is input into the synchronization separator IC202 pin No. 3 (horizontal) and pin No. 13 (Vertical). The synchronization signal input from the BNC connector is input into the IC202 pin No. 2 (horizontal) and pin No. 14 (vertical). When the IC202 pin No. 1 is LOW, the BNC input is selected, and when HIGH, the D-SUB input is selected. The signal is then output from the IC202 pin No. 4 (horizontal) and pin No. 12 (vertical). The output from the IC202 pin No. 4 (horizontal) and pin No. 12 (vertical) is input into the IC203 pin No. 3 (horizontal) and pin No. 5 (vertical). The waveform is created and the signal is amplified, before being output from pin No. 4 (horizontal) and pin No. 6 (vertical). The Sync on Green signal is input with IC203 using the control signal from IC200.

### 2.5.3 On Screen Display circuit

The adjustment picture (OSD) control signal is input to the IC300 pin No. 5 (CLK), pin No. 6 (DATA), pin No. 18 (H-BLK), and pin No. 19 (V-BLK).

The signal output from pin No. 12 (BLKO), pin No. 13 (GOSD), pin No. 15 (ROSD) and pin No. 17 (BOSD) is combined with the video signal at IC301.

## 2.6 Control circuit

### 2.6.1 Outline

The control section is configured of the 16-bit single-chip MPU IC100, non-volatile memory IC101, deflection compensation control IC701, IC7A1, convergence compensation control IC802, convergence compensation coil drive IC804 and geomagnetism cancel control IC303, etc.

### 2.6.2 Rotation circuit

The rotation circuit compensates the inclination of the picture caused by geomagnetism. Adjustments are made by passing a DC current to the rotation coil wound on the front side of the DY. Control is carried out by IC100#4 (PWM\_DAC) to 0 to 5V (J103#1 to J802#1) using 2.5V as a reference. A +/- DC current is passed to the rotation coil from Q813 and Q814.

### 2.6.3 Corner purity circuit

The corner purity circuit compensates the color unevenness or color unmatching at the picture corner. Adjustments are made by passing a DC current to the corner purity coil installed on the four corners of the picture on the back side of the CRT.

This compensation circuit is established with the (1) User (automatic adjustment device) adjustment (OSD display), (2) time transition compensation and (3) high/low-temperature drift compensation functions.

#### (1) User (automatic adjustment device) adjustment (OSD display)

The user (automatic adjustment device) flows the +/- DC current to each corner purity coil following the OSD display value.

#### (2) Time transition compensation

Color unevenness and color unmatching at the screen corners, which thermal expansion/contraction of the aperture grill by electronic beam strike appears caused by time passage after the monitor powered ON/OFF, are automatically adjusted. The voltage that detects the power ON/OFF time passage is read by the IC100#15 (MPU\_ADC) from the CR charge (integral) circuit configured of C158 and R1A2, and the CR discharge (integral) circuit configured of C158 and R1D6. Then, a +/- DC current is passed to each corner purity coil following the specified control program.

### (3) High/low-temperature drift compensation

The picture corner color unevenness and color unmatching caused by the thermal expansion/contraction of the front panel (glass) due to changes in the monitor installation environment is automatically adjusted. The voltage that detects the monitor installation environment temperature changes is read in by IC100#13 (MPU-ADC) from the circuit configured of TH100 (thermistor) arranged near the front panel (glass). Then, a +/- DC current is passed to each corner purity coil following the specified control program.

- The upper left corner of the picture is controlled by IC806#1 (12C control\_DAC) to 0 to 5V using 2.5V as a reference. Then, a +/- DC current is passed to the upper left corner purity coil from IC812.
- The upper right corner of the picture is controlled by IC806#2 (12C control\_DAC) to 0 to 5V using 2.5V as a reference. Then, a +/- DC current is passed to the upper right corner purity coil from IC812.
- The lower left corner of the picture is controlled by IC806#3 (12C control\_DAC) to 0 to 5V using 2.5V as a reference. Then, a +/- DC current is passed to the lower left corner purity coil from IC811.
- The lower right corner of the picture is controlled by IC806#4 (12C control\_DAC) to 0 to 5V using 2.5V as a reference. Then, a +/- DC current is passed to the lower right corner purity coil from IC811.

### 2.6.4 Geomagnetism canceler circuit

The geomagnetism canceler circuit is divided into the meridional horizontal magnetic field cancel function and vertical magnetic field cancel function. The voltage and direction of the meridional horizontal magnetic field (IC305#5) and vertical magnetic field (IC303#6) are detected with the IC303 (geomagnetism sensor unit). That detected voltage is read by IC100#14 and #18 (MPU\_ADC) and the following cancel function is automatically controlled by the specified control program.

The IC303 (geomagnetism sensor unit) output voltage operates as follows.

- Meridional horizontal magnetic field (IC305#5): 0.5V (-0.04mT) to 2.5V ( $\pm 0.00$ mT) to 4.0V (+0.04mT)
- Vertical magnetic field (IC303#6): 3.3V (-0.04mT) to 2.5V ( $\pm 0.00$ mT) to 0.1V (+0.10mT)

#### 2.6.4.1 Meridional horizontal magnetic field cancel function

##### 2.6.4.1.1 Horizontal magnetic field landing cancel

The horizontal magnetic field landing cancel circuit compensates the color unevenness and color unmatching that occurs in the horizontal direction, which is the reverse direction at the upper edge and bottom edge of the monitor display picture. Automatic adjustments are made by passing a DC current to the purity coil wound around the display picture. The current is controlled to 0 to 5 (J103#2 to J802#2) by IC100#2 (PWM\_DAC), using 2.5V as reference, and a +/- DC current is passed to the purity coil from IC805.

##### 2.6.4.1.2 Horizontal magnetic field convergence cancel

The horizontal magnetic field convergence cancel circuit compensates the mis-convergence that occurs when the RED and BLUE vertical direction convergence deteriorates over the full picture of the monitor. Automatic adjustments are made by passing a DC current to the 4V convergence compensation coil mounted on DY. The current is controlled to 0 to 5V (J103#8 to J802#8) by IC100#6 (PWM\_DAC), using 2.5V as a reference, and a +/- DC current is passed to the 4V convergence compensation coil from IC804#5 and #6 (PowerOamp).

#### **2.6.4.2 Vertical magnetic field cancel function**

##### **2.6.4.2.1 Vertical magnetic field landing cancel**

The vertical magnetic field landing cancel circuit compensates the color unevenness and color unmatching that occurs in the horizontal direction, which is the maximum at the center of the horizontal shaft direction and the minimum at the upper and lower edges of the monitor display picture. Automatic adjustments are made by passing current on the speed modulating coil mounted on the CRT neck section. The current is controlled to 0 to 5V (J103#3 to J803#3) by IC100#5 (PWM-DAC), using 2.5V as a reference, and a +/- DC current is passed to the speed modulating coil from IC813.


##### **2.6.4.2.2 Vertical magnetic field convergence cancel**

The vertical magnetic field convergence cancel circuit compensates the mis-convergence that occurs when the RED and BLUE vertical direction convergence, which has the reverse direction at the upper and lower edges of the monitor display picture, deteriorates. Automatic adjustments are made by passing a DC current to the 4V convergence compensation coil mounted on DY. A +/- sawtooth waveform (vertical cycle) current is passed to the 4V convergence compensation coil from the IC804#5, 6 (PowerOpAmp) controlled with a  $\pm 1.0V_{p-p}$  sawtooth waveform (vertical cycle) by the IC802#31 (STV9107M), using 1.0V as a reference.

##### **2.6.4.2.3 Vertical magnetic field horizontal picture position cancel**

The vertical magnetic field horizontal picture position cancel circuit compensates the fluctuations of the horizontal picture position. Automatic adjustments are made by controlling the horizontal picture position adjustment signal H\_POSI (IC700#7/PWM\_DAC).

----- Circuit description -----



----- Circuit description -----

I2C bus line connection IC list


Signal name : SDA\_I2C, SCL\_I2C

IC sources	IC models	Slave Address	PWB	Remarks
IC300	M35071	7C/7D	VIDEO	
IC301	M52742SP	88/89	VIDEO	
IC701	STV9107	8C/8D	DY-SUB	
IC802	STV9107M	8E/8F	DY-SUB	
IC101	M24C32WMN6T	A0/A1	CONTROL	Variable
IC104	M62320FP	70/71	CONTROL	Variable
(IC105)	DS75	90/91	CONTROL	Variable

Signal name : SDA\_AFC, SCL\_AFC

IC sources	IC models	Slave Address	PWB	Remarks
IC7A1	TDA9110	8C/8D	DEFL-SUB	
IC806	M62334P	98/99	DEFL-SUB	

# Circuit description





## Circuit description

### B Chassis MPU pin assignment

PIN No.	FUNCTION	TYPE	ASSIGNMENT	IN/OUT	Active	Remarks
1	DA0	O	SUB BRIGHT	OUT	high	(D/A)
2	DA1	O	HCANCEL	OUT	high	(D/A)
3	DA2	O	(NOT USE)	-	-	
4	DA3	O	ROTATION	OUT	high	(D/A)
5	DA4	O	VCANCEL	OUT	high	(D/A)
6	DA5	O	H-STATIC	OUT	high	(D/A)
7	DA6	O	H-POSI	OUT	high	(D/A)
8	DA7	O	H-SIZE	OUT	high	(D/A)
9	DA8	O	(NOT USE)	-	-	
10	VSSA	S	GND(A)	-	-	Analog GND
11	VDDA	S	+5V	-	-	Analog Power supply
12	PB7	I/O	FRONT BUTTON	IN	high	(A/D)
13	PB6	I/O	THERM	IN	high	(A/D)
14	PB5	I/O	XOUT	IN	high	(A/D)
15	PB4	I/O	TIME	IN	high	(A/D)
16	PB3	I/O	ACC	IN	high	(A/D)
17	PB2	I/O	H-DET	IN	high	(A/D)
18	PB1	I/O	YOUT	IN	high	(A/D)
19	PB0/VFBACK	I/O	USB UPB VCC	IN	high	
20	VSYNCl1	I	VSYNCl	IN	-	
21	PD7/VSYNCl2/ITD	I/O	USB UPA VCC	IN	high	
22	PD6/CLAMPO	I/O	P-OFF	OUT	low	
23	PD5/ITA	I/O	CHSYNCl	IN	high	
24	PD4/ITB	I/O	HLOCKOUT	IN	low	
25	PD3/ITC	I/O	P-SUS	OUT	low	
26	PD2/VSYNCO	I/O	VSYNCl-OUT	OUT	low	
27	PD1/HSYNCO	I/O	HSYNCl-OUT	OUT	low	
28	PD0/CSYNCl	I/O	CSYNCl	IN	-	
29	VSS	S	GND(D)	-	-	Digital GND
30	HSYNCl1	I	HSYNCl	IN	-	
31	VDD	S	+5V(D)	-	-	Power supply
32	PC0/OCMP/HFBACK	I/O	DEGAUSS	OUT	high	
33	PC1/HSYNCl2	I/O	CONNECTOR	OUT	-	
34	PC2/SCLD(DDC)/RX	I/O	SCL DDC	IN	high	(DDC)
35	PC3/SDAD(DDC)	I/O	SDA DDC	BI	high	(DDC)
36	PC4/SCLl(I2C)	I/O	SCL 12C	OUT	high	(12C)
37	PC5/SDAl(I2C)	I/O	SDA 12C	BI	high	(12C)
38	PC6/RDI(SCI)	I/O	RDI	IN	high	
39	PC7/TDO(SCI)	I/O	TDO	IN	high	
40	USBGND	S	USBGND	-	-	
41	USBDM	I/O	USBDM	BI	-	
42	USBDP	I/O	USBDP	BI	-	
43	USBVCC	S	USBVCC	-	-	
44	OSCOU	O	CRYSTAL	OUT	high	
45	OSCIN	I	CRYSTAL	IN	high	
46	PA7/BLANKO	I/O	HUBSUS	IN	-	
47	PA6	I/O	UPSEL	OUT	-	
48	PA5	I/O	SDAl AFC	IN	high	
49	PA4	I/O	SDAO AFC	OUT	high	
50	PA3	I/O	SCL AFC	OUT	high	
51	PA2	I/O	S/GSEL	OUT	-	
52	PA1	I/O	LED	OUT	low	
53	PA0	I/O	RESET USB	OUT	low	
54	NOT(NRESET)	I/O	RESET	OUT	low	
55	IRIN	I/O	GND	-	-	
56	VPP/TEST	S	GND	-	-	

### 2.6.5 DDCC circuit

The Digital Dynamic Convergence Clear (hereinafter DDCC) circuit compensates the convergence by passing a compensation current to the sub-yoke installed on the back of the deflection yoke.

The compensation current waveform is generated and amplified simultaneously.

The principle of the convergence compensation with the sub-yoke is the same as the CP ring. However, the CP ring is a static change that moves in parallel over the full picture with an even magnetic field generated with a permanent magnet though, and the sub-yoke is a dynamic change that compensates a random position on the picture by controlling the current waveform that flows to the electromagnet's coil. (Refer to fig.11)


#### (1) Generation of compensation current waveform

There is a total of 17 compensation elements. Each type is programmed in IC701 and IC802 using functions. By inputting a compensation coefficient in the function, the amplitude of the current is controlled.

$$Y_{ht} = b_{11} \cdot y^2$$

$$Y_{hj} = b_{12} \cdot y$$

$$Y_H = b_{11} \cdot y^2 + b_{12} \cdot y$$



Examples of the function, current waveform and compensation operation for  $Y_H$  are shown below.

In the above expression,  $b_{11}$  and  $b_{12}$  are the compensation coefficient, and  $y$  is the vertical cycle.

The sections other than the compensation coefficients are programmed into the IC, and when a coefficient is given, a random amplitude (compensation value) is obtained.

$Y_{ht}$  compensates the DY characteristic elements and  $Y_{hj}$  compensates the axial deviation element. Thus,  $Y_H$  is a combination of  $Y_{ht}$  and  $Y_{hj}$ , and is output from one IC port.

#### (2) Waveform and movement on picture

When looking at the flow of each current to the sub-yoke 4H coil, for the  $Y_{ht}$  (parabola wave) (refer to Fig. 11), the current is large at the start and end of the vertical cycle in the same direction and is 0 at the center. The magnetic field is generated in proportion to this, so the Red and Blue change only at the top and bottom of the picture. For  $Y_{hj}$  (sawtooth wave), the direction that the current flows is in reverse at the start and end of the vertical cycle, so the direction that Red and Blue changes differs at the top and bottom of the picture. When the current is passed with the horizontal cycle in the same manner, the left and right of the picture can be compensated, and when the current is passed to the 4V coil, the vertical direction can be compensated.

## Circuit description

### (3) Adjustment methods

The prerequisite for this method is that the center of the picture (H-STA, V-STA) and each phase are correctly adjusted.

H-STA and V-STA superimpose the direct current on the sub-yoke, but adjustments are carried out with the CP ring to reduce the stress of output IC. The phases are adjusted with the DBF phase.

As the B chassis only has the 4H and 4V coils, the convergence between Red, Blue and Green (6H, 6V) must be within the specified values for the CRT performance.

To adjust, the value of each 17 elements is not set to 0. Instead, each element is adjusted orderly in a balanced method, and neared to 0 to complete the adjustment. For example, with the Yht element, if the value before compensation is 0.4mm on the top and 0.2mm on the bottom, the element is compensated by the value obtained by adding these values and dividing them by 2 (0.3mm). The result is 0.1mm on the top and -0.1mm on the bottom. The next Yhj element is compensated in this state. When compensated with the values added and divided by two in the same manner, the result will be 0mm.

The correspond of each name in the DDCC adjustment mode, and each coefficient (38 items) of the 17 elements in Fig. 12 are shown below.

Names of coefficients and adjustment modes.

<Factory mode>												
4H Coil	b11	YH-T	b12	YH-J	b21	XH-T	b22	XH-J	b32T	PQHT	b32B	PQHB
	b31L	PQHL	b31R	PQHR	b41L	PQ1L	b41R	PQ1R	b52T	B3HT	b52B	B3HB
	b51L	B3HL	b51R	B3HR								
4V Coil	c11	YV-T	c12	YV-J	c21	XV-T	c22	XV-J	c32T	PQVT	c32B	PQVB
	c31L	PQVL	c31R	PQVR	c51L	S1VL	c51R	S1VR	c42T	S3VT	c42B	S3VB
	c41L	S3VL	c41R	S3VR	c62T	S3VL	c62B	S3VR	c61L	S2VT	c61R	S2VB

<Normal mode>			
b22L	H-CONVERGENCE-L	c12T	V-CONVERGENCE-T
b22R	H-CONVERGENCE-R	c12B	V-CONVERGENCE-B

### (4) Block diagram

The DDCC circuit block diagram is shown in Fig. 12.

The four elements for 4H are output from IC701, and the five elements for 4V are output from IC802. The elements for 4H and 4V are added at IC801, and the current is passed to the coil via IC803.

DC for V-STA is output from IC701 and from the MPU for H-STA, and is superimposed on IC803.

For 4-pole magnetic field









<p>Static changes by permanent magnetic field (Parallel movement over entire surface)</p>		
		
<p>Dynamic changes by electromagnetic (Compensate at random position on screen)</p>	<p>4H coil</p> 	 <p>For YH compensation</p>
	<p>4V coil</p> 	 <p>For PQv compensation</p>

Figure 11

# Circuit description




Figure 12. DDCC circuit block diagram

## Circuit description

### 2.6.6 Deflection compensation


#### 2.6.6.1 PCC

The PCC includes CENTER-PCC, TOP-PCC, BOTTOM-PCC, PCC-PHASE, CORNER-PCC-BALANCE, and CENTER-PCC-BALANCE. These signals send data via the I2C bus to the deflection control IC701 (STV9107) from the MPU IC100.


At the IC701, the signals are incorporated into the internal calculation expression based on the received data, and are input from pin No. 32 to the +B control IC5J2 (BA9757) on the main PWB.

#### 2.6.6.2 PIN-KEY

The PIN-KEY includes PIN-BALNACE and KEY-BALANCE. These signals send data via the I2C bus to the deflection control IC701 (STV9107) from the MPU IC100. At the IC701, the signals are incorporated into the internal calculation expression based on the received data, and are output from pin No. 25. The signals are then input to pin No. 10 of the other deflection control IC7A1 (TDA9110) on the DEFL-SUB PWB via J7A2. At IC7A1, the input PIN-KEY signal is incorporated in the H-DRIVE signal and output from pin No. 26.





# Circuit description



IC7A1 TDA9110

# Circuit description



IC5J2 BA9757



## 2.7 Control software

### 2.7.1 Outline

The outline of the MPU (IC100) process is as follows.

(1) Input SYNC judgment

The frequency counter and polarity of Sync input from the PWB-I/F is judged, and whether the picture adjustment value is the registered timing is judged.

(2) Picture adjustment function

The adjustment value stored in the EEPROM (IC101) is read based on the input Sync frequency, and the picture size/position/distortion and brightness/color coordination, etc., are set.

(3) POWER SAVE function

The suspend mode or complete off mode are entered according to the input Sync and POWER SAVE ON/OFF function.

(4) Input connector select

The BNC/DSUB connector is selected. If the input Sync is not available for either H or V, the other connector is automatically checked, and operation takes place with the connector side for which the input is confirmed.

(5) External communication (DDC)

The DDC1/2B/2Bi functions are provided.

### 2.7.2 Input SYNC judgment

(1) Operation frequency range

- Horizontal frequency: 30kHz to 121kHz
- Vertical frequency: 50Hz to 160Hz

(2) Max. No. of memorized timings

- Preset timings: 22 timings
- User timings: 15 timings

(3) Judgment of memorized timing

The state of the input SYNC and the state of the SYNC saved in the EEPROM are compared. When the following conditions (a), (b) and (c) are all satisfied, it is judged as the memorized timing.

- (a) The input SYNC polarity is the same for both H and V
- (b) The difference of the horizontal frequency is within 0.5kHz
- (c) The difference of the vertical frequency is within 0.5Hz

Order of comparing directories:

The directories are compared in the order of PRESET0→PRESET1→... PRESET21→  
USER0→USER1→ ... USER14.

If the same timing is judged midway, the comparison step is stopped, and the corresponding adjustment value is read from the EEPROM.

(4) Order for saving user timing

When a new timing is input and the picture is adjusted, the input SYNC frequency, polarity and adjustment value at that time are saved in the EEPROM.

If 15 (max.) user timings are already saved, the oldest timing will be deleted, and the new timing information will be saved.

**2.7.3 Picture adjustment function**

The picture adjustment modes include the following:

User mode: Normal monitor adjustment mode.

Factory adjustment mode: Mode dedicated for factory adjustments. The factory dedicated adjustment items can be adjusted.

When the input timing is the preset timing, the adjustment value in this mode will be the adjustment value for reset and center click.

Refer to "Adjustment procedures: 3.8 Adjustment" for details on entering the factory adjustment mode and returning to the user mode.

A list of adjustment items is given on the following pages.

\*Center click: If the adjustment item per timing for preset timing or a common adjustment item is selected with the OSD, and the AJD state is entered by pressing the ENTER button, the adjustment value will return to the factory adjustment value when the + and - buttons are pressed simultaneously.

**2.7.4 POWER SAVE function**

When the OSD adjustment item "POWER SAVE" is "ON", the POWER SAVE mode will be entered when the H or VSYNC input stops.

The input SYNC and POWER SAVE mode correspond as follows.

HSYNC	VSYNC	Mode
X	○	Suspend mode
○	X	Suspend mode
X	X	Complete OFF mode

(1) Suspend mode

By setting P\_OFF (IC100#22) to HIGH and P\_SUS (IC100#25) to LOW, the power output other than +6.5V, +5V, P-OFF+5V, D3.3V and HEATER will stop.

If the SYNC input from the selected input connector is stopped only for H or V, the suspend mode will be entered.

In this mode, the input connector selection and POWER SAVE mode will be maintained until the H and V are both input into the selected input connector, or until both H and V SYNC are stopped.

(2) Complete OFF mode

By setting P\_SUS (IC100#25) to LOW and P\_OFF (IC100#22) to LOW, the power output other than +6.5V, +5V and D3.3V will stop.

The complete off mode will be entered when both the H and V SYNC input from the selected input connector is stopped.

In this mode, the connector on the opposite side is checked at a one-second interval, and if there is a SYNC input at that connector, the complete off mode will be cancelled.

## Circuit description

### (3) Transition to POWER SAVE mode

When the POWER SAVE mode is entered, the OSD and POWER LED will operate as follows.

(Common for suspend and complete off modes.)

(i) When the input SYNC stops, the following yellow background OSD will appear.

ATTENTION  
NO SIGNAL  
H : OFF (or ON)    V : OFF (or ON)  
PLEASE CHECK  
INPUT SIGNAL OR  
CONNECTION

(ii) After the above state continued for approx. five seconds, the following white background OSD will appear.

POWER SAVE

(iii) After the above state continued for approx. one second, the POWER SAVE mode will be entered. After entering the mode, the POWER LED will change to orange.

### 2.7.5 Input connector select

The B chassis has the two input systems BNC and DSUB, which can be used when selected. The select function operates as follows.

#### (1) When power is turned ON

The input connector having displayed the previous picture is selected.

#### (2) Select with BNC/DSUB button

When the BNC/DSUB button is pressed, the connector opposite the currently selected input connector will be selected.

#### (3) When SYNC is not input correctly

##### (a) When input SYNC is OUT OF RANGE

That input connector will be held, and the OUT OF RANGE OSD will appear.

##### (b) When only H or VSYNC is input

That input connector will be held, and the NO SIGNAL OSD will appear, or the POWER SAVE mode will be entered.

##### (c) When neither H nor VSYNC is input

Input connector will be switched to the other at one-second intervals. If there is a SYNC input, that input connector selection will be held. If there is no SYNC input even at the other input connector, the one-second interval switching will be continued. The NO SIGNAL OSD will appear, or the POWER SAVE mode will be entered.

# Circuit description

	User free	Data management		Reset			Center click
		Each timing	Common	All	Color	Screen	
CONTRAST	o		o	o			o
BRIGHT	o		o				o
COLO NO	o	o		o			
R-GAIN(COLOR 1, 2, 3)	o		o	o	o		o
G-GAIN(COLOR 1, 2, 3)	o		o	o	o		o
B-GAIN(COLOR 1, 2, 3)	o		o	o	o		o
COLOR TEMPERATURE 1, 2, 3	o		o	o	o		o
COLOR RESET 1, 2, 3	o		o	o	o		o
HORIZ-SIZE	o	o		o		o	o
HORIZ-PHASE	o	o		o		o	o
HORIZ-POSITION	o	o		o		o	o
V-SIZE	o	o		o		o	o
V-POSITION	o	o		o		o	o
PINCUSHION	o	o		o		o	o
KEYSTONE	o	o		o		o	o
PIN-CENTER	o	o		o		o	o
TOP-PIN	o	o		o		o	o
BOTTOM-PIN	o	o		o		o	o
PIN-BALANCE	o	o		o		o	o
KEY-BALANCE	o	o		o		o	o
CORNER-BALANCE	o	o		o		o	o
PCC-CENRER-BALANCE	o	o		o		o	o
V-LIN-BALANCE	o	o		o		o	o
V-LIN	o	o		o		o	o
ROTATION	o		o	o			o
ZOOM	o		o	o			o
GEOMETRY RESET	o	o	o	o	o	o	o
TEXT MODE	o	o		o			
BLACK LEVEL	o	o		o			
HORIZ-CONVERGENCE	o		o	o			o
VERT-CONVERGENCE	o		o	o			o
VERT-CONV-TOP	o		o	o			o
VERT-CONV-BOTTOM	o		o	o			o
HORIZ-CONV-RIGHT	o		o	o			o
HORIZ-CONV-LEFT	o		o	o			o
MOIRE CANCEL	o	o		o			
MOIRE CANCEL LEVEL	o	o		o			o
CORNER PURITY (TL)	o		o	o			o
CORNER PURITY (TR)	o		o	o			o
CORNER PURITY (BL)	o		o	o			o
CORNER PURITY (BR)	o		o	o			o
CLAMP PULSE POSITION	o	o		o			
DEGAUSS	o	o	o	o	o	o	o
POWER SAVE	o		o	o			
CONTROL LOCK	o		o	o			
OSD POSITION	o		o	o			
ALL RESET	o	o	o	o	o	o	o
GTF AUTO ADJUST	o	o	o	o	o	o	o
DIAGNOSIS	o	o	o	o	o	o	o
LANGUAGE	o	o		o			
USB UP-STREAM	o		o	o			
USB PORT COMBINATION	o		o	o			
DBF H AMP (X2-L)		o		o	o	o	o
DBF H AMP (X2-R)		o		o	o	o	o
DBF H AMP (X4-L)		o		o	o	o	o
DBF H AMP (X4-R)		o		o	o	o	o
DBF H PHASE		o		o	o	o	o
DBF V AMP (X2)		o		o	o	o	o
R BIAS (COLOR 1)			o	o	o	o	o
G BIAS (COLOR 1)			o	o	o	o	o
B BIAS (COLOR 1)			o	o	o	o	o
R BIAS (COLOR 2)			o	o	o	o	o
G BIAS (COLOR 2)			o	o	o	o	o
B BIAS (COLOR 2)			o	o	o	o	o
R BIAS (COLOR 3)			o	o	o	o	o
G BIAS (COLOR 3)			o	o	o	o	o
B BIAS (COLOR 3)			o	o	o	o	o
SUB-BRIGHT			o	o	o	o	o
ABL			o	o	o	o	o
H-PURITY			o	o	o	o	o
V-PURITY			o	o	o	o	o
YH-T			o	o	o	o	o
YH-J			o	o	o	o	o
XH-T			o	o	o	o	o
XH-J			o	o	o	o	o
PQHT			o	o	o	o	o
PQHB			o	o	o	o	o
PQHL			o	o	o	o	o
PQHR			o	o	o	o	o
PQ1L			o	o	o	o	o
PQ1R			o	o	o	o	o
B3HT			o	o	o	o	o
B3HB			o	o	o	o	o
B3HL			o	o	o	o	o
B3HR			o	o	o	o	o
YV-T			o	o	o	o	o
YV-J			o	o	o	o	o
XV-T			o	o	o	o	o
XV-J			o	o	o	o	o
PQVT			o	o	o	o	o
PQVB			o	o	o	o	o
PQVL			o	o	o	o	o
PQVR			o	o	o	o	o
S1VL			o	o	o	o	o
S1VR			o	o	o	o	o
S3VT			o	o	o	o	o
S3VB			o	o	o	o	o
S3VL			o	o	o	o	o
S3VR			o	o	o	o	o
S2VT			o	o	o	o	o
S2VB			o	o	o	o	o
S2VL			o	o	o	o	o
S2VR			o	o	o	o	o

**2.8 USB circuit**

**2.8.1 Outline**

The B chassis has a function to monitor and control with the 2 upstream/3 downstream USB SELF POWERED HUB and USB.

**<USB HUB controller (IC1A0)>**

This is mainly configured a regulator (IC1A1) for supplying the Vbus with overcurrent detection.

**(1) Data signal**

The data signal is connected from the root port connector (J1A4 or J1A5) to the controller (IC1A0) root port. The data signal is connected from the IC1A0 downstream ports 1, 2 and 5 to each downstream port connector (J1A2, J8A7). The controller waits for data communication between the upstream side and downstream side.

**(2) 2 upstream**

The B chassis has two root port connectors (ROOT A and ROOT B). The data signal from the ROOT A or B is connected from the analog switch (IC1A2) to the controller (IC1A0) root port.

If either ROOT A or B is connected, that root port will be connected to automatically.

If both ROOT A and B are connected, which port to be connected to can be selected with OSD settings.

**(3) Power supply to downstream**

The B chassis USB HUB is a SELF POWERED HUB. A +5V power is supplied from the regulator (IC1A1) to each downstream port.

An overcurrent detection function is provided, so if an overcurrent is detected at any of the downstream ports, the power supply to the downstream port will stop.

**(4) USB monitor control**

The controller (IC1A0) downstream 3 (IC1A0 #9, 10) is connected to the MPU (IC100) USB port (#42, 41), and monitoring and control by the USB can be carried out with this.

**2.8.2 USB 2 upstream**

The MPU (IC100) inputs the UPSEL signal (IC100#47) into the analog switch (IC1A2), and connects either the ROOT A or B data signal to the controller (IC1A0) root port.

UPSEL	Selected ROOT
LOW	ROOT B (J1A5)
HIGH	ROOT A (J1A4)

The Vbus (#1) of each root port connector is connected to the MPU (IC100), and when the voltage reaches HI, the MPU judges this as an upstream connection.

The MPU controls as follows according to the connections.

**(1) When both ROOT A and B are not connected.**

When both UPA (IC100#21) and UPB (IC100#19) are LOW, the UPSEL setting is held, and the OSD "USB UPSTREAM" display changes to "NO ROOT CONNECTION".

## Circuit description

(2) When either ROOT A or B is connected

When either UPA or UPB is HI, the MPU controls with the UPSEL signal so that the data signal of that root port is connected to the controller (IC1A0).

At this time, the OSD "USB UPSTREAM" display changes to blue only for the connected root.

(3) When both ROOT A and B are connected

When either UPA or UPB is HI, ROOT A or B is selected with the OSD setting. At this time, the OSD "USB UPSTREAM" display changes to blue only for the selected root, and to black for all other roots.

(a) When root is selected with +/- buttons at OSD "USB UPSTREAM"

The OSD designation (blue characters) root port is selected.

This selection status is saved in the EEPROM (IC101), and the selection of that route is held regardless of the BNC/DSUB connector selection state. The OSD "USB PORT COMBINATION" display changes to black characters.

(b) When the combination with the input connector is selected with the +/- buttons at OSD "USB PORT COMBINATION", the combination designated with the +/- button is displayed in blue.

The root corresponding to the input connector designated and displayed on the picture is selected with the combination of the OSD designation (blue characters).

### 2.8.3 USB downstream power supply

The power supply and overcurrent detection to the B chassis downstream is carried out with the 3 downstream together.

(1) Vbus power supply

When the controller (IC1A0) is recognized from the root port direction, the current output signal at the downstream is output from IC1A0 #33. When #1, 5 and 9 are set to HI, the power regulator (IC1A1) supplies a 5V power to each downstream port (J1A2 #1, 5, J8A7 #1).

(2) Overcurrent detection

The regulator (IC1A1) has an overcurrent detection function. When the current output of each port reaches 550mA (min.) or more, the current output from that port is automatically stopped, and the corresponding overcurrent detection flag terminal (IC1A1 #2, #6 or #10) is grounded.

The overcurrent detection flag terminal is an open collector output, which is pulled up to +5V at R1H7. LOW is input into the controller overcurrent detection input terminal (IC1A0 #26).

When the controller (IC1A0) detects this signal, it turns IC1A1 #1, 5, and 9 to LOW to disable the current output.

With this, the current output at all downstream ports is stopped.

The regulator (IC1A1) has a function to stop the overcurrent detection for a set time after current output starts to avoid malfunctioning of the overcurrent detection caused by the rush current. This time is controlled by the external capacitors (C1C1, C1D8, C1D4).

#### **2.8.4 USB monitor control**

The USB monitor control is carried out by the MPU (IC100) connected to the downstream port (DOWN3) of the USB HUB controller(IC1A0). A low-speed (1.5Mbps) compatible USB interface circuit is built into the MPU. When the monitor is connected to a PC, the various descriptors saved in the MPU memory are sent from the monitor to the PC. The monitor USB interface is recognized as an HID (Human Interface Device) Class compatible peripheral device, and the required drivers are automatically installed. To adjust the monitor, the monitor adjustment software (Diamond Control) is required. This can be downloaded from the Mitsubishi internet home page. For the HID class driver required for USB monitor control, the driver enclosed as a standard with Windows 98 can be used. The various descriptors of the B chassis are given below.

## Circuit description

### Descriptor of USB Monitor function

(1) REPORT_DESCRIPTOR		
0x05	0x80	USAGE_PAGE (Monitor) (#10)
0x09	0x01	USAGE (Monitor Control)
0xa1	0x01	COLLECTION (Application)
0x05	0x82	USAGE_PAGE (VESA Virtual Controls)
0x75	0x08	REPORT_SIZE (8)
0x85	0x04	REPORT_ID (4) (#20)
0x15	0x01	LOGICAL_MINIMUM (1)
0x25	0x7f	LOGICAL_MAXIMUM (127)
0x95	0x02	REPORT_COUNT (2)
0x09	0x20	USAGE (Horizontal Position) (h phase)
0x09	0x30	USAGE (Vertical Position)
0xb1	0x62	FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x20	USAGE (Horizontal Position) (h phase)
0x09	0x30	USAGE (Vertical Position)
0x81	0x62	INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x1d	REPORTED_ID (29) (#17)
0x15	0x01	LOGICAL_MINIMUM (1)
0x26	0xff	0x00 LOGICAL_MAXIMUM (255)
0x95	0x01	REPORT_COUNT (1)
0x09	0x18	USAGE (Video Gain Green)
0xb1	0x62	FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x18	USAGE (Video Gain Green)
0x81	0x62	INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x06	REPORTED_ID (6) (#21)
0x15	0x01	LOGICAL_MINIMUM (1)
0x26	0xff	0x00 LOGICAL_MAXIMUM (255)
0x95	0x02	REPORT_COUNT (2)
0x09	0x16	USAGE (Video Gain Red)
0x09	0x1a	USAGE (Video Gain Blue)
0xb1	0x62	FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x16	USAGE (Video Gain Red)
0x09	0x1a	USAGE (Video Gain Blue)
0x81	0x62	INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x12	REPORTED_ID (18) (#25)
0x15	0x01	LOGICAL_MINIMUM (1)
0x26	0xff	0x00 LOGICAL_MAXIMUM (255)
0x95	0x03	REPORT_COUNT (3)
0x09	0x6D	USAGE (Video Red Bias)
0x09	0x6F	USAGE (Video Blue Bias)
0x09	0x71	USAGE (Video Green Bias)
0xb1	0x62	FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x6D	USAGE (Video Red Bias)
0x09	0x6F	USAGE (Video Blue Bias)
0x09	0x71	USAGE (Video Green Bias)
0x81	0x62	INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x03	REPORTED_ID (3) (#17)
0x15	0x01	LOGICAL_MINIMUM (1)
0x26	0xff	0x00 LOGICAL_MAXIMUM (255)
0x95	0x01	REPORT_COUNT (1)
0x09	0x10	USAGE (Brightness)
0xb1	0x62	FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x10	USAGE (Brightness)
0x81	0x62	FEATURE (Data, Var, Abs, NPrf, Null)
0x85	0x05	REPORTED_ID (5) (#16)
0x15	0x01	LOGICAL_MINIMUM (1)
0x25	0x7f	LOGICAL_MAXIMUM (127)
0x95	0x01	REPORT_COUNT (1)
0x09	0x32	USAGE (V-SIZE)



## Circuit description

0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x32		USAGE (V-SIZE)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x07		REPORT_ID (7) (#16)
0x15	0x01		LOGICAL_MINIMUM (1)
0x25	0x03		LOGICAL_MAXIMUM (3)
0x95	0x01		REPORT_COUNT (1)
0x09	0x14		USAGE (Color No.)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x14		USAGE (Color No.)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x09		REPORTED_ID (9) (#17)
0x15	0x01		LOGICAL_MINIMUM (1)
0x26	0xff	0x00	LOGICAL_MAXIMUM (255)
0x95	0x01		REPORT_COUNT (1)
0x09	0x42		USAGE (PCC-PHASE)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x42		USAGE (PCC-PHASE)
0x81	0x42		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x0A		REPORTED_ID (10) (#16)
0x15	0x01		LOGICAL_MINIMUM (1)
0x25	0x3f		LOGICAL_MAXIMUM (63)
0x95	0x01		REPORT_COUNT (1)
0x09	0x40		USAGE (KEY-BALANCE)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x40		USAGE (KEY-BALANCE)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x0B		REPORTED_ID (11) (#16)
0x15	0x01		LOGICAL_MINIMUM (1)
0x25	0x7f		LOGICAL_MAXIMUM (127)
0x95	0x01		REPORT_COUNT (1)
0x09	0x24		USAGE (PCC-AMP)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x24		USAGE (PCC-AMP)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x0C		REPORTED_ID (12) (#16)
0x15	0x01		LOGICAL_MINIMUM (1)
0x25	0x3f		LOGICAL_MAXIMUM (63)
0x95	0x01		REPORT_COUNT (1)
0x09	0x26		USAGE (PIN-BALANCE)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x26		USAGE (PIN-BALANCE)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x0D		REPORTED_ID (13) (#17)
0x15	0x01		LOGICAL_MINIMUM (1)
0x26	0xff	0x00	LOGICAL_MAXIMUM (255)
0x95	0x01		REPORT_COUNT (1)
0x09	0x44		USAGE (ROTATION)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x44		USAGE (ROTATION)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x0E		REPORTED_ID (14) (#17)
0x15	0x01		LOGICAL_MINIMUM (1)
0x26	0xff	0x00	LOGICAL_MAXIMUM (255)
0x95	0x1		REPORT_COUNT (1)
0x09	0xE5		USAGE (CORNER-BALANCE)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0xE5		USAGE (CORNER-BALANCE)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x0F		REPORTED_ID (15) (#17)
0x15	0x01		LOGICAL_MINIMUM (1)

## Circuit description

0x26	0xff	0x00	LOGICAL_MAXIMUM (255)
0x95	0x01		REPORT_COUNT (1)
0x09	0xE6		USAGE (PCC-CENTER)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0xE6		USAGE (PCC-CENTER)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x10		REPORT_ID (16) (#21)
0x15	0x01		LOGICAL_MINIMUM (1)
0x26	0xFF	0x00	LOGICAL_MAXIMUM (255)
0x95	0x02		REPORT_COUNT (2)
0x09	0x46		USAGE (PCC-TOP-CORNER)
0x09	0x4a		USAGE (PCC-BOTTOM-CORNER)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x46		USAGE (PCC-TOP-CORNER)
0x09	0x4a		USAGE (PCC-BOTTOM-CORNER)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x11		REPORTED_ID (17) (#21)
0x15	0x32		LOGICAL_MINIMUM (50)
0x26	0xCD	0x00	LOGICAL_MAXIMUM (205)
0x95	0x02		REPORT_COUNT (2)
0x09	0x28		USAGE (H-STATIC)
0x09	0x38		USAGE (V-STATIC)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x28		USAGE (H-STATIC)
0x09	0x38		USAGE (V-STATIC)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	016		REPORTED_ID (22) (#28)
0x15	03a		LOGICAL_MINIMUM (1)
0x26	0c6	0x00	LOGICAL_MAXIMUM (126)
0x95	0x04		REPORT_COUNT (4)
0x09	0xE8		USAGE (C-PURITY (TL))
0x09	0xE9		USAGE (C-PURITY (TR))
0x09	0xEA		USAGE (C-PURITY (BL))
0x09	0xEB		USAGE (C-PURITY (BR))
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0xE8		USAGE (C-PURITY (TL))
0x09	0xE9		USAGE (C-PURITY (TR))
0x09	0xEA		USAGE (C-PURITY (BL))
0x09	0xEB		USAGE (C-PURITY (BR))
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x17		REPORTED_ID (23) (#21)
0x15	0x50		LOGICAL_MINIMUM (80)
0x26	0xAA	0x00	LOGICAL_MAXIMUM (170)
0x95	0x02		REPORT_COUNT (2)
0x09	0xF2		USAGE (V-CONV-TOP)
0x09	0xF3		USAGE (V-CONV-BOTTOM)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0xF2		USAGE (V-CONV-TOP)
0x09	0xF3		USAGE (V-CONV-BOTTOM)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x32		REPORTED_ID (50) (#21)
0x15	0x3C		LOGICAL_MINIMUM (60)
0x26	0xBE	0x00	LOGICAL_MAXIMUM (190)
0x95	0x02		REPORT_COUNT (2)
0x09	0xF0		USAGE (H-CONV-LEFT)
0x09	0xF1		USAGE (H-CONV-RIGHT)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0xF0		USAGE (H-CONV-LEFT)
0x09	0xF1		USAGE (H-CONV-RIGHT)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x1A		REPORTED_ID (26) (#17)
0x15	0x01		LOGICAL_MINIMUM (1)
0x26	0xff	0x00	LOGICAL_MAXIMUM (255)

## Circuit description

0x95	0x01		REPORT_COUNT (1)
0x09	0xE7		USAGE (PCC-CENTER-BALANCE)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0xE7		USAGE (PCC-CENTER-BALANCE)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x1B		REPORT_ID (27) (#17)
0x15	0x7f		LOGICAL_MINIMUM (127)
0x26	0xff	0x00	LOGICAL_MAXIMUM (255)
0x95	0x01		REPORT_COUNT (1)
0x09	0x12		USAGE (CONTRAST)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x12		USAGE (CONTRAST)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x1C		REPORT_ID (28) (#17)
0x15	0x01		LOGICAL_MINIMUM (1)
0x26	0x90	0x00	LOGICAL_MAXIMUM (144)
0x95	0x01		REPORT_COUNT (1)
0x09	0x22		USAGE (H-SIZE)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0x22		USAGE (H-SIZE)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x85	0x1F		REPORT_ID (31) (#29)
0x15	0x00		LOGICAL_MINIMUM (0)
0x26	0xFF	0x00	LOGICAL_MAXIMUM (255)
0x95	0x01		REPORT_COUNT (4)
0x09	0xAC		USAGE (fh hi byte)
0x09	0xAD		USAGE (fh lo byte)
0x09	0xAE		USAGE (fv hi byte)
0x09	0xAF		USAGE (fv lo byte)
0xb1	0x62		FEATURE (Data, Var, Abs, NPrf, Null)
0x09	0xAC		USAGE (fh hi byte)
0x09	0xAD		USAGE (fh lo byte)
0x09	0xAE		USAGE (fv hi byte)
0x09	0xAF		USAGE (fv lo byte)
0x81	0x62		INPUT (Data, Var, Abs, NPrf, Null)
0x05	0x82		USAGE (VESA Virtual Controls) (#24)
0x75	0x08		REPORT_ID (8)
0x15	0x00		LOGICAL_MINIMUM (0)
0x25	0x01		LOGICAL_MAXIMUM (1)
0x85	0x14		REPORT_ID (20)
0x95	0x01		REPORT_COUNT (3)
0x09	0x01		USAGE (Degauss)
0xb1	0x02		FEATURE (Data, Var, Abs)
0x09	0x08		USAGE (COLOR RESET)
0xb1	0x02		FEATURE (Data, Var, Abs)
0x09	0x06		USAGE (Geometry RESET)
0xb1	0x02		FEATURE (Data, Var, Abs)
0x05	0x82		USAGE PAGE (VESA Virtual Controls) (#24)
0x85	0x15		REPORT_ID (21)
0x09	0xB0		USAGE (SETTINGS)
0xa1	0x02		COLLECTION (Logical)
0x05	0x81		USAGE PAGE (Monitor Enumrated Value)
0x09	0x01		USAGE (ENUM 1) (Save current Settings)
0x09	0x02		USAGE (ENUM 2) (Restore Factory Settings)
0x75	0x08		REPORT_SIZE (8)
0x15	0x01		LOGICAL_MINIMUM (1)
0x25	0x02		LOGICAL_MAXIMUM (2)
0xb1	0x40		FEATURE (Data, Ary, Abs, Null)
0xc0			END_COLLECTION
0xc0			END_COLLECTION

(2) Device descriptor

```

0x12, // bLength
0x01, // bDescriptorType
0x00, // bcdUSB
0x01,
0x00, // bDeviceClass
0x00, // bDeviceSubClass
0x00, // bDeviceProtocol
0x08, // bMaxPacketSize0
0x52, // idVendor (0452h)Mistubishi Electronics (MELA)
0x04,
0x83, // idProduct 0071;TFA1105U-A
0x00,
0x00, // bcdDevice
0x01,
4, // Index of string descriptor
// describing manufacturer
0x2C, // Index of string descriptor
// describing product
0x3E, // Index of string descriptor
// describing the device's
// serial number
0x01 // bNumConfigurations
    
```

(3) String descriptor

```

0x04,
0x03,
0x09,
0x04, // LangID = 0x0409: U.S. English
// 4
0x2b, // Size of manufacturer string
0x03, // bDescriptorType = String descriptor
// Manufacturer: "MITSUBISHI ELECTRIC"
'M',0,'I',0,'T',0,'S',0,'U',0,'B',0,'I',0,'S',0,'H',0,'I',0,' ',0,'E',0,
'L',0,'E',0,'C',0,'T',0,'R',0,'I',0,'C',0,
// 44
0x12,
0x03, // Product name: "TFA1105U "
'N',0,'S',0,'B',0,'I',0,'I',0,'O',0,'7',0,'U',0,
// 62
0x16,
0x03, // Serial number
'1',0,'9',0,'9',0,'9',0,'1',0,'2',0,'3',0,'4',0,'F',0,'A',0
(The contents are different each manufacture.)
// 84
    
```

## Circuit description

### (4) Configuration descriptor

0x09	bLength: Configuration Descriptor size
0x02	bDescriptorType: Configuration
34	wTotalLength: 34 Bytes returned
0x00	
0x01	bNumInterfaces: 1 interface
0x01	bConfigurationValue: Configuration value
0x00	iConfiguration: Index of string descriptor describing the configuration
0x40	bmAttributes: Self powered
0x32	MaxPower 100 mA
0x09	bLength: Interface Descriptor size
0x04	bDescriptorType: Interface descriptor type
0x00	bInterfaceNumber: Number of Interface
0x00	bAlternateSetting: Alternate setting
0x01	bNumEndpoints: Two endpoints used
0x03	bInterfaceClass: HID
0x00	bInterfaceSubClass: No subclass
0x00	nInterfaceProtocol: None
0x00	iInterface: Index of string descriptor
0x09	bLength: HID Descriptor size
0x21	bDescriptorType: HID
0x00	bcdHID: HID Class Spec release number
0x01,	
0x00	bCountryCode: Hardware target country
0x01	bNumDescriptors: Number of HID class descriptors to follow
0x22	bDescriptorType
0xf3	wItemLength: Total length of Report descriptor
0x01	wItemLength: Total length of Report descriptor
0x07	bLength: Endpoint Descriptor size
0x05	bDescriptorType: Endpoint descriptor type
0x81	bEndpointAddress: Endpoint Address (IN)
0x03	bmAttributes: Interrupt endpoint
0x08	wMaxPacketSize: 8 Byte max
0x00,	
0x0A	bInterval: Polling Interval (10 ms)



## ----- Adjustment procedure -----

### 3. Adjustment procedure

#### 3.1 Scope

These are the specified adjustment and inspection methods for the NSB1107STTUW/  
NUB1107STTUW.

#### 3.2 Application

Model	Rating label	Destination	Remarks
1	NSB1107STTUW/NUB1107STTUW	For own domestic use	

The applicable models are as follow.

(Note) When degaussing this monitor with the hand demagnetizer, use the following procedure.

- (1) Turn the monitor power OFF, and degauss with the hand demagnetizer.
- (2) Degauss with the hand demagnetizer in the power management state.
- (3) Degauss with the hand demagnetizer during automatic demagnetization of monitor unit.

#### 3.3 Measuring Instruments

- (1) Signal generator A: Astro Design VG-812 or equivalent
- (2) Signal generator B: Astro Design VG-829 or equivalent
- (3) DC voltmeter: 150V 0.5 Class or digital voltmeter
- (4) High voltage meter: 0.5 Class that can measure 30KV
- (5) Luminance meter: Minolta color analyzer CA-100 or equivalent
- (6) AC voltmeter: 150V/300V 0.5 Class
- (7) Oscilloscope: Scope with band of 100MHz or more
- (8) Slidac: Slidac that can be varied to 260VAC or more
- (9) Double scale: For width and distortion measurement
- (10) Withstand voltage meter: Kikusui Model TOS8650 or equivalent
- (11) Grounding conductivity measuring instrument: CLARE U.K. product

## Adjustment procedure

### 3.4 Standard setting state

Unless particularly designated, adjust with the state given in this section.

#### 3.4.1 Power voltage

Model	Assembly	Aging	Adjustment	Remarks
All models	AC100V 60Hz	AC264V 60Hz	AC220V 60Hz	

#### 3.4.2 Adjustment magnetic field

Model	Adjustment magnetic field	Remarks
All models	HORIZ. 0mT VERT. 0.04mT	Northern hemisphere
	HORIZ. 0mT VERT. 0.mT	Equator
	HORIZ. 0mT VERT. -0.04mT	Southern hemisphere

#### 3.4.3 Signal cable

Unless particularly designated, use a D-SUB 15-PIN signal cable.

### 3.5 Preparatory inspections

- (1) The assembly must be correctly assembled.
- (2) There must be no cracks or remarkable contamination on the PWB.
- (3) There must be no remarkable lifting or inclination of the parts on the PWB, and the parts must not be touching.
- (4) The connectors must be securely inserted without crimping faults.
- (5) The CRT socket, anode cap and focus lead must be securely mounted.
- (6) The lead wires must not be pressed against the edges of the board.
- (7) The lead wires must not touch the high temperature parts such as the R-METAL, R-CEMENT or TR with FIN.
- (8) The board must not be bent, remarkably contaminated or scratched.
- (9) The CRT has no scratch or chipping.
- (10) Each potentiometer must turn smoothly.
- (11) Always set each potentiometer to the following positions before turning the power ON.

Potentiometer default settings

PWB name	IC sources	Name (symbol)	Default adjustment position	Remarks
PWB-MAIN	VR601	HV-ADJ	Turn completely to left	
		FOCUS1	Center	FBT
		FOCUS2	Center	FBT
		SCREEN	Turn completely to left	FBT



## Adjustment procedure

### 3.6 Initializing the adjustment data in the EEPROM

- (1) Turn the monitor power ON to confirm that the aging raster appears.
- (2) Initialize the EEPROM with serial communication. Use the designated file shown below, and initialize the adjustment data in the EEPROM. Refer to section 3.7.3 OSD display (factory mode) for details on the default values.
- (3) Turn the monitor power OFF.

Adjustment data initialization file name

Model	Rating label	Date of revision	Remarks
1	BS_OWN_**.DAT (NSB1107STTUW) B_OWN_**.DAT (NUB1107STTUW)		

The initial data regarding the horizontal linearity is as shown below.

Frequency	LIN	CS7	CS6	CS5	CS4	CS3	CS2	CS1
30.0 -- 33.0	L	L	L	L	L	L	L	L
33.0 -- 36.5	L			L		L		L
36.5 -- 40.0	L	L	L	L				L
40.0 -- 45.0					L	L	L	
45.0 -- 47.5		L	L	L	L		L	
47.5 -- 52.0			L	L			L	
52.0 -- 55.0			L	L	L	L		
55.0 -- 59.0		L	L		L	L		
59.0 -- 62.0					L	L		
62.0 -- 66.0		L		L		L		
66.0 -- 70.0		L	L	L	L			
70.0 -- 73.5			L	L	L			
73.5 -- 77.0		L		L	L			
77.0 -- 81.0				L	L			
81.0 -- 84.0			L		L			
84.0 -- 88.0					L			
88.0 -- 92.5		L	L	L				
92.5 -- 97.0			L	L				
97.0 -- 103.0				L				
103.0 -- 110.0		L	L					
110.0 -- 118.0		L						
118.0 -- 121.0								
--								
--								
--								
--								
--								
--								
--								
--								

The above is I/O expander IC104 output and blank sections above are H.

- ※1 For preset 8 AP21 (68.68kHz/75Hz), CS6 and CS3 are L.
- ※2 When CS or LIN-COIL is ON, the corresponding bit is "L".  
When OFF, the corresponding bit is "H".


# Adjustment procedure

## 3.7 Names of each monitor part

### 3.7.1 Configuration of front control panel

<NSB1107STTUW>

- a: POWER SWITCH
- b: POWER LAMP
- c: BNC/D-SUB: CONNECTOR SELECT/OSD
- d: ADJUST ITEM SELECT BUTTON
- e: ADJUST BUTTON



<NUB1107STTUW>

- a: POWER SWITCH
- b: POWER LAMP
- c: CONNECTOR SELECT BUTTON
- d: MAIN MANU SELECT BUTTON
- e: ENTER BUTTON
- f: SUB-MENU SELECT/ADJUST BUTTON
- g: USB DOWNSTREAM




Fig. 1 Front control panel

----- Adjustment procedure -----

3.7.2 Configuration of rear input connector




Fig. 2 Rear input connector (standard)

## Adjustment procedure

### 3.7.3 OSD display matrix

#### 3.7.3.1 User mode

<NSB1107STTUW>

Adjustment items	Setting contents	Default setting	Setting classification	
			By timings	Common
OSD group 1				
CONTRAST	0~100%	100%		○
BRIGHT	0~100%	CENTER		○
COLOR NO.	1,2,3	COLOR NO.1	○	
R-GAIN 1,2,3	0~100%			○
G-GAIN 1,2,3	0~100%			○
B-GAIN 1,2,3	0~100%			○
COLOR TEMPERATURE 1,2,3	5000K~9300K	9300K		○
COLOR RESET 1,2,3	PROCEED			
OSD group 2				
HORIZ-SIZE	0~100%		○	
HORIZ-PHASE	0~100%		○	
HORIZ-POSITION	0~100%		○	
VERT-SIZE	0~100%		○	
VERT-POSITION	0~100%		○	
PINCUSHION	0~100%		○	
KEYSTONE	0~100%		○	
TOP-PIN	0~100%		○	
BOTTOM-PIN	0~100%		○	
PIN-BALANCE	0~100%		○	
KEY-BALANCE	0~100%		○	
ROTATION	0~100%	CENTER		○
ZOOM	0~100%		○	
GEOMETRY-RESET	PROCEED			
OSD group 3				
TEXTMODE	SHARP / SMOOTH	SHARP	○	
BLACK LEVEL	High/Low	High	○	
HORIZ-CONVERGENCE	0~100%	CENTER(25~75) *		○
VERT-CONVERGENCE	0~100%	CENTER(25~75) *		○
VERT-CONV-TOP	0~100%	CENTER(25~75) *		○
VERT-CONV-BOTTOM	0~100%	CENTER(25~75) *		○
HORIZ-CONV-RIGHT	0~100%	CENTER(25~75) *		○
HORIZ-CONV-LEFT	0~100%	CENTER(25~75) *		○
MOIRE CANCEL	OFF / ON	OFF	○	
MOIRE CANCEL LEVEL	0~100%	0%	○	
CORNER PURITY(TL)	0~100%	CENTER(20~80) *		○
CORNER PURITY(TR)	0~100%	CENTER(20~80) *		○
CORNER PURITY(BL)	0~100%	CENTER(20~80) *		○
CORNER PURITY(BR)	0~100%	CENTER(20~80) *		○
CLAMP PULSE POSITION	FRONT / BACK	BACK	○	
OSD group 4				
DEGAUSS	PROCEED			○
POWER-SAVE	OFF / ON	ON		○
CONTROL LOCK	OFF / ON	OFF		○
OSD POSITION	<-- -->	OSD is the center of picture		○
ALL RESET	PROCEED			
GTF AUTO ADJUST	PROCEED			
DIAGNOSIS				
LANGUAGE	ENG/ESP/ITA/GER/FRA/JAP	ENG		○
OSD group 5				
USB UP STREAM	PORT A / PORT B			○
USB PORT COMBINATION	PORT A : D-SUB BNC PORT B : BNC D-SUB			○

\* In case of NG, confirm DAC value of the factory mode.

CENTER=the factory setting value returning by pressing +, - buttons simultaneously.

## Adjustment procedure

<NUB1107STTUW>

Adjustment items	Setting contents	Default setting	Setting classification	
			By timings	Common
OSD group 1				
CONTRAST	0~100%	100%		○
BRIGHT	0~100%	CENTER		○
COLOR NO.	1,2,3	COLOR NO.1	○	
R-GAIN 1,2,3	0~100%			○
G-GAIN 1,2,3	0~100%			○
B-GAIN 1,2,3	0~100%			○
COLOR TEMPERATURE 1,2,3	5000K~9300K	9300K		○
COLOR RESET 1,2,3	PROCEED			
OSD group 2				
H-SIZE	0~100%		○	
H-PHASE	0~100%		○	
H-POSITION	0~100%		○	
V-SIZE	0~100%		○	
V-POSITION	0~100%		○	
PCC-AMP	0~100%		○	
PCC-PHASE	0~100%		○	
PCC-CENTER	0~100%		○	
TOP-PCC	0~100%		○	
BOTTOM-PCC	0~100%		○	
PIN-BALANCE	0~100%		○	
KEY-BALANCE	0~100%		○	
CORNER-BALANCE	0~100%		○	
PCC-CENTER-BALANCE	0~100%		○	
V-LIN-BALANCE	0~100%		○	
V-LIN	0~100%		○	
ROTATION	0~100%	CENTER		○
ZOOM	0~100%		○	
GEOMETRY-RESET	PROCEED			
OSD group 3				
TEXTMODE	SHARP / SMOOTH	SHARP	○	
H-CONVERGENCE	0~100%	CENTER(25~75) *		○
V-CONVERGENCE	0~100%	CENTER(25~75) *		○
V-CONVERGENCE-TOP	0~100%	CENTER(25~75) *		○
V-CONVERGENCE-BOTTOM	0~100%	CENTER(25~75) *		○
H-CONVERGENCE-RIGHT	0~100%	CENTER(25~75) *		○
H-CONVERGENCE-LEFT	0~100%	CENTER(25~75) *		○
MOIRE CANCEL	OFF / ON	OFF	○	
MOIRE CANCEL LEVEL	0~100%	0%	○	
CORNER PURITY(TL)	0~100%	CENTER(20~80) *		○
CORNER PURITY(TR)	0~100%	CENTER(20~80) *		○
CORNER PURITY(BL)	0~100%	CENTER(20~80) *		○
CORNER PURITY(BR)	0~100%	CENTER(20~80) *		○
CLAMP PULSE POSITION	FRONT / BACK	BACK	○	
VIDEO LEVEL	1.0V / 0.7V	0.7V	○	
OSD group 4				
DEGAUSS	PROCEED			○
POWER-SAVE	OFF / ON	ON		○
CONTROL LOCK	OFF / ON	OFF		○
OSD POSITION	<- ->			○
ALL RESET	PROCEED			
GTF AUTO ADJUST	PROCEED			
DIAGNOSIS				
LANGUAGE	ENG/ESP/ITA/GER/FRA/JAP	ENG		○
OSD group 5				
USB UP STREAM	PORT A / PORT B			○
USB PORT COMBINATION	PORT A : D-SUB    BNC PORT B : BNC      D-SUB			○

\* In case of NG, confirm DAC value of the factory mode.

CENTER=the factory setting value returning by pressing +, - buttons simultaneously.

## Adjustment procedure

### 3.7.3.2 Factory mode

(1) Factory mode 1 (The same section as the user mode)

<NSB1107STTUW>

Adjustment items	Setting contents	Default setting	Setting classification	
			By timings	Common
OSD group 1				
CONTRAST	0~255	255		○
BRIGHT	0~255	Center		○
COLOR NO.	1,2,3	COLOR NO.1	○	
R-GAIN 1,2,3	0~255			○
G-GAIN 1,2,3	0~255			○
B-GAIN 1,2,3	0~255			○
COLOR TEMPERATURE 1,2,3	0~86	9300K(86)		○
COLOR RESET 1,2,3	PROCEED			
OSD group 2				
HORIZ-SIZE	0~144		○	
HORIZ-PHASE	0~127		○	
HORIZ-POSITION	0~255		○	
VERT-SIZE	0~127		○	
VERT-POSITION	0~127		○	
PINCUSHION	0~127		○	
KEYSTONE	0~255		○	
PIN-CENTER	0~255		○	
TOP-PIN	0~255		○	
BOTTOM-PIN	0~255		○	
PIN-BALANCE	0~63		○	
KEY-BALANCE	0~63		○	
CORNER-BALANCE	0~255		○	
PCC-CENTER-BALANCE	0~255		○	
V-LIN-BALANCE	0~255		○	
V-LIN	0~255		○	
ROTATION	0~255	Center		○
ZOOM	0~144		○	
GEOMETRY-RESET	PROCEED			
OSD group 3				
TEXTMODE	SHARP / SMOOTH	SHARP	○	
BLACK LEVEL	High/Low	High		○
HORIZ-CONVERGENCE	94~160	Center		○
VERT-CONVERGENCE	94~160	Center		○
VERT-CONV-TOP	90~164	Center		○
VERT-CONV-BOTTOM	90~164	Center		○
HORIZ-CONV-RIGHT	90~164	Center		○
HORIZ-CONV-LEFT	90~164	Center		○
MOIRE CANCEL	OFF / ON	OFF	○	
MOIRE CANCEL LEVEL	0~31	0	○	
CORNER PURITY(TL)	0~255	Center		○
CORNER PURITY(TR)	0~255	Center		○
CORNER PURITY(BL)	0~255	Center		○
CORNER PURITY(BR)	0~255	Center		○
CLAMP PULSE POSITION	FRONT / BACK	BACK	○	
OSD group 4				
DEGAUSS	PROCEED			○
POWER-SAVE	OFF / ON	OFF		○
CONTROL LOCK	OFF / ON	OFF		○
OSD POSITION	<-- -->	OSD is the center of picture		○
ALL RESET	PROCEED			
GTF AUTO ADJUST	PROCEED			
DIAGNOSIS				
LANGUAGE	ENG/ESP/ITA/GER/FRA/JAP	ENG		○
OSD group 5				
USB UP STREAM	PORT A / PORT B			○
USB PORT COMBINATION	PORT A : D-SUB BNC PORT B : BNC D-SUB			○

\* In case of NG, confirm DAC value of the factory mode.

CENTER=the factory setting value returning by pressing +, - buttons simultaneously.

## Adjustment procedure

<NUB1107STTUW>

Adjustment items	Setting contents	Default setting	Setting classification	
			By timings	Common
OSD group 1				
CONTRAST	0~255	255		○
BRIGHT	0~255	128		○
COLOR NO.	1,2,3	COLOR NO.1	○	
R-GAIN 1,2,3	0~255			○
G-GAIN 1,2,3	0~255			○
B-GAIN 1,2,3	0~255			○
COLOR TEMPERATURE 1,2,3	0~86	9300K(86)		○
COLOR RESET 1,2,3	PROCEED			
OSD group 2				
H-SIZE	0~144		○	
H-PHASE	0~127		○	
H-POSITION	0~255		○	
V-SIZE	0~127		○	
V-POSITION	0~127		○	
PCC-AMP	0~127		○	
PCC-PHASE	0~255		○	
PCC-CENTER	0~255		○	
TOP-PCC	0~255		○	
BOTTOM-PCC	0~255		○	
PIN-BALANCE	0~63		○	
KEY-BALANCE	0~63		○	
CORNER-BALANCE	0~255		○	
PCC-CENTER-BALANCE	0~255		○	
V-LIN-BALANCE	0~255		○	
V-LIN	0~255		○	
ROTATION	0~255	127		○
ZOOM	0~144		○	
GEOMETRY-RESET	PROCEED			
OSD group 3				
TEXTMODE	SHARP / SMOOTH	SHARP	○	
H-CONVERGENCE	50~205	127		○
V-CONVERGENCE	50~205	127		○
V-CONVERGENCE-TOP	80~170	127		○
V-CONVERGENCE-BOTTOM	80~170	127		○
H-CONVERGENCE-RIGHT	60~190	127		○
H-CONVERGENCE-LEFT	60~190	127		○
MOIRE CANCEL	OFF / ON	OFF	○	
MOIRE CANCEL LEVEL	0~31	0	○	
CORNER PURITY(TL)	58~198	127		○
CORNER PURITY(TR)	58~198	127		○
CORNER PURITY(BL)	58~198	127		○
CORNER PURITY(BR)	58~198	127		○
CLANP PULSE POSITION	FRONT / BACK	BACK	○	
VIDEO LEVEL	1.0V / 0.7V	0.7V	○	
OSD group 4				
DEGAUSS	PROCEED			○
POWER-SAVE	OFF / ON	OFF		○
CONTROL LOCK	OFF / ON	OFF		○
OSD POSITION	<-- -->			○
ALL RESET	PROCEED			
GTF AUTO ADJUST	PROCEED			
DIAGNOSIS				
LANGUAGE	ENG/ESP/ITA/GER/FRA/JAP	ENG		○
OSD group 5				
USB UP STREAM	PORT A / PORT B			○
USB PORT COMBINATION	PORT A : D-SUB BNC PORT B : BNC D-SUB			○

\* In case of NG, confirm DAC value of the factory mode.  
CENTER=the factory setting value returning by pressing +, - buttons simultaneously.

## Adjustment procedure

(2) Factory mode 2 (The added section to the user mode)

<NSB1107STTUW>

Adjustment items	Setting contents	Default setting	Setting classification	
			By timing	Common
FACT 00				
DBF H AMP(X2-L)	0~127		<input type="radio"/>	
DBF H AMP(X2-R)	0~127		<input type="radio"/>	
DBF H AMP(X4-L)	0~127	20	<input type="radio"/>	
DBF H AMP(X4-R)	0~127	50	<input type="radio"/>	
DBF H PHASE	0~255		<input type="radio"/>	
DBF V AMP(X2)	0~127		<input type="radio"/>	
R BIAS(COLOR1)	0~255	50		<input type="radio"/>
G BIAS(COLOR1)	0~255	50		<input type="radio"/>
B BIAS(COLOR1)	0~255	50		<input type="radio"/>
R BIAS(COLOR2)	0~255	50		<input type="radio"/>
G BIAS(COLOR2)	0~255	50		<input type="radio"/>
B BIAS(COLOR2)	0~255	50		<input type="radio"/>
R BIAS(COLOR3)	0~255	50		<input type="radio"/>
G BIAS(COLOR3)	0~255	50		<input type="radio"/>
B BIAS(COLOR3)	0~255	50		<input type="radio"/>
SUB-BRIGHT	0~255	200		<input type="radio"/>
ABL	0~255	220		<input type="radio"/>
H-PURITY	0~255	Center		<input type="radio"/>
V-PURITY	90~220	Center		<input type="radio"/>
FACT 01				
YH-T	113~141	Center		<input type="radio"/>
YH-J	113~141	Center		<input type="radio"/>
XH-T	109~145	Center		<input type="radio"/>
XH-J	90~164	Center		<input type="radio"/>
PQHT	15~239	Center		<input type="radio"/>
PQHB	30~224	Center		<input type="radio"/>
PQHL	0~255	255		<input type="radio"/>
PQHR	0~255	255		<input type="radio"/>
PQ1L	45~209	Center		<input type="radio"/>
PQ1R	22~232	Center		<input type="radio"/>
B3HT	84~170	Center		<input type="radio"/>
B3HB	84~170	Center		<input type="radio"/>
B3HL	0~255	0		<input type="radio"/>
B3HR	0~255	0		<input type="radio"/>
YV-T	115~139	Center		<input type="radio"/>
YV-J	90~164	Center		<input type="radio"/>
XV-T	81~173	Center		<input type="radio"/>
XV-J	95~159	Center		<input type="radio"/>
PQVT	0~255	Center		<input type="radio"/>
PQVB	0~255	Center		<input type="radio"/>
PQVL	0~255	0		<input type="radio"/>
PQVR	0~255	0		<input type="radio"/>
S1VL	60~194	Center		<input type="radio"/>
S1VR	40~214	Center		<input type="radio"/>
S3VT	75~179	Center		<input type="radio"/>
S3VB	75~179	Center		<input type="radio"/>
S3VL	0~255	0		<input type="radio"/>
S3VR	0~255	0		<input type="radio"/>
S2VT	80~174	Center		<input type="radio"/>
S2VB	80~174	Center		<input type="radio"/>
S2VL	0~255	0		<input type="radio"/>
S2VR	0~255	0		<input type="radio"/>



## Adjustment procedure

<NUB1107STTUW>

Adjustment items	Setting contents	Default setting	Setting classification	
			By timing	Common
FACT 00				
DBF H AMP(X2-L)	0~127		○	
DBF H AMP(X2-R)	0~127		○	
DBF H AMP(X4-L)	0~127	0	○	
DBF H AMP(X4-R)	0~127	40	○	
DBF H PHASE	0~255		○	
DBF V AMP(X2)	0~127		○	
R BIAS(COLOR1)	0~255	50		○
G BIAS(COLOR1)	0~255	50		○
B BIAS(COLOR1)	0~255	50		○
R BIAS(COLOR2)	0~255	50		○
G BIAS(COLOR2)	0~255	50		○
B BIAS(COLOR2)	0~255	50		○
R BIAS(COLOR3)	0~255	50		○
G BIAS(COLOR3)	0~255	50		○
B BIAS(COLOR3)	0~255	50		○
SUB-BRIGHT	0~255	200		○
ABL	0~255	220		○
H-PURITY	0~255	127		○
V-PURITY	90~220	127		○
FACT 01				
YH-T	0~255	127		○
YH-J	0~255	127		○
XH-T	0~255	127		○
XH-J	60~190	127		○
PQHT	0~255	127		○
PQHB	0~255	127		○
PQHL	0~255	255		○
PQHR	0~255	255		○
PQ1L	0~255	127		○
PQ1R	0~255	127		○
B3HT	0~255	127		○
B3HB	0~255	127		○
B3HL	0~255	0		○
B3HR	0~255	0		○
YV-T	0~255	127		○
YV-J	0~255	127		○
XV-T	0~255	127		○
XV-J	80~170	127		○
PQVT	0~255	127		○
PQVB	0~255	127		○
PQVL	0~255	0		○
PQVR	0~255	0		○
S1VL	0~255	127		○
S1VR	0~255	127		○
S3VT	0~255	127		○
S3VB	0~255	127		○
S3VL	0~255	0		○
S3VR	0~255	0		○
S2VT	0~255	127		○
S2VB	0~255	127		○
S2VL	0~255	0		○
S2VR	0~255	0		○

## General adjustment

### 3.8 Adjustment

#### 3.8.1 How to select the factory adjustment (FACTORY) mode

##### 3.8.1.1 Selecting with automatic adjustment device (Selecting with communication)

Using the communication command (DDC2Bi), issue the command from the automatic adjustment device to the monitor, and set the factory adjustment mode flag in the EEPROM to "01h" ("00h" for user mode).

(Refer to the A/B chassis automatic adjustment communication specifications (Protocol of DDC2Bi Enhanced) for details.)

##### 3.8.1.2 Selecting with front panel switches

- (1) Turn the power ON while holding down the BNC/DSUB CONNECTOR SELECT button.
- (2) After step (1), release the button after one to two seconds.
- (3) Confirm that 00 is displayed for the counter on the OSD display, and set to 225 with the (-) ADJUST button.
- (4) Set to 05 with the (+) ADJUST button.
- (5) When the ADJUST ITEM SELECT button (NSB1107STTUW) or ENTER button (NUB1107STTUW) is pressed, the factory mode will be entered.

This factory adjustment mode is entered with the above steps.

\*The factory adjustment mode remains valid even after the power is turned OFF.

Note that steps (3) to (4) must be carried out within ten seconds. If ten seconds are exceeded, the mode will return to the user mode.

#### <Returning to the user mode from the factory mode>

- (1) OSD (for factory, user select) is displayed with the group selection.
- (2) Set the counter value to 010 with the (-) (+) ADJUST buttons.
- (3) When the ADJUST ITEM SELECT button (NSB1107STTUW) or ENTER button (NUB1107STTUW) is pressed, the mode will return to the user mode.

#### 3.8.2 Adjustments before aging

Status Indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Before aging		The only the sync. signal of No. 12 : 106.25K / 85Hz

##### 3.8.2.1 Adjusting the high voltage

Status Indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	High voltage		The only the sync. signal of No. 12 : 106.25K / 85Hz

- (1) Turn the monitor power OFF, and connect a high voltage meter to the CRT anode. Then, turn the monitor power ON.
- (2) Turn the FBT picture potentiometer completely to the left.
- (3) Adjust the PWB-MAIN VR601 (HV-ADJ), and set to 27.0kV±0.5kV.

##### 3.8.2.2 SCREEN voltage adjustment

Status Indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	SCREEN voltage		The only the sync. signal of No. 12 : 106.25K / 85Hz

- (1) Connect a high voltage meter to the TP-SC terminal on the PWB-CRT.
- (2) Set to 700V±5V with the FBT picture potentiometer.

## ----- General adjustment -----

### 3.8.2.3

Adjust the focus pack "FOCUS 1, 2" so that both edges of the picture are clear.

### 3.8.2.4 Setting the high voltage protector working voltage

Status Indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Setting the high voltage protector working voltage		The only the sync. signal of No. 12 : 106.25K / 85Hz

- (1) Connect a voltage meter to TP-XPRO on the PWB-MAIN.
- (2) Confirm that the TP-XPRO voltage is  $10V \pm 1V$ .
- (3) Apply voltage ( $13.5 \pm 0.5V$  for NSB1107sTTUW,  $14 \pm 0.5V$  for NUB1107STTUW) from a source outside the monitor onto the TP-XPRO to confirm that the high voltage protector operates.
- (4) After confirming, repeatedly turn the power ON and OFF (at five second intervals) to confirm that the high voltage protector does not operate.

### 3.8.2.5 Shock test

Status Indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Shock test		The color bar pattern signal of No. 12 : 106.25K / 85Hz

- (1) Display the "color bar" from the signal generator A.
- (2) Confirm that there is no abnormality in the image when shock is applied on the monitor.

### 3.8.2.6 Preadjustment before aging

Status Indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Before aging		No. 12 : 106.25K / 85Hz
			Full white

- (1) Display a "full white" from the signal generator A.
- (2) Confirm that the R, G and B channel images are output.
- (3) Confirm that the H-CENT, picture position, picture size, PCC and balance can be controlled, and approximately adjust.
- (4) Confirm that the OSD power management is turned OFF.
- (5) Enter the factory mode (aging mode) beforehand.
- (6) Disconnect the signal and confirm that the following display appears on the OSD. Then, adjust the picture to the specified luminance value before ITC adjustment using BRIGHT adjustment, and carry out heat run for 30 minutes or more.

### 3.8.2.7 Adjusting the landing (ITC/4 corner purity adjustment)

Status Indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	landing		No. 12 : 106.25K / 85Hz
			Full green

- (1) Display the timing No. 12 (1600 x 1200, 106.25K/85) and full green.
- (2) Turn the monitor power OFF, and degauss with the hand demagnetizer.
- (3) Select TL with the SELECT button.
- (4) Using the ADJUST button and measuring instrument, adjust so that the landing value at the upper left corner is the "specified landing value".  
At this time, confirm that the adjustment value is within the range of 83 to 173 for NSB1107STTUW, 86 to 170 for NUB1107STTUW.

## General adjustment

(Specify the working range limit for ITC here.)

The value indicated in the designs is to be used for the "specified landing value".

- (5) Adjust the TF/BL/BR in the same manner.
- (6) Display the timing No. 12 (1600 x 1200, 106.25K/85) and full white.

The luminance before ITC adjustment shall be the "specified luminance value before ITC adjustment."

The value indicated in the designs is to be used for the "specified luminance value before ITC adjustment".

### 3.8.3 Adjustments after aging

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	After aging		

There is no +B adjustment.

### 3.8.4 Adjusting the picture size, position and distortion (using automatic adjustment device)

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Picture size, position, distortion	Factory	No. 12 : 106.25K / 85Hz

The manual adjustment methods are explained below. The adjustments are executed in the factory adjustment (factory) mode.

Adjust the picture size to the value indicated in the list of adjustment values.

Adjust the distortion to the value indicated in the picture performance inspection item.

#### 3.8.4.1 Adjusting the picture rotation

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Picture rotation		No. 12 : 106.25K / 85Hz
			Crosshatch with frame

Set the OSD to ROTATION, and using the (-) (+) ADJUST buttons, set the raster inclination to be horizontal to the CRT face surface.

#### 3.8.4.2 Adjusting the back raster position

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Back raster position	Factory	No. 12 : 106.25K / 85Hz

- (1) Set BRT to 100% to show the back raster. (When using the automatic adjustment device, set RGB-BIAS to MAX also.)

- (2) Input each adjustment timing, and set the OSD display to H-POSI. Using the (-) (+) ADJUST buttons, adjust the horizontal back raster position to the center of the bezel.

At this time, the raster width will be  $|L1-L2| \leq 3\text{mm}$ .

## General adjustment

### 3.8.4.3 Adjusting the left/right distortion, picture width, picture position (H-PHASE) and vertical linearity (all modes)

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Left/right distortion, picture width		See table of 3.9.1.12 (P3-35).
	picture position, vertical linearity		

- (1) Adjust the vertical size to approx. 295mm, and the vertical position to the approximate center.
- (2) Select V-LIN and V-LIN-BAL with the OSD, and adjust so that the vertical linearity is equal at the very top of the picture, at the very bottom of the picture, and at the center of the picture.
- (3) Select V-SIZE and V-POSI with the OSD, and adjust the vertical width and vertical position to the specified values using the ADJUST buttons.
- (4) Select PINCUSHION, KEYSTONE, PIN-CENTER, TOP-PIN and BOTTOM-PIN for NSB1107STTUW, PCC-AMP, PCC-PHASE, PCC-CENTER, PCC-TOP-CORNER, and PCC-BOTTOM-CORNER for NUB1107STTUW with the OSD, and adjust the vertical line at both side of the picture to the straight line using the ADJUST buttons.
- (5) If the left and right distortions differ, select PIN-BALANCE, KEY-BALANCE, CORNER-BALANCE and PCC-CENTER-BALANCE with the OSD, and adjust so that the distortions are visually balanced.
- (6) Select H-PHASE with the OSD, and adjust the horizontal raster position to the center of the picture using the ADJUST buttons.
- (7) Select H-SIZE with the OSD, and adjust the horizontal raster width to the value given in the adjustment list using the ADJUST buttons.

\* Note that the picture position and distortion must be within the ranges given in the picture performance inspection items.

### 3.8.4.4 Horizontal linearity adjustment

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Horizontal linearity		No. 2 (640x480 31.5K/60) only

- (1) Measure the horizontal linearity.
- (2) If the value is 9% or less, it is reference to OK.
- (3) If the value is 9% or more, judge whether the right expands or contracts.
- (4) If the right expands, set H-POSI data for -40 and DBF-H-PHASE for +9.
- (5) If the right contracts, set H-POSI data for +40 and DBF-H-PHASE for -9.
- (6) Adjust to that the image is the center with H-PHASE.
- (7) Measure the horizontal linearity once more to confirm that the value is 9%.


### 3.8.4.5 Adjusting the DBF amplitude and phase

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	DBF amplitude and phase		See table of 3.9.1.12 (P3-35).


- (1) Connect the oscilloscope to the PWB-MAIN TP-DBF and to one of the signal outputs for the signal sources full R, G, B (VIDEO).

## General adjustment

- (2) Select the following adjustment picture with the select button, and set to the following values with the (-) (+) ADJUST buttons.
  - (a) DBF H AMP (X4-L) : 20 (NSB1107STTUW), 0 (NUB1107STTUW)
  - (b) DBF H AMP (X4-R) : 50 (NSB1107STTUW), 40 (NUB1107STTUW)
- (3) Set the OSD to the DBF-H-AMP (2X-L and 2X-R) select picture, and using the (-) (+) ADJUST buttons adjust the horizontal parabola wave amplitude (image area) to the value given in the list of adjustment values.  
 Note that the same value must be input for L and R.
- (4) Set the OSD to the DBF-H-PHASE select picture, and using the (-) (+) ADJUST buttons adjust the horizontal parabola wave phase as shown below in respect to the image signal.
- (5) Set the OSD to the DBF-V-AMP (X2-L) select picture, and using the (-) (+) ADJUST buttons adjust the vertical parabola wave amplitude (image area) to the value given in the list of adjustment values.



DBF-V-AMP adjustment



DBF-H-AMP adjustment

## General adjustment

### 3.8.5 Adjusting the cut off (using the automatic adjustment device)

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Cut off	Factory	No. 12 : 106.25K / 85Hz


- (1) Input the timing No. 12 from the signal source. (R, G, B OFF)
- (2) Select BIAS1, and set BRIGHT to 128, SUB-BRIGHT to 200, and the R, G, B-BIAS to 50.
- (3) Adjust the back raster luminance to  $0.3 \pm 0.1 \text{cd/m}^2$ .
  - (a) If more than  $0.3 \text{cd/m}^2$ , change SUB-BRIGHT to adjust.
  - (b) If less than  $0.3 \text{cd/m}^2$ , change R, G, B-BIAS to adjust.
 The R, G, B-BIAS data must be the same values at this time.
- (4) Using two colors except for the basic colors, adjust the color coordination to the following values.
- (5) Change SUB-BRIGHT, and adjust the back raster luminance to  $0.3 \pm 0.1 \text{cd/m}^2$  for NSB1107STTUW  $0.3 \pm 0.05 \text{cd/m}^2$  for NUB1107STTUW.  
If adjustments with just SUB-BRIGHT are not possible, change BRIGHT and adjust.
- (6) If the back raster color coordination is deviated from the following values, repeat steps (4) and (5).  
(If the back raster cannot disappear, set BRIGHT to min., and set to the point where the back raster is eliminated with SUB-BRIGHT. Next, change BRIGHT, and adjust the back raster luminance to  $0.3 \pm 0.05 \text{cd/m}^2$ , and then adjust again from step (3).)
- (7) Copy COLOR 1 G-BIAS, to the COLOR 2, 3 G-BIAS.
- (8) Select BIAS 2, and change the BIAS data for the R and B colors (G-BIAS is fixed). Adjust the back raster color coordination to the following table.
- (9) Select BIAS 3, and change the BIAS data for the R and B colors (G-BIAS is fixed). Adjust the back raster color coordination to the following table.

Model	Confirmation item	COLOR 1	COLOR 2	COLOR 3	
All models	Color coordination	x	$0.283 \pm 0.015$	$0.313 \pm 0.015$	$0.345 \pm 0.015$
		y	$0.297 \pm 0.015$	$0.329 \pm 0.015$	$0.359 \pm 0.015$

\*The flow chart is provided on the next page.

# General adjustment


## Cutoff adjustment procedures



Continued on next page



Continued from previous page



## General adjustment

### 3.8.6 Adjusting the RGB drive signal

#### 3.8.6.1 Adjusting the R, G, B drive signal (Adjustment of COLOR 1)

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	R, G, B drive signal	Factory	No. 12 : 106.25K / 85Hz
			WINDOW picture

- (1) Input the following adjustment timing at the signal source.  
WINDOW picture (Input amplitude = 0.7Vp-p)

Model group	Adjustment timing
All model	Timing No. 12 (1600 x 1200 106.25K/85)

- (2) Select CONTRAST with the OSD, and set to MAX with (+) ADJUST button.  
 (3) Select BRIGHT with the OSD, and set the data to 128 with the (-) (+) ADJUST buttons.  
 (4) Set the signal generator A output to the WINDOW pattern (approx. 80mm square at center of CRT picture), and input only "GREEN".  
 (5) Set the COLOR 1 G with the OSD, and adjust the luminance to the following value with the ADJUST button.  
 (6) Input BLUE, RED and GREEN, appropriately select the COLOR 1 B and R, and adjust the color coordination to the following value with the ADJUST button.  
 (7) Set CONTRAST to 25cd/m<sup>2</sup> with the OSD to confirm that the change in color coordination is within  $\pm 0.015$  for both x and y.  
 \*Adjust COLOR 2 and 3 to the following values with the same method.

(Note) After adjusting COLOR, always set to COLOR 1.

(The COLOR preset will be set to the default COLOR 1 with this step.)

Model group	COLOR		1	2	3	Remarks
All models	G-WINDOW luminance		78.0	68.0	58.0	(Reference value)
	W-WINDOW color coordination	x	0.283	0.313	0.345	$\pm 0.005$
		y	0.297	0.329	0.359	$\pm 0.005$
	Full white luminance(cd/m <sup>2</sup> )		105 or more	92 or more	77 or more	

#### 3.8.6.2 Adjusting ABL

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	ABL	Factory	No. 12 : 106.25K / 85Hz
			Full white

- (1) Set the OSD ABL to 220.  
 (2) Input timing No. 12 at the signal source.  
 (Full white picture input amplitude = 0.7Vp-p)  
 (3) Set contrast to MAX, bright to MAX, and select ABL-ADJUST with OSD. Adjust to 115cd/m<sup>2</sup> $\pm 5$  for NSB1107STTUW, 108cd/m<sup>2</sup> $\pm 3$  for NUB1107STTUW with COLOR 1.  
 The picture size must be approximately the H width given in the list of adjustment values at this time.

## General adjustment

### 3.8.7 Adjusting the Purity

Status Indicator	Adjustment Item	Adjustment mode/set	Input signal/pattern
	Purity	Factory	Check 4 : 85Hz
			RED crosshatch reverse

- (1) Input the check 4 timing: 1600 x 1200/85Hz at the signal source to confirm that the RED crosshatch is displayed in reverse.
- (2) Set the chamber adjustment magnetic field to the northern hemisphere magnetic field (HORIZ. = 0mT, VERT. = +0.04mT).
- (3) After carefully degaussing the monitor with 100V handy-demagnetizer, demagnetize with a demagnetizer.
- (4) Set the monitor to the factory mode from the front, select H-Purity, and press the ADJUST ITEM SELECT button (NSB1107STTUW) or ENTER button (NUB1107STTUW) once. With this, the calibration of the horizontal (tube axis) and vertical (two way) geomagnetism sensor will be carried out by the MPU.  
Confirm that the current that flows to HCANCEL-Coil at this time is within 0±5mA.  
If not within 0±5mA, select H-Purity, and adjust to within 0±5mA.
- (5) Fully scan the picture size with the normal mode to confirm the below effective magnetic field allowance. (Carry out the 45-degree rotation check only for the tube axis direction magnetic field.)

(a) Turn the cancel switch OFF.

(b) Effective magnetic field (Magnetic field for adjustment magnetic field) ←

- |                                       |                                       |
|---------------------------------------|---------------------------------------|
| (1) BH: +0.04mT                       | (2) BH: -0.04mT                       |
| (3) BV: +0.35mT (NSB1107STTUW)        | (4) BV: -0.04mT (NSB1107STTUW)        |
| BV: +0.06mT (NUB1107STTUW)            | BV: -0.06mT (NUB1107STTUW)            |
| (Northern hemisphere)                 | (Northern hemisphere)                 |
| (5) BV: +0.04mT (Southern hemisphere) | (6) BV: -0.04mT (Southern hemisphere) |
| (Equator)                             | (Equator)                             |

Repeat the effective magnetic field four times in the following order.

- (1) (2) (3) (4) ... (Northern hemisphere)  
 (1) (2) (5) (6) ... (Southern hemisphere)  
 (Equator)

(c) Demagnetize with a demagnetizer.

(d) Turn the cancel switch ON.

(e) Judgment

\* Repeat (a) to (e) four times for each effective magnetic field.

\*\* When another color is hit while checking the 45-degree rotation of the tube axis direction magnetic field, if the level is not a problem in use of the normal mode Corner Purity, the level will be OK.



\*\*\* Before checking the vertical magnetic field, set the effective magnetic field, and then carry out manual degaussing on OSD once.

- (6) After confirming the effective magnetic field allowance in step (5), return to the adjustment (reference) magnetic field. After carefully degaussing the monitor with 100V handy-demagnetizer, confirm that the current flowing to the HCANCEL-Coil is within 0±5mA.  
If not within 0±5mA, adjust again from step (4).
- (7) Set the chamber adjustment magnetic field to the Southern hemisphere magnetic field (HORIZ. = 0mT, VERT. = -0.04mT).
- (8) After carefully degaussing the monitor with 100V handy-demagnetizer, degauss with a demagnetizer.
- (9) Repeat steps (5) and (6).
- (10) Set the chamber adjustment magnetic field to the Equator magnetic field (HORIZ. = 0mT, VERT. = 0mT).
- (11) After carefully degaussing the monitor with 100V handy-demagnetizer, degauss with a demagnetizer.
- (12) Repeat steps (5) and (6).

## General adjustment

### 3.8.8 Adjusting the focus

Status Indicator	Adjustment item	Adjustment mode/SEL	Input signal/pattern
	Focus		No. 12 : 106.25K / 85Hz
			H character, crosshatch

	Normal or reverse display	Point to align with
Vertical line	Reverse display	 <p>FOCUS JUST at center of right side vertical line (circle section).</p>
Horizontal line	Normal display	 <p>FOCUS JUST at center of screen (circle section).</p>

#### <Adjusting the static focus>

Status Indicator	Adjustment item	Adjustment mode/SEL	Input signal/pattern
	Static focus		No. 12 : 106.25K / 85Hz
			H character, crosshatch

For steps (1) and (2), use the timing No. 12 (1600 x 1200 106.25K/85) H character pattern and crosshatch pattern.

For step (3), use all preset timing H character patterns and crosshatch patterns.

- (1) Display a white crosshatch pattern, and adjust the focus following section "3.8.8 Adjusting the focus".
- (2) If the DBF voltage is insufficient or excessive, select DBF H AMP (X2-L)/DBF H AMP (X2-R) and DBF V AMP from the OSD, and readjust with the ADJUST button. Then repeat step (1), and adjust so that the following judgement conditions are satisfied.
- (3) For all of the other preset timings, if the DBF voltage is insufficient or excessive, select DBF H AMP (X2-L)/DBF H AMP (X2-R) and DBF V AMP from the OSD, and readjust with the ADJUST button.

The focus is judged as follows.

Timing	Judgment pattern (Note 1) (Note 2)
Normal display	Crosshatch pattern
Reverse display Timing No. 2, 6~12, 19 Timing No. 15,25 (NSB1107STTUW) Timing No. 25,27 (NUB1107STTUW)	Judge with pattern A Judge with pattern B

(Note 1) Pattern A: Font 7 X9, Cell 10X11, e character

(Note 2) Pattern B: Font 7 X9, Cell 10X11, H character

Core: Judge the ratio of the halo (total area 1:1).

To judge the reverse display, do not carry out a relative evaluation with the other point on the screen. Instead, judge whether the e (H) character can be read at that point.



## General adjustment

Adjusting the center miss convergence and axial miss convergence

Adjustment item name	Problem	Adjustment point	Adjustment procedure
H-STATIC V-STATIC			Adjust to $\pm 0.1$ mm or less with CP-ASSY 4P.
YH axial deviation			Adjust so that the TOP+BOTTOM is $\pm 0.1$ mm or less with the YH potentiometer.
YV axial deviation			Adjust so that the TOP+BOTTOM is $\pm 0.1$ mm or less with the YV potentiometer.
XH axial deviation			Adjust so that the LEFT-RIGHT is $\pm 0.1$ mm or less with the XH slider.
XV characteristics			Only when the XV (B-Bow) is $\pm 0.1$ mm or more, adjust so that the LEFT-RIGHT is $\pm 0.1$ mm or less with the B-Bow 4P and CP-ASSY 4P sequence.
XV axial deviation			Adjust so that the LEFT-RIGHT is $\pm 0.1$ mm or less with the XV differential coil.

## General adjustment









### 3.8.9.2 Adjusting DDCP (using automatic adjustment device)

The method for carrying out the automatic adjustment manually is explained below.

- (1) Input the timing No. 12 (1600 x 1200 106.2K/85) crosshatch pattern.
- (2) Enter the factory mode.
- (3) Adjust in the following order. (It is assumed that the center and axial mis-convergence on the previous page have already been adjusted.)

Adjustment order	Adjustment item name	Problem	Adjustment point	Adjustment procedure
<b>4H-COIL</b>				
1	H-CONVERGENCE			Adjust to 0.05mm or less. (Adjustment target is 0mm.)
2	YH-T (DY V coil characteristics)  YH-J (V direction axial deviation)			$YH-T = \frac{YH(Top) + YH(Btm)}{2}$ Compensate by the value obtained by adding the Top and Bottom mis-convergence amount and dividing it by 2, so that the top and bottom are the same absolute value. $YH-J = \frac{YH(Top) - YH(Btm)}{2}$ Basically, the adjustment is the same as above, however, the axial deviation element (top/bottom signs reversed) is subtracted. After adjusting, both the top and bottom must be 0.05mm or less. The target is 0mm.
3	XH-T (DY H coil characteristics)  XH-J (H direction axial deviation)			$XH-T = \frac{XH(L) + XH(R)}{2}$ Compensate by the value obtained by adding the Left and Right mis-convergence amount and dividing it by 2, so that the left and right are the same absolute value. $XH-J = \frac{XH(L) - XH(R)}{2}$ Basically, the adjustment is the same as above, however, the axial deviation element (left/right signs reversed) is subtracted. After adjusting, both the left and right must be 0.05mm or less. The target is 0mm.
4	PQHT PQHB PQHL PQHR			$PQHT = \frac{PQH(TL) + PQH(TR)}{2}$ $PQHB = \frac{PQH(BL) + PQH(BR)}{2}$ $PQHL = \frac{PQH(TL) + PQH(BL)}{2}$ $PQHR = \frac{PQH(TR) + PQH(BR)}{2}$ As with procedures 2 and 3, the compensation amount is the value obtained by adding and dividing by 2. Repeat the adjustment so that the results are 0.3mm or less.
5	PQ1L PQ1R			$PQ1L = \frac{PQ1(TL) + PQ1(BL)}{2}$ $PQ1R = \frac{PQ1(TR) + PQ1(BR)}{2}$ Same as above. However, the PQH in procedure 4 may have changed, so repeat steps 4 and 5 to achieve 0.3mm or less.

## General adjustment

Adjustment order	Adjustment item name	Problem	Adjustment point	Adjustment procedure
6	B3HT B3HB B3HL B3HR (B-ing characteristics)		B3H(TL)    B3H(TR)  B3H(BL)    B3H(BR)	$\frac{B3HT+(B3H(TL)+B3H(TR))/2}{2}$ $\frac{B3HB+(B3H(BL)+B3H(BR))/2}{2}$ $\frac{B3HL+(B3H(TL)+B3H(BL))/2}{2}$ $\frac{B3HR+(B3H(TR)+B3H(BR))/2}{2}$ The compensation amount is the value obtained by adding and dividing by 2. Repeat the adjustment so that the results are 0.3mm or less.
<b>4H-COIL</b>				
7	V-CONVERGENCE			Adjust to 0.05mm or less. (Adjustment target is 0mm.)
8	YV-T  YV-J		YV(Top)  YV(Btm)	$\frac{YV(Top)+YV(Btm)}{2}$ Compensate by the value obtained by adding the Top and Bottom mis-convergence amount and dividing it by 2, so that the top and bottom are the same absolute value.  $\frac{YV(Top)-YV(Btm)}{2}$ Basically, the adjustment is the same as above, however, the axial deviation element (top/bottom signs reversed) is subtracted. After adjusting, both the top and bottom must be 0.05mm or less. The target is 0mm.
9	XV-T  XV-J		XV(L)    XV(R) 	$\frac{XV(L)+XV(R)}{2}$ Compensate by the value obtained by adding the Left and Right mis-convergence amount and dividing it by 2, so that the left and right are the same absolute value.  $\frac{XV(L)-XV(R)}{2}$ Basically, the adjustment is the same as above, however, the axial deviation element (left/right signs reversed) is subtracted. After adjusting, both the left and right must be 0.05mm or less. The target is 0mm.



## General adjustment

Adjustment order	Adjustment item name	Problem	Adjustment point	Adjustment procedure
10	PQVT PQVB PQVL PQVR			$\frac{PQVT+(PQV(TL)+PQV(TR))/2}{2}$ $\frac{PQVB+(PQV(BL)+PQV(BR))/2}{2}$ $\frac{PQVL+(PQV(TL)+PQV(BL))/2}{2}$ $\frac{PQVR+(PQV(TR)+PQV(BR))/2}{2}$ <p>As with procedures 8 and 9, the compensation amount is the value obtained by adding and dividing by 2. Repeat the adjustment so that the results are 0.3mm or less.</p>
11	S1VL S1VR			$\frac{S1VL+(S1V(TL)+S1V(BL))/2}{2}$ $\frac{S1VR+(S1V(TR)+S1V(BR))/2}{2}$ <p>Same as above. However, the PQV in procedure 10 may have changed, so repeat steps 10 and 11 to achieve 0.3mm or less.</p>
12	S3VT S3VB S3VL S3VR			$\frac{S3VT+(S3V(TL)+S3V(TR))/2}{2}$ $\frac{S3VB+(S3V(BL)+S3V(BR))/2}{2}$ $\frac{S3VL+(S3V(TL)+S3V(BL))/2}{2}$ $\frac{S3VR+(S3V(TR)+S3V(BR))/2}{2}$ <p>The compensation amount is the value obtained by adding and dividing by 2. Repeat the adjustment so that the results are 0.3mm or less.</p>
13	S2VT S2VB S2VL S2VR			$\frac{S2VT+(S2V(TL)+S2V(TR))/2}{2}$ $\frac{S2VB+(S2V(BL)+S2V(BR))/2}{2}$ $\frac{S2VL+(S2V(TL)+S2V(BL))/2}{2}$ $\frac{S2VR+(S2V(TR)+S2V(BR))/2}{2}$ <p>The compensation amount is the value obtained by adding and dividing by 2. Repeat the adjustment so that the results are 0.3mm or less.</p>
14	<p>Finally, confirm that 4H and 4V have been adjusted to 0.3mm or less over the entire picture region.</p> <p>※ Adjust 6H and 6V so that the peripheral deviation amount is averaged, and set to 0.3mm or less.</p>			

※ The adjustment range of this DDCP adjustment (automatic adjustment device, manual adjustment) is designated as shown below.

Adjustment item	Adjustment value range (factory mode)	
	<NSB1107STTUW>	<NUB1107STTUW>
H-CONVERGENCE	115 ~ 139	96 ~ 158
V-CONVERGENCE	112 ~ 139	96 ~ 158
V-CONVERGENCE-TOP	112 ~ 142	109 ~ 145
V-CONVERGENCE-BOTTOM	112 ~ 142	109 ~ 145
H-CONVERGENCE-RIGHT	112 ~ 142	101 ~ 153
H-CONVERGENCE-LEFT	112 ~ 142	101 ~ 153

## General adjustment

### 3.8.10 Default settings (With factory mode)

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Default settings	Factory mode	Each adjustment timing
			Crosshatch

- (1) Set the default values as shown in the table (user mode) given in the OSD display (section 3.7.3 (1).)

If the setting class is an item for each timing, carry out for each adjustment timing.

The default setting CENTER is the factory adjustment value called when the (-) (+) ADJUST buttons are pressed simultaneously in the normal mode.

Only CONTRAST will be set to 100% when the (-) (+) ADJUST buttons are pressed simultaneously in the normal mode.

- (2) Return to the user mode with the front panel or automatic adjustment device.
- (3) Execute ALL RESET to confirm that each OSD setting is as shown in the table (user mode) given in the OSD display (section 3.7.3(1)).
- (4) After setting the default values, turn the power switch OFF.

## Adjustment procedure

### 3.9 Inspections (In normal mode)

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Inspections	Normal mode	

#### 3.9.1 Electrical performance

Inspect the electrical performance by setting contrast to MAX and bright to center (press the (-) (+) ADJUST buttons simultaneously).

##### 3.9.1.1 Withstand voltage

There must be no abnormality when 1500VAC is applied for two seconds between both ends of the AC input terminal and chassis, and between the DG coil terminal and chassis.

##### 3.9.1.2 Grounding conductivity check

Check that the resistance value is 100mΩ or less when 25A is passed between the AC input terminal grounding GND and chassis GND.

##### 3.9.1.3 Degaussing coil operation

Confirm that when OSD DEGAUSS is executed, the picture vibrates and then stops.

##### 3.9.1.4 POWER SAVE function operation (Set the AC power input to 230V)

Model	Confirmation timing
All model	Timing No. 12 (1600 x 1200 106.25K/85)

Use the full white pattern without R, G, B signals.

Select POWER-SAVE from the OSD, and set the POWER-SAVE function ON.

(Note) For the USB, do not connect a pseudo-USB load. Instead measure the following power consumption.

#### (1) STANDBY MODE

(a) Confirm that when H-SYNC is removed, the system waits for approx. five seconds, displays POWER SAVE for approx. three seconds, and then the picture darkens.

Also confirm that the power LED changes to orange and the power consumption is as follows.

Power consumption	15W or less
-------------------	-------------

(b) Confirm that when H-SYNC is input again, the high voltage is recovered, and the picture appears in approx. four seconds.

#### (2) SUSPEND MODE

(a) Confirm that when V-SYNC is removed, the system waits for approx. five seconds, displays POWER SAVE for approx. three seconds, and then the high voltage drops.

Also confirm that the power LED changes to orange when the high voltage is down. Confirm that the power consumption is as follows.

Power consumption	15W or less
-------------------	-------------

(b) Confirm that when V-SYNC is input again, the high voltage is recovered, and the picture appears in approx. four seconds.

\* It can be confirmed either the step (1) or (2) on the above.  
It is need to confirm the step (3).

## Adjustment procedure

### (3) COMPLETE OFF MODE

(a) Confirm that when both H-SYNC and V-SYNC are removed, the system waits for approx. five seconds, displays POWER SAVE for approx. three seconds, and then the high voltage drops.

Also confirm that the power LED changes to orange when the high voltage is down. Confirm that the power consumption is as follows.

Power consumption	3W or less
-------------------	------------

(b) Confirm that when H-SYNC and V-SYNC are input again, the high voltage is recovered, and the picture starts to become brighter within 12 seconds.

#### 3.9.1.5 Confirming the MOIRE-CLEAR function

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	MOIRE-CLEAR		No. 5 : 91.1K / 85Hz

Input timing No. 5 (1280 x 1024 91.1K/85.0), and turn the MOIRE-CLEAR function ON. Confirm that the picture vibrates in the horizontal direction.

#### 3.9.1.6 Confirming the CORNER-PURITY function

Model	Confirmation timing
All model	Timing No. 12 (1600 x 1200 106.25K/85)

Input a (full white display), and press the (-)(+) ADJUST buttons to change the CORNER PURITY (TR/TL/BR/BL). Confirm that the color coordination around the picture changes. Then, press the (-)(+) ADJUST buttons simultaneously to confirm that the picture purity returns to the CENTER.


#### 3.9.1.7 Focus, picture performance (Timing No. 12 (1600 x 1200 @ 85Hz))

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Focus, picture performance		No. 12 : 85Hz

The picture must be evenly bright with the "e" character normal and reverse displays.

#### 3.9.1.8 Fixing the parts

- (1) After the adjustment and inspection are completed, fix SCREEN-VR on the FBT focus pack with a yellow pen or white pen.
- (2) Place the DHHS-CAP on the PWB-MAIN VR601. Use TSE3940 adhesive.



## Adjustment procedure

### 3.9.1.9 Mis-convergence

After heat running for 20 minutes or more, the mis-convergence amount in the horizontal and vertical directions when the set is faced to the East or West must be below the following values.

The mis-convergence amount is the value between the two colors of R, G and B separated the most in the horizontal (X) and vertical (Y) directions when a 17 vertical line x 13 horizontal line crosshatch is displayed.

Zone	Mis-convergence amount				
	All models				
Center	0.2mm or less				
A	0.3mm or less				
B	0.35mm or less				
Measurement timing (Timing No.)	12				






## Adjustment procedure






### 3.9.1.10 Picture distortion

When the picture distortion is measured, each distortion of the preset timing must be less than the following values.



<Picture performance inspection items> Inspect the following items for the picture distortion.

No.	Item	Judgement reference value	Input signal
1.	<p>4-corner section distortion Inspect the distortion at the four corners.</p> <ul style="list-style-type: none"> <li>Signal, H character with frame (both normal/reverse)</li> <li>Distortion x: Distortion in the range of one H character height. Judge with the white display G. (Judge the distortion amount with a fluorescent material stripe.)</li> </ul> 	$x \leq 1\text{pitch}$ $(=0.3\text{mm})$	H character with frame (both normal/reverse)
2.	<p>4-edge distortion When S-character or seagull type high frequency distortion is visible, check with the following method.</p> <ul style="list-style-type: none"> <li>Distortion x of S-character distortion, etc.: Distortion excluding normal pin, barrel or trapezoid. Note: There must be no seagull distortion.</li> <li>Distortion y: High frequency distortion excluding trapezoid.</li> </ul> 	$x \leq 0.6\text{mm}$ * Note  $y \leq 1.0\text{mm}$	Crosshatch pattern
3.	<p>Inner distortion</p> <ul style="list-style-type: none"> <li>Distortion x: a. Center line b. Curve of other vertical line</li> <li>Distortion x: a. Center line b. Curve of other vertical line</li> <li>Distortion <math>\Delta x</math>: Curve within 50mm range</li> </ul> 	a. $x \leq 1.0\text{mm}$ b. $x \leq 1.5\text{mm}$ (*)  (*) Present No. 0 (31.5kHz, 60Hz) is: a. $x \leq 1.5\text{mm}$ b. $x \leq 2.0\text{mm}$  $\Delta x \leq 0.6\text{mm}$	↓

## Adjustment procedure

No.	Item	Judgement reference value	Input signal
4.	<p>Line curve (crosshatch pattern outer contour)</p>  <p> <math>\Delta x</math>: Curve within 50mm range (horizontal)  <math>\Delta y</math>: Curve within 50mm range (vertical)         </p>	$\Delta x \leq 1.0\text{mm}$ $\Delta y \leq 1.0\text{mm}$	Crosshatch pattern
5.	<p>Horizontal trapezoid (top/bottom), vertical trapezoid (left/right)</p>  <ul style="list-style-type: none"> <li>• <math>\Delta y =  y1 - y2 </math></li> <li>• <math>\Delta x =  x1 - x2 </math></li> <li>• Control with the above right value for each the top, bottom, left and right.</li> </ul>	$\Delta y \leq 2.0\text{mm}$ $\Delta x \leq 1.8\text{mm}$	
6.	<p>Top/bottom pin and barrel, left/right pin and barrel</p>  <p>Picture</p>	<p>(Provisional standards)</p> $\Delta y_b \leq 1.0\text{mm}$ $\Delta y_p \leq 1.5\text{mm}$ $\Delta x \leq 1.0\text{mm}$	
7.	<p>Parallelogram distortion</p>  <p>Measure the larger of <math>x1</math> and <math>x2</math>.</p>	$x \leq 0.8\text{mm}$	
8.	<p>Inclination</p>  <p>Measure <math>\Delta y =  y1 - y2 </math>.</p>	$\Delta y \leq 2.0\text{mm}$	↓

## Adjustment procedure

No.	Item	Judgement reference value	Input signal
9.	Distortion Must be within the following frame. ※ (Note, excluding ROTATION) <div style="text-align: center;">  </div>	$y \leq 2.0\text{mm}$ $x \leq 2.0\text{mm}$	Crosshatch pattern
10.	Picture position Display picture <div style="text-align: center;">  </div>	$ L1-L2  \leq 3.0\text{mm}$ $ L3-L4  \leq 3.0\text{mm}$	Full white

### 3.9.1.11 Linearity

Measure the linearity with a 17 horizontal line x 13 vertical line crosshatch.

Horizontal linearity : 10% or less, adjacent : 7% or less

Vertical linearity : 10% or less, adjacent : 7% or less

Calculation expression :  $(X_{\text{max}} - X_{\text{min}}) / X_{\text{max}} \times 100\%$

\* When any doubts arise about the judgment, judge with  $\pm 3.0\text{mm}$  of the tolerance of horizontal and vertical width, picture position is  $|L1-L2| \leq 3.0\text{mm}$  and  $|L3-L4| \leq 3.0\text{mm}$ .



## Adjustment value list

### 3.9.1.12 Adjustment value list

The horizontal width, vertical width and DBF-H amplitude must be within the following ranges.

<NSB1107STTUW>

Timing	Horizontal width (mm)		Vertical width (mm)		DBF-H amplitude (V)		DBF-V amplitude (V)	
No.	Group 1		Group1		Group 1		Group 1	
1								
2	393±5		295±4		380±10		160±10	
3								
4								
5								
6	393±5		295±4		380±10		160±10	
7	393±5		295±4		380±10		160±10	
8	393±5		295±4		380±10		160±10	
9	369±5		295±4		350±10		160±10	
10	369±5		295±4		350±10		160±10	
11	393±5		295±4		380±10		160±10	
12	393±5		295±4		380±10		160±10	
13								
14								
15								
16								
17								
18								
19	393±5		295±4		380±10		160±10	
20								
21								
22								
23								
24								
25	393±5		295±4		380±10		160±10	
26								
27								

<NUB1107STTUW>

Timing	Horizontal width (mm)		Vertical width (mm)		DBF-H amplitude (V)		DBF-V amplitude (V)	
No.	Group 1		Group1		Group 1		Group 1	
1								
2	393±5		295±4		420±10		160±10	
3								
4								
5								
6	393±5		295±4		420±10		160±10	
7	393±5		295±4		420±10		160±10	
8	393±5		295±4		420±10		160±10	
9	369±5		295±4		390±10		160±10	
10	369±5		295±4		390±10		160±10	
11	393±5		295±4		420±10		160±10	
12	393±5		295±4		420±10		160±10	
13								
14								
15								
16								
17								
18								
19	393±5		295±4		420±10		160±10	
20								
21								
22								
23								
24								
25	393±5		295±4		420±10		160±10	
26								
27	369±5		295±4		390±10		160±10	

## Adjustment procedure

### 3.9.1.13 Confirming GTF

GTF does not need to be confirmed.

### 3.9.1.14 Checking the functions during Sync on Green and Composite Sync input

Status Indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Checking the functions during Sync on Green and Composite Sync input		Check 1 : 35K / 66Hz, Check 2 : 35K / 66Hz
			Full white

[Sync on Green]

Timing: Check 1 (35K/66), full white

[Composite Sync]

Timing: Check 2 (35K/66), full white

In the normal mode, input the above timing into the D-SUB or BNC connector to confirm that the operation is normal.

### 3.9.1.15 Confirming the D-SUB/BNC input (Timing No. 12 1600 x 1200 @85Hz)

Status Indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Confirming the D-SUB/BNC input		No. 12 : 85Hz

Confirm the input select function for both D-SUB and BNC with the following procedure. Confirm one of the following with an independent stage.

- (1) After connecting D-SUB, press the front button (D-SUB/BNC) and confirm that after the picture darkens it returns to the normal state.
- (2) After connecting BNC, press the front button (D-SUB/BNC) and confirm that after the picture darkens it returns to the normal state.

### 3.9.1.16 Confirming the ROTATION function and reset operation

Model	Confirmation timing
All model	Timing No. 12 (1600 x 1200 106.25K/85)

<NSB1107STTUW>

Carry out the following confirmation in the NORMAL MODE.

#### (1) Confirming the ROTATION

When selecting ROTATION and pressing the ADJUST button(-) (+), confirm the picture rotating.

#### (2) Confirming the reset operation

When pressing the ADJUST button(-) (+) after lowering any the CONTRAST data, confirm the data becoming 100%.

\*For all reset, confirm with "3.8.10 default setting".

<NUB1107STTUW>

Carry out the following confirmation in the NORMAL MODE.

(1) After lowering the CONTRAST data somewhat, press the (-)(+) ADJUST buttons simultaneously to confirm that the data changes to 100%.

(2) After lowering the BRIGHT data somewhat, press the (-)(+) ADJUST buttons simultaneously to confirm that the data changes to CENTER.

## Adjustment procedure

- (3) After setting H-SIZE to MAX, start the Geometry Reset function with the OSD to confirm that the data returns to the original value.
- (4) After lowering the ROTATION data somewhat, press the (-)(+) ADJUST buttons simultaneously to confirm that the data returns to the original value.
- (5) After lowering the H-STATIC data somewhat, press the (-)(+) ADJUST buttons simultaneously to confirm that the data returns to the original value.
- (6) After lowering the COLOR-1 GREEN data somewhat, press the reset button to confirm that the GREEN data returns to the original value.

### 3.9.1.17 Confirming the full white luminance

Status Indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Confirming the full white luminance		No. 12 : 85Hz
			Full white

Timing No. 12 (1600 x 1200 106.25K/85), input amplitude = 0.7Vp-p  
 Confirm that the full white luminance is the following value.

Model	COLOR 1	COLOR 2	COLOR 3	Remarks
All models	105 or more	92 or more	77 or more	

### 3.9.1.18 Confirming the back raster luminance

Status Indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Confirming the back raster luminance		No. 12 : 85Hz、 R, G, B OFF

<NSB1107STTUW>

It is not need to confirm.

<NUB1107STTUW>

Input timing No. 12 (1600 x 1200 @85Hz) (R, G, B OFF).

When at the BRIGHT CENTER with COLOR 1, confirm that the back raster luminance is 0.3+/- 0.1cd/m<sup>2</sup>. Confirm that the back raster luminance is 2.5cd/m<sup>2</sup> or more at BRIGHT MAX.

### 3.9.1.19 Luminance/color coordination uniformity

Status Indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Luminance/color coordination uniformity		No. 12 : 85Hz

The luminance ratio between the center and periphery must be 80% or more with timing No. 12 (1600 x 1200 @85Hz) COLOR 1.

The color coordination difference between the center and periphery must be  $\Delta x, y < \pm 0.012$  at COLOR 1/2/3.

Model	Confirmation item	COLOR 1	COLOR 2	COLOR 3	
All models	Color coordination	x	0.283±0.007	0.313±0.007	0.345±0.007
		y	0.297±0.007	0.329±0.007	0.359±0.007

※ OSD color coordination confirmation X=0.283±0.04 Y=0.297±0.05  
 (Confirm at the white section of the OSD.)

## Adjustment procedure

### 3.9.1.20 Confirming the full white color coordination

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Confirming the color tracking		No. 12 : 85Hz
			Full white

Confirm that the color coordination at the center of the full white is within the following range at the drive signal adjustment timing.

### 3.9.1.21 Confirming the color tracking

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Confirming the TEXT MODE operation		No. 12 : 85Hz
			Crosshatch

Confirm with timing No. 12 (1600 x 1200 @ 85Hz).

Measure the color coordination at the center of the picture using a full white pattern (input amplitude = 0.7Vp-p).

- (a) Confirm that the color coordination change is within the  $\pm 0.012$  range when the CONTRAST is set to 25cd/m<sup>2</sup> with the OSD.
- (b) Confirm that the color coordination change is within the  $\pm 0.012$  range when the input amplitude is set to 0.22Vp-p at the signal source.

### 3.9.1.22 Confirming the TEXT MODE operation

Using a timing No. 12 (1600 x 1200 @ 85Hz) crosshatch pattern, select the TEXT mode with the OSD. Confirm that the vertical line becomes thicker during the reverse display when changed from SHARP to SMOOTH.

### 3.9.1.23 Confirming the BLACK LEVEL

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Confirming the BLACK LEVEL		No. 12 : 106.25K / 85Hz

When selecting BLACK LEVEL with the OSD, the Timing No. 12 and the full white, and setting High --->Low, confirm the luminance becoming dark.

### 3.9.1.24 CRT installation position

CRT installation position tolerance    Within  $\pm 3$ mm in vertical direction    Within  $\pm 2.5$ mm in horizontal direction  
Inclination: Within  $\pm 2.5$ mm at bezel reference

### 3.9.1.25 Confirming the geomagnetism tolerance (Timing No. 12: 1600 x 1200 106.25K/85)

Status indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Confirming the geomagnetism tolerance		No. 12 : 106.25K / 85Hz

There must be no apparent color unevenness with each single color when the magnetic field is changed with the following procedure. The display picture size is 393mm x 295mm.

1. Northern hemisphere magnetic field : Horizontal magnetic field (B<sub>H</sub>) : 0 $\pm$ 0.04mT  
Vertical magnetic field (B<sub>V</sub>) : +0.04 $\pm$ 0.35mT/0.04-0.04mT (NSB1107STTUW)  
Vertical magnetic field (B<sub>V</sub>) : +0.04 $\pm$ 0.06mT (NUB1107STTUW)
2. Southern hemisphere magnetic field : Horizontal magnetic field (B<sub>H</sub>) : 0 $\pm$ 0.04mT  
Vertical magnetic field (B<sub>V</sub>) : -0.04 $\pm$ 0.04mT
3. Equator magnetic field : Horizontal magnetic field (B<sub>H</sub>) : 0 $\pm$ 0.04mT  
Vertical magnetic field (B<sub>V</sub>) : 0 $\pm$ 0.04mT

## Adjustment procedure

<Confirmation procedure>

Completely demagnetize the entire unit including the monitor plates, CRT, funnel section, along the DG coil and face surface with handy-demagnetizer (100V) at the magnetic fields for BH = 0G and Bv = destination. Then, change BH and Bv to the above values, and demagnetize again. Then, visually confirm.

Note that when changing Bv, set to the effective magnetic field, and then carry out manual degaussing on the OSD once before confirming.

### 3.9.1.26 Confirming the cancel function operation (Timing No. 12: 1600 x 1200 106.25K/85)

Status Indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Confirming the cancel function operation		No. 12 : 106.25K / 85Hz

- (1) Confirm that the following cancel function operates correctly when the tube axial magnetic field (BH) is moved 0.04mT in the + direction or - direction.
- (2) Confirm that the cancel function operates correctly when the vertical magnetic field (Bv) is moved by the following value in the + direction or - direction.

Note that when changing Bv, set to the effective magnetic field, and then carry out manual degaussing on the OSD once before confirming.

1. Northern hemisphere magnetic field : 0.035mT/-0.04mT (NSB1107STTUW)  
: 0.06mT (NUB1107STTUW)
2. Southern hemisphere magnetic field : 0.04mT
3. Equator magnetic field : 0.04mT

<Procedures for confirming cancel function>

1. Mis-convergence (NUB1107STTUW only)  
If the values given in section 3.9.1.9 Mis-convergence are satisfied, the state is OK.
2. Distortion and picture position (Horizontal raster position)  
Confirm that the "distortion" and "picture position" compensation operations are correct.

### 3.9.1.27 Confirming the grill vibration

Status Indicator	Adjustment item	Adjustment mode/set	Input signal/pattern
	Confirming the grill vibration		No. 12 : 106.25K / 85Hz
			Full white

Using timing No. 12 (1600 x 1200 106.25K/85) full white pattern.

- (1) Tap the top of the monitor with a rubber hammer.  
(Strength equivalent to shock test.)
- (2) Observe from a position 60cm away from the tube surface.
- (3) If the vibration continues for 10 seconds or more, judge as line out.
- (4) For the set judged as line out, after carry out normal aging (30 minutes or more), apply an impact on the center of the tube surface with an impact hammer. Impact strength: 0.35Nm
- (5) Observe from a position 60cm away from the tube surface.
- (6) If the vibration continues for 9.5 seconds or more, replace the CRT. If the vibration is within 9.5 seconds, return to the line.

**3.9.1.28 Confirming the USB hub**

Test using a USB mouse, etc.

**3.9.1.29 Others**

- (1) When the PUSH button is pressed, the changes must be smooth, and there must be no abnormalities such as noise.
- (2) Synchronization must not flow when the power switch is turned ON and OFF.
- (3) Confirm that the POWER LED is lit.

**3.10 Checking the DDC function (using automatic adjustment device)**

This writing operation is carried out in combination with the PC.

Confirm that the PC internal clock is correctly set when preparing for this work.

**3.10.1 Writing/checking the DDC and EDID data**

- (1) Following the PC picture displays, select the target model. (This step is carried out only once when the device is started up or the model is changed.)
- (2) Turn the monitor power ON.
- (3) Following the PC picture displays, write the data into the EEPROM.  
The data contents shall be those designated in the table of section 3.10.3.
- (4) Following the PC picture displays, check the DDC function.
- (5) There may be an error of four weeks for the manufacturing week and year information.

## Adjustment procedure

### 3.10.2 Setting the serial No.

#### (1) DDC compatible serial No. setting specifications

[Hexadecimal conversion]

Read the following serial No. with the barcode system, and set the serial No. with the following conversion.

Model	Serial No.
All models	Mitsubishi serial No.
	Customer serial No.

Low-order 5 digits of S/N → Hexadecimal conversion → Store data in order from low-order byte  
 6th and higher digit of S/N → Set as 0 (Follow VESA Standards)

(Example) 512002978 → 00000BA2 → Address0C : A2  
 Address0D : 0B  
 Address0E : 00  
 Address0F : 00

(The above address is the offset from the head address 0C32h in the EEPROM.)

[ASCII conversion] (All models)

Read the Mitsubishi serial No. with the barcode system, and set the serial No. with the following conversion.

Low-order 5 digits of S/N → ASCII code conversion → Store data in order from low-order byte  
 (To MONITOR DESCRIPTOR #4)

(Example) 512A02978

↓  
 35 31 32 41 30 32 39 37 38  
 ↓

Address (H)	Data (H)
71	35
72	31
73	32
74	41
75	30
76	32
77	39
78	37
79	38
7A	0A ← Indicates end of S/N data
7B	20 ← Indicates blank
7C	20 ← Indicates blank
7D	20 ← Indicates blank

} Fixed data  
 (Set according to No. of S/N digits)

(The above address is the offset from the head address 0C32h in the EEPROM.)

## Adjustment procedure

### (2) USB compatible serial No. setting specifications

Store the serial No. into the following address in the EEPROM with the following procedure.

[UNICODE conversion] (All models)

Read the Mitsubishi serial No. with the barcode system, and set the serial No. with the following conversion.

S/N → UNICODE conversion → Store data in order from low-order byte  
(To STRING DESCRIPTOR)

(Example) 512A02978

↓  
0035 0031 0032 0041 0030 0032 0039 0037 0038

↓  
Head address; 0F60h

Offset address from head address	Setting data
00	35
01	00
02	31
03	00
04	32
05	00
06	41
07	00
08	30
09	00
0A	32
0B	00
0C	39
0D	00
0E	37
0F	00
10	38
11	00
12	20 ; Insert the space "0020" when there is a blank
13	00



# Adjustment procedure

## 3.10.3 DDC write data contents

The contents of DDC write data must be as follows.

<NSB1107STTUW>

ROM-address	00	ff	ff	ff	ff	ff	ff	00	34	ac	11	43	**	**	**	**
0C32~	00	ff	ff	ff	ff	ff	ff	00	34	ac	11	43	**	**	**	**
0C42~	WW	YY	01	01	0e	28	1e	78	e9	04	88	a0	57	4a	9b	26
0C52~	12	48	4c	ff	ff	80	31	59	d1	4f	a9	59	a9	4f	81	99
0C62~	e1	4f	61	59	45	59	0f	75	08	b0	72	46	43	50	90	c8
0C72~	13	00	89	27	11	00	00	18	00	00	00	fd	00	32	a0	1e
0C82~	79	24	00	0a	20	20	20	20	20	20	00	00	00	fc	00	4e
0C92~	53	42	31	31	30	37	55	0a	20	20	20	20	00	00	00	ff
0CA2~0CB1	00	NN	NN	NN	NN	NN	NN	NN	NN	NN	NN	NN	20	20	00	SS

-- EDID DATA DUMP TEXT --

Vendor Name: MEL  
 Product Code LSB (HEX): 11  
 Product Code MSB (HEX): 43  
 Product Code (DEC): 17169  
 (Microsoft INF ID: MEL4311)  
 Serial Number (DEC): 0  
 Serial Number (HEX): 00000000  
 Week of Manuf: WW  
 Year of Manuf: YY

EDID Version: 1  
 EDID Revision: 1  
 Extension Flag: 0

Input Signal: ANALOG  
 Setup: NO  
 Sync on Green: YES  
 Composite Sync: YES  
 Separate Sync: YES  
 V Sync Serration: NO  
 V Signal Level: 0.700V/0.300V (1V p-p)

Max Image Size H (cm): 40  
 Max Image Size V (cm): 30  
 DPMS Stand By: YES  
 DPMS Suspend: YES  
 DPMS Active Off: YES  
 GTF Support: YES  
 Standard default Color Space: NO  
 Preferred Timing Mode: NO  
 Display Type: RGB Color

Gamma: 2.2  
 Red x: 0.625  
 Red y: 0.340  
 Green x: 0.290  
 Green y: 0.605  
 Blue x: 0.150  
 Blue y: 0.070  
 White x: 0.283  
 White y: 0.297

Established Timings:

720x400@70  
 720x400@88  
 640x480@60  
 640x480@67  
 640x480@72  
 640x480@75  
 800x600@56  
 800x600@60  
 800x600@72  
 800x600@75  
 832x624@75  
 1024x768@87  
 1024x768@60  
 1024x768@70  
 1024x768@75  
 1152x870@75  
 1280x1024@75

Standard Timing #1:  
 Horizontal Active Pixels: 640  
 Aspect Ratio: 4:3  
 (480 active lines)  
 Refresh Rate: 85Hz

Standard Timing #2:  
 Horizontal Active Pixels: 1920  
 Aspect Ratio: 4:3  
 (1440 active lines)  
 Refresh Rate: 75Hz

Standard Timing #3:  
 Horizontal Active Pixels: 1600  
 Aspect Ratio: 4:3  
 (1200 active lines)  
 Refresh Rate: 85Hz

Standard Timing #4:  
 Horizontal Active Pixels: 1600  
 Aspect Ratio: 4:3  
 (1200 active lines)  
 Refresh Rate: 75Hz

Standard Timing #5:  
 Horizontal Active Pixels: 1280  
 Aspect Ratio: 5:4  
 (1024 active lines)  
 Refresh Rate: 85Hz

Standard Timing #6:  
 Horizontal Active Pixels: 2048  
 Aspect Ratio: 4:3  
 (1536 active lines)  
 Refresh Rate: 75Hz

Standard Timing #7:  
 Horizontal Active Pixels: 1024  
 Aspect Ratio: 4:3  
 (768 active lines)  
 Refresh Rate: 85Hz

Standard Timing #8:  
 Horizontal Active Pixels: 800  
 Aspect Ratio: 4:3  
 (600 active lines)  
 Refresh Rate: 85Hz

Detailed Timing (block #1):  
 Pixel Clock: 299.67  
 Horizontal Active: 1800  
 Horizontal Blanking: 688  
 Vertical Active: 1350 lines  
 Vertical Blanking: 67 lines  
 (Horizontal Frequency: 120.45 kHz)  
 (Vertical Frequency: 85.0 Hz)  
 Horizontal Sync Offset: 144 pixels  
 Horizontal Sync Width: 200 pixels  
 Vertical Sync Offset: 1 lines  
 Vertical Sync Width: 3 lines  
 Horizontal Border: 0 pixels  
 Vertical Border: 0 lines  
 Horizontal Image Size: 363 mm  
 Vertical Image Size: 295 mm  
 Interlaced: NO  
 Image: Normal Display  
 Sync: Digital Separate  
 Bit 1: OFF  
 Bit 2: OFF

Monitor Range Limits (block #2):  
 Minimum Vertical Rate: 50 Hz  
 Maximum Vertical Rate: 160 Hz  
 Minimum Horizontal Rate: 30 kHz  
 Maximum Horizontal Rate: 121 kHz  
 Maximum Pixel Clock: 330 MHz  
 GTF Data: 00 0a 20 20 20 20 20

Monitor Name (block #3): NSB1107U

Monitor Serial Number (block #4):  
 NNNNNNNNN

EDID EDITOR V1.34 (990407) (C)  
 Mitsubishi Electric 1995-1999

EDID DATA DUMP HEX

```

00 ff ff ff ff ff ff
34 ac 11 43 ** ** ** **
WW YY 01 01 0e 28 1e 78
e9 04 88 a0 57 4a 9b 26
12 48 4c ff ff 80 31 59
d1 4f a9 59 a9 4f 81 99
e1 4f 61 59 45 59 0f 75
08 b0 72 46 43 50 90 c8
13 00 89 27 11 00 00 18
00 00 00 fd 00 32 a0 1e
79 24 00 0a 20 20 20 20
20 20 00 00 fc 00 52
53 46 32 32 48 0a 20 20
20 20 20 20 00 00 00 ff
00 NN NN NN NN NN NN NN
NN NN 0a 20 20 20 00 SS
** : Serial number 1 (HEX)
WW : Week of manufacture
YY : Year of manufacture
NN : Serial number 2 (ASCII)
SS : Checksum
    
```

# Adjustment procedure

<NUB1107STTUW>

-- EDID DATA DUMP TEXT --

Vendor Name: MEL  
Product Code LSB (HEX): 0  
Product Code MSB (HEX): 43  
Product Code (DEC): 17152  
(Microsoft INF ID: MEL4300)  
Serial Number: 0 HEX: 0  
Week of Manuf: 1  
Year of Manuf: 98

EDID Version: 1  
EDID Revision: 1  
Extension Flag: 0

Input Singal: ANALOG  
Setup: NO  
Sync on Green: YES  
Composite Sync: YES  
Separate Sync: YES  
V Sync Serration: NO  
V Signal Level: 0.700V/0.300V (1V p-p)

Max Image Size H (cm): 40  
Max Image Size V (cm): 30  
DPMS Stand By: YES  
DPMS Suspend: YES  
DPMS Active Off: YES  
GTF Support: YES  
Display Type: RGB Color

Gamma: 2.2  
Red x: 0.625  
Red y: 0.340  
Green x: 0.290  
Green y: 0.605  
Blue x: 0.150  
Blue y: 0.070  
White x: 0.283  
White y: 0.297

Established Timings:

720x400@70  
720x400@88  
640x480@60  
640x480@67  
640x480@72  
640x480@75  
800x600@56  
800x600@60  
800x600@72  
800x600@75  
832x624@75  
1024x768@87  
1024x768@60  
1024x768@70  
1024x768@75  
1152x870@75  
1280x1024@75

Standard Timing #1:  
Horizontal Active Pixels: 1800  
Aspect Ratio: 5:4  
Refresh Rate: 80

Standard Timing #2:  
Horizontal Active Pixels: 1800  
Aspect Ratio: 4:3  
Refresh Rate: 85

Standard Timing #3:  
Horizontal Active Pixels: 1600  
Aspect Ratio: 4:3  
Refresh Rate: 85

Standard Timing #4:  
Horizontal Active Pixels: 1600  
Aspect Ratio: 4:3  
Refresh Rate: 75

Standard Timing #5:  
Horizontal Active Pixels: 1280  
Aspect Ratio: 5:4  
Refresh Rate: 85

Standard Timing #6:  
Horizontal Active Pixels: 1280  
Aspect Ratio: 5:4  
Refresh Rate: 75

Standard Timing #7:  
Horizontal Active Pixels: 1024  
Aspect Ratio: 4:3  
Refresh Rate: 85

Standard Timing #8:  
Horizontal Active Pixels: 800  
Aspect Ratio: 4:3  
Refresh Rate: 85

Detailed Timing (block #1):  
Pixel Clock: 299.95  
Horizontal Active: 1800  
Horizontal Blanking: 688  
Vertical Active: 1440  
Vertical Blanking: 67  
(Horizontal Frequency: 120.56 kHz)  
(Vertical Frequency: 79.9 Hz)  
Horizontal Sync Offset: 144  
Horizontal Sync Width: 200  
Vertical Sync Offset: 1  
Vertical Sync Width: 3  
Horizontal Border: 0  
Vertical Border: 0  
Horizontal Image Size: 369  
Vertical Image Size: 295  
Interlaced: NO  
Image: Normal Display  
Sync: Digital Separate  
Bit 1: OFF  
Bit 2: OFF

Monitor Range Limits (block #2):  
Minimum Vertical Rate: 50 Hz  
Maximum Vertical Rate: 160 Hz  
Minimum Horizontal Rate: 30 kHz  
Maximum Horizontal Rate: 121 kHz  
Maximum Pixel Clock: 330 MHz  
GTF Data: 00 0a 20 20 20 20 20 20

Monitor Name (block #3): NUB1107STTUW

Monitor Serial Number (block #4):  
NNNNNNNNNN

EDID EDITOR V1.17 (970612) (C)  
Mitsubishi Electric

EDID DATA DUMP HEX

```
00 ff ff ff ff ff ff 00
34 ac 00 43 ** ** ** **
WW YY 01 01 0e 28 1e 78
e9 04 88 a0 57 4a 9b 26
12 48 4c ff ff 80 c2 94
c2 59 a9 59 a9 4f 81 99
81 8f 61 59 45 59 2b 75
08 b0 72 a0 43 50 90 c8
13 00 71 27 11 00 00 18
00 00 00 fd 00 32 a0 1e
79 21 00 0a 20 20 20 20
20 20 00 00 00 fc 00 52
44 46 32 32 48 0a 20 20
20 20 20 20 00 00 00 ff
00 NN NN NN NN NN NN NN
NN NN 0a 20 20 20 00 SS
```

\*\* : Serial number (HEX)  
WW : Week of manufacture  
YY : Year of manufacture  
NN : Serial number (ASCII)  
SS : Checksum

## Adjustment procedure

### 3.11 Default inspection

#### 3.11.1 Default setting of switches

Confirm that the following switch is set as follows.

- (1) Power switch: OFF

#### 3.11.2 Default setting of OSD

Confirm that each OSD setting is as shown in the OSD display (section 3.7.3) table (user mode/factory mode).

If the setting class is an item for each timing, carry out for each adjustment timing.

- \* CENTER is the factory adjustment value called when the (-) (+) ADJUST buttons are pressed simultaneously in the normal mode.

Only CONTRAST will be set to MAX when the (-) (+) ADJUST buttons are pressed simultaneously in the normal mode.

#### 3.11.3 Checking the labels

Confirm that the "SERVICEMAN WARNING", "rating label", "manufacturing date stamp", "SERIAL NO. label", and "set sub-No.", etc., are attached to the specified position, and have been checked.

#### 3.11.4 Packaging

- (1) There must be no remarkable contamination, tearing or scratches, etc.
- (2) The model name must be accurately displayed.
- (3) The SERIAL NO. must be attached. (Must be the same No. as the set.)
- (4) The package must be accurately sealed.

## Adjustment procedure

### 3.12 Degaussing with handy-demagnetizer


#### 3.12.1 General precautions

- (1) Carry this procedure out with the monitor power ON.
- (2) When degaussing with handy-demagnetizer, the demagnetizer power must be turned ON and OFF at a position at least 1m away from CRT tube.
- (3) Use a bar type demagnetizer instead of a ring type.  
Carefully and slowly (1m/3 sec.) demagnetize the CRT tube and bezel side surface.  
When separating the degaussing coil at the end, separate as slow as possible with the following procedure.  
If separated quickly, stripes could remain at the picture corners.

#### 3.12.2 How to hold and use the handy-demagnetizer


- (1) Approach the demagnetizer as carefully and slowly (approx. 1m/3 sec.) as possible, and move around the bezel side periphery two to three times.
- (2) Next, gradually (approx. 1m/3 sec.) move to the CRT tube side, and move around the CRT tube four to five times with the following procedure.
- (3) Finally, leave the CRT tube as slowly (approx. 1m/3 sec.) as possible, and turn the handy-

Looking from side of set




<Holding the hand degaussing unit>

Face the hand degaussing unit so that the longitudinal direction is vertical in respect to the CRT.



Do not hold the hand degaussing unit so that the longitudinal direction is parallel in respect to the CRT.




demagnetizer unit switch OFF at a position 1 to 1.5m away.

### 3.13 Caution

Do not input the user timing before factory adjustments.  
(The automatic tracking of the FOCUS could be adversely affected.)

# Timing chart

## 3.14 Timing chart



※Refer to after the next page for the preset timing details.



# Adjustement timing

NO	Fh (KHz)	Clock (MHz)	Th (μSEC)	Tsh (μSEC)	Tth (μSEC)	Tbh (μSEC)	Tdh (μSEC)	Unh- zation	H re- trace s+f+b	Fv (Hz)	Tv (mSEC)	Tsv (mSEC)	Tv (mSEC)	Tbv (mSEC)	Tdv (mSEC)	V re- trace	Hs	Vs	VIDEO level (V)	set up level (V)	Serra- tion	NSB 1107 STUW	MLB 1107 STUW	Remarks
1	31.470	25.175	31.778 (800)	3.813 (96)	0.636 (16)	1.907 (48)	25.422 (640)	80.00	6.356 (449)	70.090 (525)	14.268 (449)	0.064 (2)	0.382 (12)	1.111 (35)	12.711 (400)	1.175	-	-	0.7	-	-	-	-	(640*400)70Hz
2	31.470	25.175	31.778 (800)	3.813 (96)	0.636 (16)	1.907 (48)	25.422 (640)	80.00	6.356 (449)	59.940 (525)	16.693 (525)	0.064 (2)	0.318 (10)	1.048 (33)	15.253 (480)	1.112	-	-	0.7	-	-	00	00	VGA(640*480)60Hz
3	37.500	31.500	26.667 (840)	2.032 (64)	0.508 (16)	3.810 (120)	20.317 (640)	76.19	6.350 (500)	75.000 (500)	13.333 (500)	0.080 (3)	0.027 (1)	0.426 (16)	12.800 (480)	0.506	-	-	0.7	-	-	-	-	VESA(640*480)75Hz
4	43.269	36.000	23.111 (832)	1.556 (56)	1.556 (56)	2.222 (80)	17.778 (640)	76.92	5.334 (509)	85.008 (509)	11.764 (509)	0.069 (3)	0.023 (1)	0.578 (25)	11.093 (480)	0.647	-	-	0.7	-	-	-	-	VESA(640*480)85Hz
5	46.875	49.500	21.333 (1056)	1.616 (80)	0.323 (16)	3.232 (160)	16.162 (800)	75.76	5.171 (625)	75.000 (625)	13.333 (625)	0.064 (3)	0.021 (1)	0.448 (21)	12.800 (600)	0.512	+	+	0.7	-	-	-	-	VESA(800*600)75Hz
6	53.674	56.250	18.631 (1048)	1.138 (64)	0.569 (32)	2.702 (152)	14.222 (800)	76.34	4.409 (631)	85.061 (631)	11.756 (631)	0.056 (3)	0.019 (1)	0.503 (27)	11.179 (600)	0.559	+	+	0.7	-	-	01	01	VESA(800*600)85Hz
7	60.020	78.750	16.661 (1312)	1.219 (96)	0.203 (16)	2.235 (176)	13.004 (1024)	78.05	3.657 (800)	75.029 (800)	13.328 (800)	0.050 (3)	0.017 (1)	0.466 (28)	12.795 (768)	0.516	+	+	0.7	-	-	02	02	VESA(1024*768)75Hz
8	68.677	94.500	14.561 (1376)	1.016 (96)	0.508 (48)	2.201 (208)	10.836 (1024)	74.42	3.725 (808)	84.997 (808)	11.765 (808)	0.044 (3)	0.015 (1)	0.524 (36)	11.183 (768)	0.568	+	+	0.7	-	-	03	03	VESA(1024*768)85Hz
9	79.976	135.000	12.504 (1688)	1.067 (144)	0.119 (16)	1.837 (248)	9.481 (1280)	75.82	3.023 (1066)	75.025 (1066)	13.329 (1066)	0.038 (3)	0.013 (1)	0.475 (38)	12.804 (1024)	0.513	+	+	0.7	-	-	04	04	VESA(1280*1024)75Hz
10	91.146	157.500	10.971 (1728)	1.016 (160)	0.406 (64)	1.422 (224)	8.127 (1280)	74.08	2.844 (1417)	85.027 (1417)	11.761 (1417)	0.033 (3)	0.011 (1)	0.483 (69)	11.234 (1344)	0.516	+	+	0.7	-	-	05	05	VESA(1280*1024)85Hz
11	93.750	202.500	10.667 (2560)	0.948 (224)	0.316 (128)	1.501 (352)	6.444 (1856)	74.07	2.765 (1500)	75.000 (1500)	13.333 (1500)	0.027 (3)	0.011 (1)	0.491 (104)	12.800 (1392)	0.523	+	+	0.7	-	-	06	06	VESA(1600*1200)75Hz
12	106.250	229.500	9.412 (2640)	0.837 (224)	0.279 (144)	1.325 (304)	6.972 (1920)	74.08	2.441 (1500)	85.000 (1500)	11.765 (1500)	0.028 (3)	0.009 (1)	0.433 (46)	11.294 (1200)	0.461	+	+	0.7	-	-	07	07	VESA(1600*1200)85Hz
13	106.270	261.000	9.41 (2456)	0.828 (216)	0.368 (96)	1.349 (352)	6.866 (1792)	72.96	2.545 (1500)	74.997 (1500)	13.334 (1500)	0.028 (3)	0.009 (1)	0.649 (69)	12.647 (1344)	0.677	+	+	0.7	-	-	-	-	VESA(1792*1344)75Hz
14	112.500	288.000	8.889 (2560)	0.778 (224)	0.444 (128)	1.222 (352)	6.444 (1856)	72.49	2.444 (1500)	75.000 (1500)	13.333 (1500)	0.027 (3)	0.009 (1)	0.924 (104)	12.373 (1392)	0.951	+	+	0.7	-	-	-	-	VESA(1856*1392)75Hz
15	112.500	287.000	8.889 (2640)	0.754 (224)	0.485 (144)	1.185 (352)	6.465 (1920)	72.73	2.424 (1500)	75.000 (1500)	13.333 (1500)	0.027 (3)	0.009 (1)	0.498 (56)	12.800 (1440)	0.525	+	+	0.7	-	-	08	08	VESA(1920*1440)75Hz
16	35.00	30.240	28.571 (864)	2.116 (64)	2.116 (64)	3.175 (96)	21.164 (96)	74.08	7.407 (525)	66.67 (525)	15.000 (525)	0.086 (3)	0.086 (3)	1.114 (39)	13.714 (480)	1.2	-	-	0.7	-	-	-	-	APPLE13(640*480)
17	49.710	57.270	20.115 (1152)	1.118 (64)	0.559 (32)	3.910 (224)	14.528 (832)	72.22	5.587 (667)	74.530 (667)	13.417 (667)	0.060 (3)	0.020 (1)	0.785 (39)	12.552 (624)	0.845	-	-	0.7	-	-	-	-	APPLE16(832*624)
18	60.240	80.000	16.600 (1328)	1.200 (96)	0.400 (32)	2.200 (176)	12.800 (1024)	77.11	3.800 (804)	74.930 (804)	13.346 (804)	0.050 (3)	0.049 (3)	0.498 (30)	12.749 (768)	0.548	-	-	0.7	-	-	-	-	APPLE19(1024*768)
19	68.680	100.000	14.560 (1456)	1.280 (128)	0.320 (32)	1.440 (144)	11.520 (1152)	79.12	3.040 (915)	75.060 (915)	13.322 (915)	0.044 (3)	0.043 (3)	0.568 (39)	12.667 (870)	0.612	-	-	0.7	-	-	09	09	APPLE21(1152*870)
20	100.200	219.638	9.980 (2192)	0.801 (176)	0.546 (120)	1.348 (296)	7.285 (1600)	73.00	2.895 (1336)	75.000 (1336)	13.333 (1336)	0.03 (3)	0.01 (1)	0.519 (52)	12.774 (1280)	0.549	-	-	0.7	-	-	-	-	GTF(1600*1280)75Hz
21	107.200	234.982	9.328 (2192)	0.749 (176)	0.511 (120)	1.260 (296)	6.809 (1600)	73.00	2.520 (1340)	80.000 (1340)	12.5 (1340)	0.028 (3)	0.009 (1)	0.522 (56)	11.94 (1280)	0.55	-	-	0.7	-	-	-	-	GTF(1600*1280)80Hz
22	114.240	252.242	8.754 (2208)	0.698 (176)	0.507 (128)	1.205 (304)	6.343 (1600)	72.46	2.410 (915)	85.000 (915)	11.765 (915)	0.026 (3)	0.009 (1)	0.525 (60)	11.204 (1280)	0.551	-	-	0.7	-	-	-	-	GTF(1600*1280)85Hz
23	105.675	261.229	9.463 (2472)	0.766 (200)	0.521 (136)	1.286 (336)	6.891 (1800)	72.82	2.573 (1409)	75.000 (1409)	13.333 (1409)	0.028 (3)	0.009 (1)	0.52 (55)	12.775 (1350)	0.548	-	-	0.7	-	-	-	-	GTF(1800*1350)75Hz
24	113.040	278.435	8.846 (2472)	0.716 (200)	0.487 (136)	1.202 (336)	6.442 (1800)	72.82	2.405 (1413)	80.000 (1413)	12.5 (1413)	0.027 (3)	0.009 (1)	0.522 (59)	11.943 (1350)	0.549	-	-	0.7	-	-	-	-	GTF(1800*1350)80Hz
25	120.445	299.667	8.303 (2488)	0.667 (200)	0.481 (144)	1.148 (344)	6.007 (1800)	72.35	2.296 (1417)	85.000 (1417)	11.765 (1417)	0.025 (3)	0.008 (1)	0.523 (63)	11.208 (1350)	0.548	-	-	0.7	-	-	10	09	GTF(1800*1350)85Hz
26	112.725	278.656	8.871 (2472)	0.718 (200)	0.488 (136)	1.206 (336)	6.460 (1800)	72.82	2.412 (1503)	75.000 (1503)	13.333 (1503)	0.027 (3)	0.009 (1)	0.523 (59)	12.774 (1440)	0.55	-	-	0.7	-	-	-	-	GTF(1800*1440)75Hz
27	120.560	299.953	8.295 (2488)	0.667 (200)	0.480 (144)	1.147 (344)	6.001 (1800)	72.34	2.294 (1507)	80.000 (1507)	12.5 (1507)	0.025 (3)	0.008 (1)	0.523 (63)	11.944 (1440)	0.548	-	-	0.7	-	-	-	-	GTF(1800*1440)80Hz

Mark ○ : Factory adjustment  
 Mark □ : Factory adjustment [Though they are presets, it does not apply to the specification of the picture distortion. The sync. signals are reference to the above. (It is possible to reset with the above timings.)]  
 Mark ▲ : Initial data [So long as initial data, the sync. signals are reference to Hs: + and Vs: -. However, it is necessary to adjust only the H-SIZE, H-PHASE, DBF-H-AMP, DBF-H-PHASE in factory mode.]  
 The numbers after the marks are the number of preset.

## Adjustment procedure

### 3.16 USB monitor control data

Address (HEX)	Data (HEX)	Contents	Address (HEX)	Data (HEX)	Contents
F00	12	Descriptor byte number	F40	45	"E"
F01	01	Descriptor type	F41	00	
F02	00	USB release No. (Lower order)	F42	43	"C"
F03	01	USB release No. (Upper order)	F43	00	
F04	00	Device class	F44	54	"T"
F05	00	Device subclass	F45	00	
F06	00	Device protocol	F46	52	"R"
F07	08	MAX packet size 0	F47	00	
F08	52	Vender ID (Lower order) : 0452	F48	49	"I"
F09	04	Vender ID (Upper order)	F49	00	
F0A	83	Product ID (Lower order) : 0083	F4A	43	"C"
F0B	00	Product ID (Upper order)	F4B	00	
F0C	00	Device release No. (Lower order)	F4C	12	This descriptor size
F0D	01	Device release No. (Upper order)	F4D	03	This descriptor type
F0E	04	Index to character descriptor to descript supplier	F4E	4E	"N"
F0F	2C	Index to character descriptor to descript product	F4F	00	
F10	3E	Index to character descriptor to descript serial No. of device	F50	53	"S"
F11	01	Possible number of configuration	F51	00	
F12	FF		F52	42	"B"
F13	FF		F53	00	
F14	FF		F54	31	"1"
F15	FF		F55	00	
F16	FF		F56	31	"1"
F17	FF		F57	00	
F18	FF		F58	30	"0"
F19	FF		F59	00	
F1A	FF		F5A	37	"7"
F1B	FF		F5B	00	
F1C	FF		F5C	55	"U"
F1D	FF		F5D	00	
F1E	FF		F5E	16	This descriptor size
F1F	FF		F5F	03	This descriptor type
F20	04	This descriptor size	F60	31	"1"
F21	03	Descriptor type	F61	00	
F22	09	Language ID	F62	39	"9"
F23	04	Language ID	F63	00	
F24	28	This descriptor size	F64	39	"9"
F25	03	Descriptor type	F65	00	
F26	4D	"M"	F66	39	"9"
F27	00		F67	00	
F28	49	"I"	F68	31	"1"
F29	00		F69	00	
F2A	54	"T"	F6A	32	"2"
F2B	00		F6B	00	
F2C	53	"S"	F6C	33	"3"
F2D	00		F6D	00	
F2E	55	"U"	F6E	34	"4"
F2F	00		F6F	00	
F30	42	"B"	F70	46	"F"
F31	00		F71	00	
F32	49	"I"	F72	41	"A"
F33	00		F73	00	
F34	53	"S"	F74	FF	
F35	00		F75	FF	
F36	48	"H"	F76	FF	
F37	00		F77	FF	
F38	49	"I"	F78	FF	
F39	00		F79	FF	
F3A	20	Space	F7A	FF	
F3B	00		F7B	FF	
F3C	45	"E"	F7C	FF	
F3D	00		F7D	FF	
F3E	4C	"L"	F7E	FF	
F3F	00		F7F	FF	






AUTO-SCANNING WITH DIGITAL CONTROL  
COLOR DISPLAY MONITOR

---

## Diamond Pro 2020u

---

MODEL **NUB1107STTUW**  
USER'S GUIDE



For future reference, record the serial number of your display monitor in the space below:

SERIAL No.

The serial number is located on the rear cover of the monitor.

Internet Home Page: <http://www.mitsubishi-display.com/>

Supplying Windows 95/98 INF File download service, new products information, etc.

## RADIO INTERFERENCE REGULATIONS STATEMENT FOR U.S.A.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

THIS PRODUCT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS WITH SIGNAL CABLE SC-B102 OR SC-B104. USE IT TO REDUCE THE POSSIBILITY OF CAUSING INTERFERENCE TO RADIO, TELEVISION, AND OTHER ELECTRIC DEVICES.

NO USER SERVICEABLE PARTS INSIDE. DO NOT ATTEMPT TO MODIFY THIS EQUIPMENT. IF MODIFIED, YOUR AUTHORITY TO OPERATE THIS EQUIPMENT MIGHT BE VOIDED BY FCC.

### Declaration of Conformity - United States only

Product Name: 22 in. (55cm) Color Display Monitor  
Type: NUB1107STTUW  
Brand Name: MITSUBISHI

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For questions regarding this declaration, contact:  
Mitsubishi Electronics America, Inc.  
5665 Plaza Drive, P.O. Box 6007,  
Cypress, California 90630-0007

or, call

714-220-2500

To identify this product, refer to the model number found on the product.

### ANMERKUNG:

Dieser Monitor erfüllt die Anforderungen der deutschen Ergonomie-Norm ZH1/618/10.80 bei Verwendung der beiden folgenden Timing:

Auflösung	Videoeingang	fH(kHz)	fV(Hz)	Interlace/Non-Interlace
1600x1200	Analog RGB,	93.8	75.0	Non-Interlaced
	0.7Vs-s			

Aus ergonomischen Gründen wird empfohlen, die Grundfarbe Blau nicht auf dunklerem Untergrund zu verwenden (schlechte Erkennbarkeit, Augenbelastung bei zu geringem Zeichenkontrast).

Bei hellem Hintergrund empfehlen wir aus ergonomischen Gründen nur Vertikalfrequenzen größer oder gleich 70Hz zu verwenden.

Zur Trennung vom Netz ist der Netzstecker aus der Steckdose zu ziehen, welche sich in der Nähe des Gerätes befinden muß und leicht zugänglich sein soll.


Das Gerät stellt sich automatisch auf die zutreffende Nennspannung ein.

As an ENERGY STAR Partner, Mitsubishi Electric Corporation has determined that this product meets the ENERGY STAR guidelines for energy efficiency.

### 高調波ガイドライン適合品

この装置は、情報処理装置等電波障害自主規制協議会(VCCI)の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをしてください。



Energy 2000 Labeling Award



### **Congratulations!**

You have just purchased a TCO'99 approved and labelled product! Your choice has provided you with a product developed for professional use. Your purchase has also contributed to reducing the burden on the environment and also to the further development of environmentally adapted electronics products.

### **Why do we have environmentally labelled computers?**

In many countries, environmental labelling has become an established method for encouraging the adaptation of goods and services to the environment. The main problem, as far as computers and other electronics equipment are concerned, is that environmentally harmful substances are used both in the products and during their manufacture. Since it is not so far possible to satisfactorily recycle the majority of electronics equipment, most of these potentially damaging substances sooner or later enter nature.

There are also other characteristics of a computer, such as energy consumption levels, that are important from the viewpoints of both the work (internal) and natural (external) environments. Since all methods of electricity generation have a negative effect on the environment (e.g. acidic and climate-influencing emissions, radioactive waste), it is vital to save energy. Electronics equipment in offices is often left running continuously and thereby consumes a lot of energy.

### **What does labelling involve?**

This product meets the requirements for the TCO'99 scheme which provides for international and environmental labelling of personal computers. The labelling scheme was developed as a joint effort by the TCO (The Swedish Confederation of Professional Employees), Svenska Naturskyddsforeningen (The Swedish Society for Nature Conservation) and Statens Energimyndighet (The Swedish National Energy Administration).

Approval requirements cover a wide range of issues: environment, ergonomics, usability, emission of electric and magnetic fields, energy consumption and electrical and fire safety.

The environmental demands impose restrictions on the presence and use of heavy metals, brominated and chlorinated flame retardants, CFCs (freons) and chlorinated solvents, among other things. The product must be prepared for recycling and the manufacturer is obliged to have an environmental policy which must be adhered to in each country where the company implements its operational policy.

The energy requirements include a demand that the computer and/or display, after a certain period of inactivity, shall reduce its power consumption to a lower level in one or more stages. The length of time to reactivate the computer shall be reasonable for the user.

Labelled products must meet strict environmental demands, for example, in respect of the reduction of electric and magnetic fields, physical and visual ergonomics and good usability.

Below you will find a brief summary of the environmental requirements met by this product. The complete environmental criteria document may be ordered from:

### **TCO Development**

SE-114 94 Stockholm, Sweden

Fax: +46 8 782 92 07

Email (Internet): [development@tco.se](mailto:development@tco.se)

Current information regarding TCO'99 approved and labelled products may also be

obtained via the Internet, using the address:

<http://www.tco-info.com/>

### **Environmental requirements**

#### ***Flame retardants***

Flame retardants are present in printed circuit boards, cables, wires, casings and housings. Their purpose is to prevent, or at least to delay the spread of fire. Up to 30% of the plastic in a computer casing can consist of flame retardant substances. Most flame retardants contain bromine or chloride, and those flame retardants are chemically related to another group of environmental toxins, PCBs. Both the flame retardants containing bromine or chloride and the PCBs are suspected of giving rise to severe health effects, including reproductive damage in fish-eating birds and mammals, due to the bio-accumulative processes. Flame retardants have been found in human blood and researchers fear that disturbances in foetus development may occur.

The relevant TCO'99 demand requires that plastic components weighing more than 25 grams must not contain flame retardants with organically bound bromine or chlorine. Flame retardants are allowed in the printed circuit boards since no substitutes are available.

#### ***Cadmium\*\****

Cadmium is present in rechargeable batteries and in the colour-generating layers of certain computer displays. Cadmium damages the nervous system and is toxic in high doses. The relevant TCO'99 requirement states that batteries, the colour-generating layers of display screens and the electrical or electronics components must not contain any cadmium.

#### ***Mercury\*\****

Mercury is sometimes found in batteries, relays and switches. It damages the nervous system and is toxic in high doses. The relevant TCO'99 requirement states that batteries may not contain any mercury. It also demands that mercury is not present in any of the electrical or electronics components associated with the labelled unit.

#### ***CFCs (freons)***

The relevant TCO'99 requirement states that neither CFCs nor HCFCs may be used during the manufacture and assembly of the product. CFCs (freons) are sometimes used for washing printed circuit boards. CFCs break down ozone and thereby damage the ozone layer in the stratosphere, causing increased reception on earth of ultraviolet light with e.g. increased risks of skin cancer (malignant melanoma) as a consequence.

#### ***Lead\*\****

Lead can be found in picture tubes, display screens, solders and capacitors. Lead damages the nervous system and in higher doses, causes lead poisoning. The relevant TCO'99 requirement permits the inclusion of lead since no replacement has yet been developed.

\* Bio-accumulative is defined as substances which accumulate within living organisms

\*\* Lead, Cadmium and Mercury are heavy metals which are Bio-accumulative.

## CAUTION

The power cord provided with this monitor is designed for safety and must be used with a properly grounded outlet to avoid possible electrical shock.

Do not remove the monitor cabinet as this can expose you to very high voltages and other hazards.

### MANUFACTURER DECLARATION FOR CE-MARKING:

We, Mitsubishi Electric Corp., declare under our sole responsibility, that this product is in conformity with the following standards:

EN60950  
EN55022 Class B  
EN50082-1  
EN61000-3-2  
EN61000-3-3

following the provisions of:

73/23/EEC Low Voltage Directive  
89/336/EEC EMC Directive

### WARNING!

This product is not designed for use in life support devices and Mitsubishi Electric Corporation makes no representations to the contrary. Life support devices are those devices which are used to measure, diagnose, or evaluate the tissue, systems or functions of the human body; or other devices employed to support or sustain life or good health.

### Trademark

IBM, PC, PS/2, PS/V, Personal System/2 are registered trademarks of International Business Machines Corp.

Apple Macintosh is a registered trademark of Apple Computer, Inc. Quadra is a trademark of Apple Computer, Inc.

UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.

ENERGY STAR is a U.S. registered mark.

1. INTRODUCTION .....	6
1.1 Features .....	6
1.2 Internal Preset Memory Capability .....	7
1.3 Power Management Function .....	7
1.4 DDC .....	7
1.5 Location Considerations .....	7
1.6 Cleaning Your Monitor .....	7
1.7 Unpacking .....	8
1.8 Tilt/Swivel Base .....	8
Screen Position Adjustment .....	8
1.9 Quick Operation Chart .....	8
2. PART NAME .....	9
2.1 Control Names .....	9
2.2 Function .....	9
3. INSTALLATION AND CONNECTION .....	10
3.1 AC Power Connection .....	10
3.2 Signal Cable Connection .....	10
3.2.1 Connecting to any IBM VGA Compatible System .....	10
3.2.2 Connecting to an Apple Macintosh Computer .....	10
3.2.3 Connecting to a Unix Workstation & Third Party Graphics Card .....	10
3.2.4 BNC Connection .....	11
3.3 USB System Basic Application .....	11
3.4 Installation of USB Function .....	12
4. OSD(On Screen Display) FUNCTIONS .....	14
4.1 How to adjust the screen .....	14
4.2 Adjustment Items .....	15
5. TROUBLESHOOTING .....	19
6. SPECIFICATIONS .....	21
7. APPENDIX .....	22
7.1 Monitor Signal Input Connector (DB9-15P) ..	22
7.2 Signal Cable SC-B102 or SC-B104 .....	22
7.3 Macintosh Adapter AD-A205 settings .....	22

# 1

Congratulations on your purchase of the high resolution color monitor. We designed this monitor to provide you with years of reliable trouble-free operation.

This guide tells you how to connect, adjust and care for your monitor. This guide also provides technical specifications and instructions for troubleshooting any basic problems you may experience with your monitor.

## 1.1 Features

The Diamond monitor is a 55cm/22"(51cm/20" Diagonal Viewable Image) intelligent, microprocessor-based monitor compatible with most analog RGB (Red, Green, Blue) display standards, including PS/V®, PS/2®, Apple® Macintosh® Centris, Quadra, Macintosh II and Power Macintosh family signals.

It provides crisp text and vivid color graphics with VGA, SVGA, XGA (non-interlaced), and most Macintosh compatible color video cards.

- The monitor's wide auto-scanning compatibility range makes it possible to upgrade video cards or software without purchasing a new monitor.
  - Digitally controlled auto-scanning is done using an internal microprocessor, for horizontal scan frequencies between 30kHz and 121kHz, and vertical scan frequencies between 50Hz and 160Hz. The microprocessor-based intelligence allows the monitor to operate in each frequency mode with the precision of a fixed frequency monitor.
  - The monitor contains resident memory for pre-programmed screen display standards and is also capable of storing additional user adjustment parameters.
  - The monitor is capable of producing a non-interlaced maximum addressable resolution format of 1800 dots x 1440 lines. This display is well suited for windowing environments.
  - Because of the analog signal inputs, the monitor can display an unlimited palette of colors that can be manually adjusted to suit your specific needs.
  - The monitor has a power management function accorded to VESA™-DPMS™-standard. To save energy, the monitor must be connected to a system compliant with the VESA™ -DPMS™-standard. (Refer to your computer and/or video card instructions for proper operation.)
  - To ensure ease of installation and ongoing use, the monitor features On Screen Display (OSD) of all monitor set-up and adjustment functions.
  - For use in a variety of applications, the monitor complies with UL 1950, CSA C22.2 No.950 and EN60950 for safety, FCC Class-B, VCCI Class-B and EN55022 Class-B for EMI, MPR-II, ISO 9241-3, ISO9241-7, ISO9241-8 and ZH1/618 for ergonomics. The monitor also complies with TCO'99 guideline for environmental safe use.
- Digital Chassis design for lighter, more compact enclosure and increased screen performance.
  - The world's standard DIAMONDTRON tube upgraded with improved focus and convergence for supersharp and pure picture images.
  - The monitor complies with Video Electronics Standards Association (VESA™) DDC™1/2B(EDID) specification. If your computer provides DDC™1/2B(EDID) function, setup will be done automatically.
  - Fine 0.25-0.27mm variable aperture grille pitch/Maximum addressable resolution of 1800 x 1440.
  - USB self-powered hub with 2 upstream ports and 3 downstream ports.

## 1.2 Internal Preset Memory Capability

To minimize adjustment needs, the factory has preset popular display standards into the monitor, as shown in Table 1. If any of these display standards are detected, the picture size and position are automatically adjusted. All of the factory presets may be overwritten by adjusting the user controls. The monitor is capable of automatically storing up to 15 additional display standards. The new display information must differ from any of the existing display standards by at least 1kHz for the horizontal scan frequency or 1Hz for the vertical scan frequency or the sync signal polarities must be different.

Table 1. Memory Buffer Factory Presets

PRESET TIMING	Fh(kHz)	Fv (Hz)	Polarity	
			H	V
640 x 480 N.I.	31.5	60.0	-	-
800 x 600 N.I.	53.7	85.1	+	+
1024 x 768 N.I.	60.0	75.0	+	+
1024 x 768 N.I.	68.7	85.0	+	+
1152 x 870 N.I.	68.7	75.1	-	-
1280 x 1024 N.I.	80.0	75.0	+	+
1280 x 1024 N.I.	91.1	85.0	+	+
1600 x 1200 N.I.	93.8	75.0	+	+
1600 x 1200 N.I.	106.3	85.0	+	+
1800 x 1350 N.I.	120.4	85.0	-	-
1800 x 1440 N.I.	120.6	80.0	-	-

## 1.3 Power Management Function

The monitor has the power management function which reduces the power consumption of the monitor when not in use. There are three reduced power level modes.

Mode	Power(With no USB operation)	Power-On Indicator
Normal	155 W	Green
Stand-By	≤ 15 W	Amber
Suspend	≤ 15 W	Amber
Off	≤ 3 W	Amber

## 1.4 DDC

The monitor includes the VESA DDC™1 and DDC™2B feature. DDC (Display Data Channel) is a communication channel over which the monitor automatically informs the computer system about its capabilities (e.g. each supported resolution with its corresponding timing). DDC is routed through previously unused pins of the 15-pin VGA connector.

The system will perform "Plug and Play" feature if both, monitor and computer, implement the DDC protocol.

## 1.5 Location Considerations

When setting up and using the monitor, keep the following in mind:

- For optimum viewing, avoid placing the monitor against a bright background or where sunlight or other light sources may reflect on the display area of the monitor; place the monitor just below eye level.
- Place the monitor away from strong magnetic or electromagnetic fields, such as high capacity transformers, electric motors, large current power lines, steel pillars, etc...  
Magnetism can cause distortion in the picture and/or color purity.
- Avoid covering the slots or openings of the monitor. Allow adequate ventilation around the monitor so the heat from the monitor can properly dissipate. Avoid putting the monitor into any enclosure that does not have adequate ventilation.
- Avoid exposing the monitor to rain, excessive moisture, or dust, as this can cause a fire or shock hazard.
- Avoid placing the monitor, or any other heavy object, on the power cord. Damage to the power cord can cause a fire or electrical shock.
- When transporting the monitor, handle it with care.

## 1.6 Cleaning Your Monitor

When clean the monitor, please follow these guidelines:

- Always unplug the monitor before cleaning.
- Wipe the screen and cabinet front and sides with a soft cloth.
- If the screen requires more than dusting, apply a household window cleaner to a soft cloth to clean the monitor screen.

### CAUTION

*Do not use benzene, thinner or any volatile substances to clean the unit as the finish may be permanently marked. Never leave the monitor in contact with rubber or vinyl for an extended time period.*

### 1.7 Unpacking

After you unpack the box you should have all of the items indicated in Figure 1. Save the box and packing materials in case you ship or transport the monitor.




Figure 1.

1. Color Monitor
2. AC Power Cord
3. Signal Cable SC-B102 (or SC-B104)
4. USB Upstream Cable
5. Macintosh Adapter AD-A205
6. User's Guide (this document)
7. Warranty-Card
8. Questionnaire-Card

### 1.8 Tilt/Swivel Base

The monitor comes with a tilt/swivel base. This enables you to position the monitor to the best angle and tilt for maximum viewing comfort.

#### Screen Position Adjustment

Adjust the tilt and rotation of the monitor by placing your hands at opposite sides of the case. You can adjust the monitor 90 degrees right or left, 10 degrees up or 5 degrees down, as shown below.





Figure 2.

#### CAUTION

Keep your fingers away from the pivot area of the tilt/swivel base.

### 1.9 Quick Operation Chart

To summarize the steps in connecting your computer with the color monitor and setting the necessary controls and switches, refer to the chart below.



# 2

## 2.1 Control Names

See Figures 3 and 4 for the location of the user controls, indicator and connectors.

Each part is identified by number and is described individually.

### FRONT




Figure 3

### REAR




Figure 4

## 2.2 Function

1. **POWER SWITCH:** A push-on / push-off switch for AC power.
2. **POWER-ON INDICATOR:** This indicator illuminates at green when AC power is on, and illuminates at amber when the monitor is in the power management modes.
3. **INPUT CONNECTOR SELECT BUTTON:** Push to select the signal input connector, BNC or D-SUB.
4. **SCROLL BUTTON:** Push to select group icon.
5. **ENTER BOTTON:** Push to fix / unfix item icon.
6. **FUNCTION ADJUST BUTTONS:** Push the adjust buttons to select the item icon and to adjust the image on the screen.
7. **DOWNSTREAM PORT:** To connect USB camera, keyboard, mouse, etc.
8. **AC POWER CONNECTOR**
9. **SIGNAL INPUT CONNECTOR (DB9-15P)**
10. **SIGNAL INPUT CONNECTORS (BNC)**
11. **UPSTREAM PORTS:** To connect to USB equipped computer(s).
12. **DOWNSTREAM PORTS:** To connect to USB equipped peripherals, e.g, USB camera, keyboard, printer, etc.



# 3

On the back of the monitor four kinds of plug-in connections are provided: AC power connector for the AC input, DB9-15P connector and BNC connector for video signal input and USB ports for USB communication.

## 3.1 AC Power Connection

One end of the AC power cord is connected into the AC power connector on the back of the monitor. The other end is plugged into a properly grounded three-prong AC outlet. The monitor's auto-sensing power supply can automatically detect 100-120V AC or 220-240V AC and 50 or 60Hz.

## 3.2 Signal Cable Connection

The attached signal cable provides a DB9-15P connector for the VGA compatible analog RGB outputs on your computer. Apple Macintosh computers can also be interfaced with using the included Mitsubishi Macintosh adapter AD-A205.

### 3.2.1 Connecting to Any IBM VGA Compatible System

Figure 5 shows the SC-B102 or SC-B104 cable connection to the Video Graphics Array (VGA) port in an IBM Personal System/2<sup>®</sup> series, or any VGA compatible system.

1. Power off, both the monitor and the computer.
2. Connect the one end of the SC-B102 or SC-B104 cable to the DB9-15P connector on the VGA controller card.
3. Connect the other end of the SC-B102 or SC-B104 cable to the DB9-15P receptacle on the back of the monitor.
4. Power on the computer, then the monitor.
5. After using the system, power off the monitor, then off the computer.




Figure 5.

### CAUTION

The socket-outlet shall be installed near the equipment and shall be easily accessible. During servicing, disconnect the plug from the socket-outlet.  
Même si le moniteur est mis hors tension il reste toujours alimenté. La prise secteur devrait ainsi être facilement accessible en cas d'urgence.

### 3.2.2 Connecting to An Apple Macintosh Computer

Figure 6 shows the SC-B102 or SC-B104 cable and AD-A205 Adapter to the video port in an Apple Macintosh.

1. Power off, both the monitor and the computer.
2. Set the DIP switches of Macintosh Adapter according to the setting chart.  
(See 7.3 Macintosh Adapter AD-A205 settings)
3. Connect the 15-pin (DB-15P) end of the AD-A205 Adapter to the straight 15-pin connector on the Macintosh video port on the computer or on the video board.
4. Connect the sub-miniature 15-pin (DB9-15P) end of AD-A205 Adapter to the SC-B102 or SC-B104 cable.
5. Connect the other end of the SC-B102 or SC-B104 cable to the DB9-15P receptacle on the back of the monitor.
6. Power on the Macintosh, then the monitor.
7. After using the system, power off the monitor, then off the Macintosh.




Figure 6.

### 3.2.3 Connecting to a Unix Workstation & Third Party Graphics Card

Figure 7 shows the SC-B102 (or SC-B104) or "75Ω" coaxial cable (not supplied) connection to the graphics video card (PC-CAD and workstation).

1. Power off, both the monitor and the computer.
2. Connect one end of the SC-B102 (or SC-B104) cable or the "75Ω" coaxial cable to the output connector on the computer, or on the video board.
3. Connect the other end of the SC-B102 (or SC-B104) cable or the "75Ω" coaxial cable to the DB9-15P receptacle or the BNC receptacles on the back of the monitor.
4. Power on the computer, then the monitor.
5. After using the system, power off the monitor, then off the computer.






Figure 7.

### 3.2.4 BNC Connection


- (1) IN CASE OF A COMPOSITE SYNC ON GREEN VIDEO SIGNAL (SYNC ON GREEN):  
Connect the R, G and B video signals to the BNC receptacles on the back of the monitor.




- (2) IN CASE OF EXTERNAL COMPOSITE SYNC SIGNAL:  
Connect the R, G and B video signals and the Composite sync signal to BNC receptacles on rear panel, respectively.



- (3) IN CASE OF SEPARATE HORIZONTAL AND VERTICAL SYNC SIGNALS:  
Connect the R, G and B video signals and the horizontal and vertical sync signals to the BNC receptacles on the rear panel.



### 3.3 USB System Basic Application



### 3.4 Installation of USB Function

1. Power on the display monitor and computer.
2. Enumerate Mitsubishi USB HUB using the following procedure.

**NOTE**

- During the enumeration of Mitsubishi USB Hub, connect the keyboard and mouse equipped with USB function, to the computer and not to the downstream ports on the display monitor. After the enumeration, the keyboard and mouse can be used by connecting to the downstream ports.
- Do not unplug the USB cable during the enumerations.

- (1) Connect the computer and the display monitor with the included USB upstream cable. Figure 8 will appear.
- (2) Click "Next" on Figure 8 to get Figure 9.
- (3) Click "Finish" on Figure 9 to complete the enumeration of Mitsubishi USB HUB.




Figure 8




Figure 9

You can confirm that "Mitsubishi USB HUB" is successfully enumerated with the following method.

- Open "Device Manager" tab in "System" property under "Control Panel". Confirm that "Generic USB HUB" is listed in "Universal Serial Bus Controller". If you can't confirm it, re-enumerate "Mitsubishi USB HUB" again by following (a) or (b).

- (a) Disconnect and connect the USB cable to the upstream port of the display monitor.
- (b) Power Off/On the display monitor.

**NOTE**

If the mark ① appears with "Generic USB HUB", then enumeration was unsuccessful. Select "Generic USB HUB" marked with ① mark and click "Remove" and "Refresh". After that, the enumeration is automatically started.

**NOTE**

The enumeration of USB HUB may be necessary for each USB port on the computer.




Figure 10

3. Enumerate the Mitsubishi Monitor Function using the following procedure.

- (1) Insert Windows® 98 CD-ROM into your computer. Then, Figure 11 will appear.




Figure 11

(2) Click "Next" on Figure 11 and Figure 12 will appear.




Figure 12

(3) Click "Next" on Figure 12 and Figure 13 will appear.




Figure 13

(4) Click "CD-ROM Drive(C)" and "(L)", and click "Next". Figure 14 will appear.




Figure 14

(5) Click "Next" on Figure 14 and Figure 15 will appear. Click "Finish" on Figure 15 to complete Enumeration of Mitsubishi Monitor Function.




Figure 15

You can confirm that Enumeration of Mitsubishi Monitor Function is successful with the following method.

- Open "Device Manager" tab in "System" property under "Control Panel". Confirm that "HID-compliant Device" and "USB Human Interface Device" are listed in "Human Interface Device". If you can't confirm it, re-enumerate "Mitsubishi Monitor Function" again by following (a) or (b).
  - (a) Disconnect and connect the USB cable to the upstream port of the display monitor.
  - (b) Power Off/On the display monitor.

**NOTE**

If the mark ① appears with "HID-Compliant Device" and/or "USB Human Interface Device", the enumeration was unsuccessful. Select "HID-Compliant Device" and/or "USB Human Interface Device" marked with ① mark and click "Remove" and "Refresh". After that, the enumeration is automatically started.




Figure 16

**NOTE**

The following should be observed in order to use the USB function reliably:


- Make sure all connections are made firmly and correctly.
- Do not change the Upstream port during the recognition of the monitor or other peripherals.
- Close all Windows program before changing the Upstream or disconnecting USB cable.

# 4


## 4.1 How to adjust the screen

The monitor has an OSD(On Screen Display) function. The following procedure shows how to adjust the screen with using the OSD function.


- (1) Turn on the monitor.



- (2) Press any button ( ) to display the OSD screen. At the time, marks are blinking.



- (3) Select the group icon on Main Menu by pressing .




Main Menu




- (4) Select the item icon on Sub Menu by pressing or button.

Sub Menu




- (5) Fix the item icon by pressing the enter button . marks are blinking when fixed.





- (6) Adjust by pressing or button.



- (7) To select another item, press button once again. The fixed condition will be cancelled. At the time, marks are blinking.



- (8) If you don't press any button for about ten seconds, the OSD screen will disappear. Or pressing both and buttons simultaneously. The OSD screen will disappear quickly.





### NOTE































The condition of the disappeared OSD screen is memorized until turning off the display monitor. In case that the OSD screen is displayed again before turning off the display monitor, the latest OSD screen will appear.





























## 4.2 Adjustment Items

X: Available

Items	Function	A	B	C	D
CONTRAST	Adjusts the contrast level.		X	X	X
BRIGHT	Adjusts the black level of the screen		X	X	X
COLOR NO	Select the preferable color from Color 1, Color 2, and Color 3.			X	
R-GAIN	Provides the red-color balances for the display.		X	X	X
G-GAIN	Provides the green-color balances for the display.		X	X	X
B-GAIN	Provides the blue-color balances for the display.		X	X	X
COLOR TEMPERATURE	Adjusts the color temperature of the image on the screen.		X	X	X
COLOR RESET	Restores the each color gain and color temperature to the factory preset.	-	-	-	-
H-SIZE	Adjusts the horizontal size of the image on the screen.	X	X	X	
H-PHASE	Adjusts the horizontal position of the image on the screen.	X	X	X	
H-POSITION	Adjusts the horizontal position of the screen.	X	X	X	
V-SIZE	Adjusts the vertical size of the image on the screen.	X	X	X	
V-POSITION	Adjusts the vertical position of the image on the screen.	X	X	X	
PCC-AMP	Straightens the left and right sides of the image on the screen.	X	X	X	
PCC-PHASE	Adjusts the parallelism of the left and right sides of the image on the screen.	X	X	X	
PCC-CENTER	Adjusts the pincushioning near the vertical center of the screen.	X	X	X	
TOP-PCC	Adjusts the pincushioning at the top corners of the screen.	X	X	X	
BOTTOM-PCC	Adjusts the pincushioning at the bottom corners of the screen.	X	X	X	
PIN-BALANCE	Adjusts the curvature of the left and right sides of the image on the screen.	X	X	X	
KEY-BALANCE	Adjusts the vertical slant or tilt of the screen image.	X	X	X	
CORNER-BALANCE	Adjusts the curvature of the left and right sides of the image at the corners of the screen.	X	X	X	
PCC-CENTER-BALANCE	Adjusts the curvature of the both sides of the image at the center of the screen.	X	X	X	
V-LIN-BALANCE	Centers the linearity of the vertical axis of the screen.	X	X	X	
V-LIN	Adjusts the linearity of the vertical axis of the screen.	X	X	X	
ROTATION	Adjusts the rotation of the image on the screen.		X	X	X
ZOOM	Zooms the screen to all sides.	X	X	X	
GEOMETRY RESET	Restores to the factory preset level.	-	-	-	-
TEXT MODE	To get a preferable image for your work.			X	
H-CONVERGENCE	Adjusts the horizontal alignment of the red, green and blue beams.		X	X	X
V-CONVERGENCE	Adjusts the vertical alignment of the red, green and blue beams.		X	X	X
V-CONVERGENCE-TOP	Adjusts the upper vertical alignment of the red, green, and blue beams.		X	X	X
V-CONVERGENCE-BOTTOM	Adjusts the bottom vertical alignment of the red, green, and blue beams.		X	X	X
H-CONVERGENCE-RIGHT	Adjusts the horizontal alignment of the red, green and blue beams on the right part of screen		X	X	X
H-CONVERGENCE-LEFT	Adjusts the horizontal alignment of the red, green and blue beams on the left part of screen.		X	X	X
MOIRE CANCEL	When setting to ON, the moire level on the screen can decreased by the MOIRE CANCEL LEVEL.			X	
MOIRE CANCEL LEVEL	Adjusts the moire level on the screen.		X	X	
CORNER PURITY (TL)	Adjusts the purity of the top-left corners of the screen.		X	X	X
CORNER PURITY (TR)	Adjusts the purity of the top-right corners of the screen.		X	X	X
CORNER PURITY (BL)	Adjusts the purity of the bottom-left corners of the screen.		X	X	X
CORNER PURITY (BR)	Adjusts the purity of the bottom-right of the screen.		X	X	X
CLAMP PULSE POSITION	Uses this function to eliminate excessive green or white background that may occur when both Sync-On-Green and external sync signals are applied to the monitor.			X	
VIDEO LEVEL	Selects video level 1.0V or 0.7V.			X	
DEGAUSS	Eliminates possible color shading or impurity.	-	-	-	-
POWER-SAVE	When setting to ON, the power consumption of the monitor will be reduced when not in use.			X	X
CONTROL LOCK	Locks the OSD function to keep the OSD screen you desired.				X
OSD POSITION	Moves the OSD screen position.			X	X
ALL RESET	Restores all items to the factory preset level.	-	-	-	-
GTF AUTO ADJUST	Adjusts the screen size and distortion automatically.	-	-	-	-
DIAGNOSE	Indicates the current scanning frequency, factory or user preset timing number, and signal input connector.	-	-	-	-
LANGUAGE	Selects the language used on OSD screen.				X
USB UP-STREAM	Selects the Upstream port which you want to use.			X	X
USB PORT COMBINATION	Selects the combination of the Upstream port and signal input connector.			X	X

- A. Press "GEOMETRY RESET" to restore to the factory preset level.
- B. Press  and  buttons together, to restore to the factory preset level.
- C. Press "ALL RESET" to restore to the factory preset level.
- D. Set data does not change by the change of the signal timing.

Group Icon	Item Icon	Item	Press the Minus Button 	Press the Plus Button 
		CONTRAST	To decrease the contrast.	To increase the contrast.
		BRIGHT	To decrease the brightness.	To increase the brightness.
		COLOR NO	To select color 1, color 2, color 3.	
		R-GAIN	To decrease red color level of the color mode selected by "COLOR NO".	To increase red color level of the color mode selected by "COLOR NO".
		G-GAIN	To decrease green color level of the color mode selected by "COLOR NO".	To increase green color level of the color mode selected by "COLOR NO".
		B-GAIN	To decrease blue color level of the color mode selected by "COLOR NO".	To increase blue color level of the color mode selected by "COLOR NO".
		COLOR TEMPERATURE	To decrease the color temperature of the color mode selected by "COLOR NO".	To increase the color temperature of the color mode selected by "COLOR NO".
		COLOR RESET	_____	To restore the color-gain and color temperature of the color mode selected by "COLOR NO" to the factory preset.
		H-SIZE	To narrow the width of the image on the screen.	To expand the width of the image on the screen.
		H-PHASE	To move the image on the screen to the left.	To move the image on the screen to the right.
		H-POSITION	To move the image to the left.	To move the image to the right.
		V-SIZE	To narrow the height of the image on the screen.	To expand the height of the image on the screen.
		V-POSITION	To move the image down.	To move the image up.
		PCC-AMP	To collapse the center of the image.	To expand the center of the image.
		PCC-PHASE	To decrease the width at the top of the screen image and to increase the width at the bottom.	To increase the width at the top of the screen image and to decrease the width at the bottom.
		PCC-CENTER	To narrow the center of the image horizontally.	To expand the center of the image horizontally.
		TOP-PCC	To expand the width of the screen image near the corners of top.	To narrow the width of the screen image near the corners of top.
		BOTTOM-PCC	To expand the width of the screen image near the corners of bottom.	To narrow the width of the screen image near the corners of bottom.
		PIN-BALANCE	To move the top and bottom of the screen image to the right.	To move the top and bottom of the screen image to the left.
		KEY-BALANCE	To make the screen slant to the left.	To make the screen slant to the right.
		CORNER-BALANCE	To move the corners of the screen image to the right.	To move the corners of the screen image to the left.
		PCC-CENTER-BALANCE	To move the center of the image to the left.	To move the center of the image to the right.
		V-LIN-BALANCE	To vertically expand the bottom of the screen and compress the top.	To vertically compress the bottom of the screen and expand the top.
		V-LIN	To vertically compress the center of the screen and expand the top and bottom.	To vertically expand the center of the screen and compress the top and bottom.
		ROTATION	To rotate the image counterclockwise.	To rotate the image clockwise.
		ZOOM	To narrow the screen to all sides.	To expand the screen to all sides.






Group Icon	Item Icon	Item	Press the Minus Button 	Press the Plus Button 	
		GEOMETRY RESET	—————	To restore to factory preset level.	
		TEXT MODE	To select "SHARP" mode.	To select "SMOOTH" mode.	
		H-CONVERGENCE	To move the red to the left and the blue to the right.	To move the red to the right and the blue to the left.	
		V-CONVERGENCE	To move the red to the lower and the blue to the upper.	To move the red to the upper and the blue to the lower.	
		V-CONVERGENCE-TOP	To move the red to the lower and the blue to the upper of top screen.	To move the red to the upper and the blue to the lower of top screen.	
		V-CONVERGENCE-BOTTOM	To move the red to the upper and the blue to the lower on the bottom screen.	To move the red to the lower and the blue to the upper on the bottom screen.	
		H-CONVERGENCE-RIGHT	To move the red to the right and the blue to the left on the right part of screen.	To move the red to the left and the blue to the right on the right part of screen.	
		H-CONVERGENCE-LEFT	To move the red to the left and the blue to the right on the left part of screen.	To move the red to the right and the blue to the left on the left part of screen.	
		MOIRE CANCEL	To select the Moire Cancel mode off.	To select the Moire Cancel mode on.	
		MOIRE CANCEL LEVEL	To decrease the level of the moire-clear wave.		
		CORNER PURITY(TL)	To adjust the purity condition on the top-left corner.		
		CORNER PURITY(TR)	To adjust the purity condition on the top-right corner.		
		CORNER PURITY(BL)	To adjust the purity condition on the bottom-left corner.		
		CORNER PURITY(BR)	To adjust the purity condition on the bottom-right corner.		
		CLAMP PULSE POSITION	To eliminate an excessive green or white-back ground that may occur when both Sync-On-Green and external sync signals are applied to the monitor. To clamp the video signal at the front of the H-Sync pulse.	To clamp the video signal at the back of the H-Sync pulse. If you connect to Macintosh, press plus button.	
		VIDEO LEVEL	To select 1.0V of video input.	To select 0.7V of video input.	
			DEGAUSS	—————	To eliminate possible color shading or impurity.
		POWER SAVE	To select the constant power consumption mode.	To select the power-save mode.	
		CONTROL LOCK	To unlock the OSD function.	To lock the OSD function except for "BRIGHT" and "CONTRAST".	
		OSD POSITION	To move the OSD screen position in a counter clockwise direction.	To move the OSD screen position in a clockwise direction.	
		ALL RESET	—————	To restore all items to the factory preset.	
		GTF AUTO ADJUST	—————	To adjust screen size, position and distortions automatically.	
		DIAGNOSIS	It shows the current scanning frequency, Preset No., and signal input connection.		
		LANGUAGE	To choose the language used on OSD. ENG.....English, FRA.....French, ESP.....Spanish, ITA.....Italian, GER.....German, JPN.....Japanese		

**NOTE**

**CONTROL LOCK:** This is to lock the OSD function to keep the OSD screen image you set. Press plus button to lock the OSD function. You can adjust only "BRIGHT" and "CONTRAST" at the condition. Press minus button to unlock the locked condition.

**GTF:** This function is available when the computer has the GTF™ function according to the VESA®GTF™ standard.





Group Icon	Item Icon	Item	Press the Minus Button 	Press the Plus Button 
		USB UP-STREAM	<p>The USB functions of the computer connected to Upstream port ROOT-A become active.</p> <p><b>NOTE</b></p> <ul style="list-style-type: none"> <li>• The Upstream port in active is colored by blue on the OSD screen.</li> <li>• In case that either the Upstream port ROOT-A or ROOT-B is chosen by this function, the auto-change of the Upstream port is not available.</li> <li>• It may take about 15 seconds until the USB devices have been recognized by the computer after the Upstream port is changed.</li> <li>• Make sure the operation of the devices connected to the downstream ports before changing USB Upstream ports. It may take approximately 15 seconds max. until the devices have been recognized by the computer and start to operate after the Upstream ports are changed.</li> <li>• Do not change the Upstream ports during enumeration on to prevent errors of the operation of devices or application software.</li> <li>• Close all Windows programs before changing Upstream ports.</li> </ul>	<p>The USB functions of the computer connected to Upstream port ROOT-B become active.</p>
		USB PORT COMBINATION	<p>The Upstream port ROOT-A is assigned for signal input connector "D-SUB" and ROOT-B is assigned for "BNC"</p> <p><b>NOTE</b></p> <ul style="list-style-type: none"> <li>• This function is to change the Upstream port automatically in corresponding to the change of signal input connector.</li> <li>• This function is only available in case that both the Upstream ports are connected to the computers.</li> <li>• It may takes 15 seconds until the USB devices have been recognized by the computer after the Upstream port is changed.</li> <li>• In case that the computer chosen enters into a power management mode, the signal input connector and Upstream port are changed to others automatically.</li> <li>• When the Upstream port which is connected to the computer not displays on the screen is selected, the operation of the USB devices connected to the Downstream ports is not shown on the screen of the display monitor.</li> </ul>	<p>The Upstream port ROOT-A is assigned for signal input connector "BNC" and ROOT-B is assigned for "D-SUB".</p>



**NOTE**

USB Monitor Control will be available when installing "USB Monitor Control Software" into the computer. The "USB Monitor Control Software" can be downloaded from Mitsubishi Internet Home Page:  
<http://www.mitsubishi-display.com/>

# 5

Before calling your Authorized Product Support, please check that the items below are properly connected or set. In case of using a non-standard signal, please check the pin assignments and the signal timing of your computer with the specification outlined in 6. SPECIFICATIONS and 7. APPENDIX.

PROBLEM		ITEMS TO CHECK	LOCATION	
No picture	LED On (Green)	<ul style="list-style-type: none"> <li>Contrast and brightness controls.</li> </ul>	<ul style="list-style-type: none"> <li>Front (Adjust to the maximum brightness.)</li> </ul>	
	LED Off	<ul style="list-style-type: none"> <li>Power switch.</li> <li>AC power cord disconnected.</li> </ul>	<ul style="list-style-type: none"> <li>Front</li> <li>Rear</li> </ul>	
	LED On (Amber)	<ul style="list-style-type: none"> <li>Signal cable disconnected.</li> <li>BNC cables are misconnected or the green cable is disconnected.</li> <li>Computer power switch.</li> <li>Power management function is active.</li> </ul>	<ul style="list-style-type: none"> <li>Rear</li> <li>Check the graphics adapter and cables</li> <li>Computer</li> <li>Press any key on the keyboard or move the mouse.</li> </ul>	
The following message appeared			<ul style="list-style-type: none"> <li>Signal cable disconnected.</li> <li>BNC cables are misconnected or the green cable is disconnected.</li> <li>Computer power switch.</li> <li>Power management function is active.</li> </ul>	<ul style="list-style-type: none"> <li>Rear</li> <li>Check the graphics adapter and cables</li> <li>Computer</li> <li>Press any key on the keyboard or move the mouse.</li> </ul>
The following message appeared			<ul style="list-style-type: none"> <li>Input signal frequency range is disagreement.</li> <li>CGA MODE is not available.</li> <li>MDA MODE is not available.</li> <li>EGA MODE is not available.</li> </ul>	<ul style="list-style-type: none"> <li>Check the specification of graphics adapter and monitor</li> </ul>
Abnormal picture	Display is missing, center shifts, or too small or too large of a display size	<ul style="list-style-type: none"> <li>Perform "GEOMETRY-RESET" or "ALL RESET" for a standard signal.</li> <li>Adjust H-SIZE, V-SIZE, H-PHASE, and V-POSITION with non-standard signals.</li> <li>Monitor may not be able to get full-screen image depend on signal. In this case, please select other resolution, or other vertical refresh timing.</li> <li>Make sure you wait a few seconds after adjusting the size of the image before changing or disconnecting the signal.</li> </ul>	<ul style="list-style-type: none"> <li>Front (OSD)</li> <li>Front (OSD)</li> </ul>	
	Display is dark or too bright	<ul style="list-style-type: none"> <li>"VIDEO LEVEL" is not at the appropriate position for your graphics adapter output.(0.7V or 1.0Vp-p)</li> </ul>	<ul style="list-style-type: none"> <li>Front (OSD)</li> </ul>	
	No operation of the USB devices	<ul style="list-style-type: none"> <li>[Universal serial bus controller] is not listed in [Device Manager].</li> </ul>	<ul style="list-style-type: none"> <li>Confirm that Windows98 is installed into the computer.</li> </ul>	
		<ul style="list-style-type: none"> <li>[Generic USB HUB] is not listed in [Device Manager].</li> </ul>	<ul style="list-style-type: none"> <li>Make sure of the cable connections.</li> <li>Restart the computer.</li> <li>Turn off the monitor and then turn on.</li> <li>Disconnect all the cables connected to the Upstream ports and re-connect then.</li> </ul>	
	<ul style="list-style-type: none"> <li>On the OSD screen, the Upstream port to which the USB device you want to use is connected is not colored by blue.</li> </ul>	<ul style="list-style-type: none"> <li>Select the Upstream port by using the OSD screen, "Upstream port selection"</li> </ul>		


PROBLEM	ITEMS TO CHECK	LOCATION
<p>Abnormal Picture</p> <p>Black vertical lines are visible on the screen.</p>	<ul style="list-style-type: none"> <li>Thin vertical black lines on one or both sides of the screen. This minor condition is caused by grille element overlap which can occur during shipping. We suggest slapping the cabinet sides with an open hand after the monitor is warm.</li> </ul> <p>If this fails, position an open white window over the affected area of the screen and maximize the brightness and contrast controls. This will cause localized heating of the overlap which will clear permanently in a few minutes. Be sure to readjust the brightness and contrast controls back to the normal viewing levels after this procedure.</p> 	<ul style="list-style-type: none"> <li>-</li> </ul>
<p>Two fine horizontal lines are visible on the screen.</p>	<ul style="list-style-type: none"> <li>The 2 very faint thin lines across the screen are normal. They are caused by the aperture grille stabilization filaments (Damper Wires) which are required for all aperture grille CRTs'.</li> </ul> 	<ul style="list-style-type: none"> <li>-</li> </ul>
<p>A buzzing sound when power on.</p>	<ul style="list-style-type: none"> <li>A brief vibration or hum sound that is heard just after power up is normal. This is caused by the automatic degaussing function. This sound will be heard each time the monitor is powered up from a cold start and each time the manual degauss button is used.</li> </ul>	<ul style="list-style-type: none"> <li>-</li> </ul>

# 6

Model No.		NUB1107STTUW
CRT	Size	55cm/22"(51cm/20" Diagonal Viewable Image)
	Mask type	Aperture grille
	Gun	In-line
	Deflection angle	90°
	Phosphors	Red, Green, Blue EBU (medium short persistence)
	Aperture grille pitch	0.25-0.27mm (variable)
	Face Plate	Anti-glare, Anti-reflection and Anti-static film
	Focusing method	Dynamic Beam Forming (DBF)
INPUT SIGNAL	Video	0.7 or 1.0Vp-p analog RGB
	Sync	Sync. on Green or separated H, V sync. or Composite sync
SIGNAL INTERFACE	Input Connector	5BNC, DB9-15P
	Input Impedance	75Ω (video), 1kΩ(sync.)
USB	Function	<ul style="list-style-type: none"> <li>Self-powered HUB complying with Universal Serial Bus Specification Rev.1.0</li> </ul>
	Interface	<ul style="list-style-type: none"> <li>2 Upstream ports/12Mbps</li> <li>3 Downstream ports/12Mbps, 1.5Mbps, possible to supply 500mA max. per each Downstream port</li> </ul>
SCANNING FREQUENCY	Horizontal	30 - 121kHz
	Vertical	50 - 160Hz
RESOLUTION (HxV)	1800dots x 1440lines Non-Interlaced maximum addressable resolution format at 80Hz	
WARM-UP TIME	30 minutes to reach optimum performance level	
BRIGHTNESS	100cd/m <sup>2</sup> , standard full white video signal at 9300K (+ 8MPCD)	
BLANKING TIME	Horizontal	≥ 2.3 μsec (typ.)
	Vertical	≥ 450 μsec (typ.)
DISPLAY SIZE	393mm x 295mm(typ.) ratio 4:3	
COLOR	5000K-9300K	
POWER SOURCE	AC100-120/220-240V±10% 50/60Hz 155W (typ.) <170W(typ.): with USB operation>	
OPERATING ENVIRONMENT	Temperature	5 - 35°C
	Humidity	10 - 90%RH (without condensation)
DIMENSIONS	(W)19.7inch x (H)19.7inch x (D)19.0inch / (W) 500mm x (H) 500mm x (D) 482mm	
WEIGHT	Approx. 33.0kg (72.6lbs.)	
TILT/SWIVEL BASE	Tilt Angle	-5° - +10°
	Swivel Angle	±90°
REGULATIONS	Safety	UL1950 (UL), CSA C22.2 No.950 (C-UL) EN60950 (TÜV-GS)
	EMC	FCC Class-B, DOC Class-B EN55022 Class-B, VCCI Class-B EN50082-1, EN61000-3-2, EN61000-3-3
	X-Ray	DHHS, HWC, Röv vom 8.1, 1987
	Other	CE-Marking, MPR-II/TCO'91 ISO9241-3, ISO9241-7, ISO9241-8 (TÜV-ERGO) TCO '99, ZH1/618 (TÜV-GS) International ENERGY STAR Program Energy 2000 Labeling Award Guidelines for the Suppression of Harmonics in Appliances and General-Use Equipment

# 7

## 7.1 Monitor Signal Input Connector (DB9-15P)




**PIN ASSIGNMENTS**

Pin No.	Signal
1	RED VIDEO
2	GREEN VIDEO or COMPOSITE SYNC with GREEN VIDEO
3	BLUE VIDEO
4	GROUND
5	DDC GROUND
6	RED GROUND
7	GREEN GROUND
8	BLUE GROUND
9	NC
10	SYNC GROUND
11	GROUND
12	SDA
13	HORIZONTAL SYNC or COMPOSITE SYNC
14	VERTICAL SYNC(VCLK)
15	SCL

DDC ..... DISPLAY DATA CHANNEL  
 SDA ..... SERIAL DATA  
 SCL ..... SERIAL CLOCK  
 NC ..... NO-CONNECTION

## 7.2 Signal Cable SC-B102 or SC-B104



**PIN ASSIGNMENTS**

Pin No.	Signal
1	RED
2	GREEN
3	BLUE
4	GROUND
5	DDC GROUND
6	RED GROUND
7	GREEN GROUND
8	BLUE GROUND
9	NC
10	SYNC GROUND
11	GROUND
12	SDA
13	HORIZONTAL SYNC
14	VERTICAL SYNC(VCLK)
15	SCL

DDC ..... DISPLAY DATA CHANNEL  
 SDA ..... SERIAL DATA  
 SCL ..... SERIAL CLOCK  
 NC ..... NO-CONNECTION


## 7.3 Macintosh Adapter AD-A205 settings

The AD-A205 Macintosh Adapter allows you to take an advantage of the built in video capabilities of your Macintosh computer with the monitor.

- (1) Set the dip switches of the adapter, before connect to the computer.

- (2) Set the dip switches according to the following chart. By using the following chart, you can choose a main resolution, quickly.

If you wish to operate by other resolution, refer to next page; "AD-A205 Mac Adapter Setting Chart"



Apple Macintosh	Switch ON	Switch Setting
Macintosh IIsi, IIfx, IIfx, LC, LC II	1,2	
Macintosh LC III, LC475, LC630	2,4	
Macintosh Quadra 610, 650, 700, 800, 840AV, 900, 950 Macintosh Centris 610, 650, 660AV	1,2,3,4	
Performa 6260, 6310, 6410, 6420 Power Macintosh 6100, 6100AV, 6200, 6300 Power Macintosh 7100AV, 7200, 7300, 7500, 7600 Power Macintosh 8100, 8100AV, 8500, 8600 Power Macintosh 9500, 9600 Workgroup Server 7350, 8150, 9150, 9650	1,2,6	
Power Macintosh 4400, G3	3,4	

